

13. General Diagnostic Table

A: INSPECTION

Read the DTC or inspect and diagnose the following data in the current data display using Subaru Select Monitor.

1. LAN SYSTEM

Item	Operation	Specifications		Note
		YES	NO	
Diagnostic code	DTC is not displayed when inspecting all DTCs.	DTC is not displayed.	Perform the diagnosis according to DTC.	Refer to the DTC table when there are trouble codes of the CAN communication system for a multiple of modules. <Ref. to LAN(diag)-30, DTC TABLE, LIST, List of Diagnostic Trouble Code (DTC).>
Engine coolant temperature	Check the current data display of ECM, TCM and body integrated unit. Three data value are the same.	Same values	Inspect LAN system.	If engine coolant temperature sensor is not OK, inspect the sensor circuit.
R defogger SW	It turns to ON when pressing switch. (Low-speed CAN is OK)	Turns to ON.	Inspect rear defogger switch.	Rear defogger switch is connected with Low-speed CAN.
R defogger output	When switch input, it is output.	Output	Replace the body integrated unit.	If not operating with output, check the rear defogger relay.
Door lock SW	When locked with door lock switch, it turns to ON.	Turns to ON.	Inspect door lock switch.	
Door lock actuator	When locked with door lock switch, it is output.	Output	Replace the body integrated unit.	—

General Diagnostic Table

LAN SYSTEM (DIAGNOSTICS)

2. BODY INTEGRATED UNIT

Item	Operation	Specifications		Note
		YES	NO	
Illumination VR power supply	Operate the illumination volume, illumination light is controlled according to the change of voltage on data display.	Illumination light is controlled with changing of data.	Inspect the illumination volume.	—
Fuel level resistance	Check the fuel level resistance and fuel level resistance 2. Both resistances are same.	Same values	Inspect the body integrated unit.	Compare the input and output values of body integrated unit.
R wiper SW input	When rear wiper SW to ON, data display turns to ON.	Turns to ON.	Inspect the rear wiper switch.	—
R wiper output	When rear wiper switch to ON, output signal turns to ON.	Turns to ON.	Replace the body integrated unit.	If not operate with output turned to ON, check the rear wiper motor.
Keyless Entry	Keyless entry LOCK/UNLOCK the doors.	Operate	Inspect the keyless antenna.	If the antenna is OK, replace the body integrated unit.
Brake SW	When brake pedal is depressed, it turns to ON.	Turns to ON.	Inspect the brake switch.	—
Shift lock solenoid	The shift lock releases when depressing the brake pedal.	Released	Inspect the shift lock.	—
Body integrated unit registration function setting	Does Vehicle equipment correspond to setting values?	Correspondence	Reconfigure the values according to vehicle equipment.	—
Customize	When changing customize setting, the registration completes correctly.	Registered	Inspect the body integrated unit.	Return to original state after making changes.
Manual mode	Switch the shift (UP/DOWN) on Manual mode. Indicator is changed in 1 — 2.	Change	Inspect the shift lever.	—
Function check	Each checking item operate correctly. (Except for not equipped)	Operate	Inspect for non-functional actuator.	Module is normal if output switches to ON.
Security	After locking with keyless entry system and open the door, the security system operates and the horn sounds.	Horn sounds. (Security system operates.)	Inspect the security system.	Horn does not activate if siren is set to ON by customizing.

WIRING SYSTEM SECTION

WIRING SYSTEM

WI

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

WIRING SYSTEM



	Page
1. Basic Diagnostic Procedure	3
2. Working Precautions	14
3. Power Supply Circuit	15
4. Ground Circuit	22
5. Engine Electrical System	32
6. Vacuum Pump Control System	48
7. AT Control System	50
8. AT Shift Lock Control System	58
9. TPM Control System	59
10. Vehicle Dynamics Control System	60
11. Air Conditioning System	64
12. Airbag System	69
13. Occupant Detection System	74
14. Immobilizer System	75
15. Cruise Control System	76
16. CAN Communication System	79
17. Radiator Fan System	81
18. Charging System	82
19. Starter System	83
20. Remote Engine Start System	84
21. Power Seat System	87
22. Seat Belt Warning System	90
23. Seat Heater System	91
24. Headlight System	92
25. Front Fog Light System	95
26. Back-up Light System	96
27. Stop Light System	97
28. Clearance Light and Illumination Light System	98
29. Turn Signal Light and Hazard Light System	103
30. Interior Light System	105
31. Front Wiper and Washer System	111
32. Rear Wiper and Washer System	112
33. Wiper Deicer System	113
34. Washer Level Warning Light System	114
35. Audio System	115
36. Navigation System	119
37. Rearview Camera System	123
38. Multi-function Display (MFD) System	124
39. Rear Entertainment System	126
40. Front Accessory Power Supply Socket System	129
41. Rear Accessory Power Supply Socket System	130
42. Horn System	131
43. Power Window System	132

44.	Rear Defogger System	136
45.	Remote Control Mirror System	137
46.	Combination Meter System	139
47.	Speedmeter System	143
48.	Fuel Gauge System	144
49.	Coolant Temperature System	145
50.	Oil Pressure Warning Light System	146
51.	Parking Brake / Brake Fluid Level Warning Light System	147
52.	Sunroof Control System	148
53.	Keyless Entry System	149
54.	Security System	153
55.	Rear Differential Oil Temperature Warning Light System	156
56.	Harness Components Location	157
57.	Front Wiring Harness	158
58.	Bulkhead Wiring Harness (In Engine Compartment)	160
59.	Bulkhead Wiring Harness (In Compartment)	162
60.	Engine Wiring Harness and Transmission Cord	165
61.	Instrument Panel Wiring Harness	167
62.	Rear Wiring Harness	170
63.	Door Cord	176
64.	Rear Wiring Harness and Rear Gate Cord	178