

General Description



DRIVE SHAFT SYSTEM

1. General Description

A: SPECIFICATION

1. PROPELLER SHAFT

Propeller shaft type	EDJ	
Propeller shaft length: L	mm (in)	1,399 (55.08)
Front propeller shaft Joint-to-joint length: L ₁	mm (in)	645 (25.39)
Rear propeller shaft Joint-to-Joint length: L ₂	mm (in)	754 (29.69)
Outer diameter of tube: mm (in)	D ₁	63.5 (2.50)
	D ₂	57.5 (2.26)




DS-00350

General Description

DRIVE SHAFT SYSTEM

2. FRONT DRIVE SHAFT ASSEMBLY

Type of drive shaft	Axle diameter ϕ D mm (in)	Axle length L mm (in)
EBJ + PTJ	26 (1.0)	388.5 (15.30)




(A) Axle diameter

(B) Axle length

3. REAR DRIVE SHAFT ASSEMBLY

Type of drive shaft	Axle diameter ϕ D mm (in)	Axle length L mm (in)
EBJ + DOJ	24 (0.94)	386.8 (15.23)



(A) Axle diameter


(B) Axle length

General Description

DRIVE SHAFT SYSTEM

B: COMPONENT

1. PROPELLER SHAFT




DS-00353

(1) Propeller shaft
(2) Bushing

(3) Rear differential (VA2-type)

Tightening torque:N·m (kgf·m, ft·lb)
T1: 31 (3.2, 23.1)
T2: 52 (5.3, 38.3)

2. FRONT AXLE



- (1) Circlip
- (2) Baffle plate
- (3) Outer race (PTJ)
- (4) Snap ring
- (5) Trunnion
- (6) Snap ring

- (7) Boot band
- (8) Boot (PTJ)
- (9) Boot (EBJ)
- (10) EBJ shaft ASSY
- (11) Front housing
- (12) Hub bolt

- (13) Front hub unit bearing
- (14) Axle nut

Tightening torque:N·m (kgf·m, ft·lb)


T1: 240 (24.5, 177)

T2: 65 (6.6, 47.9)

General Description

DRIVE SHAFT SYSTEM

3. REAR AXLE



(1)	Baffle plate (DOJ)	(8)	Boot band	(15)	Axle nut (olive color)
(2)	Outer race (DOJ)	(9)	Boot (DOJ)		
(3)	Snap ring	(10)	EBJ shaft ASSY		Tightening torque:N·m (kgf·cm)
(4)	Inner race	(11)	Rear housing		T1: 65 (6.6, 47.9)
(5)	Ball	(12)	Back plate		T2: 75 (7.6, 55.3)
(6)	Cage	(13)	Rear hub unit bearing		T3: 240 (24.5, 177)
(7)	Snap ring	(14)	Hub bolt		

Tightening torque:N·m (kgf·m, ft-lb)

T1: 65 (6.6, 47.9)

T2: 75 (7.6, 55.3)

T3: 240 (24.5, 177)

C: CAUTION

Please clearly understand and adhere to the following general precautions. They must be strictly followed to avoid any injury to the person doing the work or people in the area.

1. OPERATION

- Wear appropriate work clothing, including a cap, protective goggles and protective shoes when performing any work.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Use SUBARU genuine grease etc. or equivalent. Do not mix grease etc. of different grades or manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Apply grease onto sliding or revolving surfaces before installation.
- Before installing snap rings, apply sufficient amount of grease to avoid damage and deformation.
- Before securing a part on a vise, place cushioning material such as wood blocks, aluminum plate, or shop cloth between the part and the vise.

2. OIL

When handling oil, follow the rules below to prevent unexpected accidents.

- Prepare container and waste cloths when performing work which oil could possibly spill. If oil spills, wipe it off immediately to prevent from penetrating into floor or flowing outside, for environmental protection.
- Follow all government and local regulations concerning waste disposal.

General Description

DRIVE SHAFT SYSTEM





D: PREPARATION TOOL

1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST-925091000	925091000	BAND TIGHTENING TOOL	Used for tightening the boot band. (A) Jig for the band (B) Ratchet wrench
 ST-926470000	926470000	AXLE SHAFT PULLER	Used for removing the axle shaft.
 ST18675AA000	18675AA000	DIFFERENTIAL SIDE OIL SEAL INSTALLER	Used for installing the differential side retainer oil seal.
 ST28099PA080	28099PA080	HUB STAND	Used for assembling hub bolt in hub.

General Description

DRIVE SHAFT SYSTEM

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST28099PA110	28099PA110	AXLE SHAFT PULLER PLATE	Same as plate 2 included in AXLE SHAFT PULLER (926470000).
 ST28099PA090	28099PA090	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> Used for installing the rear drive shaft to the rear differential. For protecting the oil seal.
 ST28399SA010	28399SA010	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> Used for installing front drive shaft into front differential. For protecting the oil seal.
 ST28399AG000	28399AG000 (Newly adopted tool)	HUB STAND	Used for extracting hub bolt.

2. GENERAL TOOL

DESCRIPTION	REMARKS
Puller	Used for removing the ball joint from knuckle arm.
Dial gauge	Used for inspecting the propeller shaft run-out.
Extension cap	Used for preventing leakage of gear oil or ATF.
Bar	Used for extracting drive shaft.