

## 10. Rear Magnetic Encoder

### A: REMOVAL

Refer to "Rear Hub Unit Bearing" for removal, because the rear magnetic encoder is integrated with rear hub unit bearing.

<Ref. to DS-21, REMOVAL, Rear Hub Unit Bearing.>

### B: INSTALLATION

Refer to "Rear Hub Unit Bearing" for installation, because the rear magnetic encoder is integrated with rear hub unit bearing.

<Ref. to DS-22, INSTALLATION, Rear Hub Unit Bearing.>

### C: INSPECTION

Visually check the magnetic encoder parts for any damage. If necessary, replace with a new hub unit bearing.

#### NOTE:

Because the magnetic encoder is integrated with hub unit bearing assembly, replace the hub unit bearing with a new part if there is any defect found on the magnetic encoder.