

6. Fuel Level Sensor

A: REMOVAL

For removal procedure, refer to “FU (H6DO)” section. <Ref. to FU(H6DO)-47, REMOVAL, Fuel Level Sensor.>

B: INSTALLATION

For installation procedure, refer to “FU (H6DO)” section. <Ref. to FU(H6DO)-47, INSTALLATION, Fuel Level Sensor.>