


4. Rear Axle

A: REMOVAL

- 1) Disconnect the ground cable from the battery.
- 2) Lift up the vehicle, and then remove the rear wheels.
- 3) Lift the crimped section of axle nut.




DS-00038

- 4) Remove the axle nut using a socket wrench while depressing the brake pedal.

CAUTION:


Remove the wheel before loosening the axle nut. Failure to follow this rule may damage the wheel bearings.

- 5) Remove the parking brake cable from parking brake assembly. <Ref. to PB-7, REMOVAL, Parking Brake Assembly (Rear Disc Brake).>
- 6) Remove the rear ABS wheel speed sensor.



DS-00363


- 7) Remove the snap pin and nut from the front lateral link.



DS-00189


- (1) Snap pin
(2) Nut

- 8) Using a puller, separate the rear housing and ball joint.



RS-00190

- 9) Detach the upper arm, trailing link, and rear lateral link from the rear housing.




DS-00364

- 10) Remove the rear axle.

NOTE:

If it is hard to remove, use the ST.

ST1 926470000 AXLE SHAFT PULLER
ST2 28099PA110 AXLE SHAFT PULLER PLATE



DS-00361

B: INSTALLATION

NOTE:

- Be sure to use a new self-locking nut.
 - Always tighten the stabilizer bushing in the state where the vehicle is at curb weight and the wheels are in full contact with the ground.
- 1) Install in the reverse order of removal.

Tightening torque:

Refer to "COMPONENT" of "General Description" for the tightening torque.

<Ref. to DS-4, COMPONENT, General Description. >

<Ref. to BR-4, COMPONENT, General Description. >

<Ref. to PB-2, COMPONENT, General Description. >


<Ref. to RS-3, COMPONENT, General Description. >

<Ref. to VDC-3, COMPONENT, General Description. >

- 2) Inspect the wheel alignment and adjust if necessary.

C: DISASSEMBLY


- 1) Remove the four bolts from the rear housing, and remove the rear hub unit bearing.



DS-00365

CAUTION:

- Be careful not to damage the magnetic encoder.
- Do not get closer the tool which charged magnetism to magnetic encoder.




DS-00251

(1) Magnetic encoder

(2) Rear hub unit bearing

- 2) Remove the two bolts from the rear housing, and remove the back plate.



DS-00366

D: ASSEMBLY

Assemble in the reverse order of disassembly.

Tightening torque:

Rear hub unit bearing


65 N·m (6.6 kgf-m, 47.9 ft-lb)

Back plate

75 N·m (7.6 kgf-m, 55.3 ft-lb)

E: INSPECTION

- 1) Moving the rear tire up and down by hand, check there is no backlash in bearing, and check the wheel rotates smoothly.




DS-00061

- 2) Inspect the lean of axis direction using a dial gauge. Replace the bearing if the load range exceeds the limitation.

Service limit:

Maximum: 0.05 mm (0.0020 in)



DS-00062