


General Description

WHEEL AND TIRE SYSTEM

1. General Description

A: SPECIFICATION

1. WHEEL AND TIRE SIZE



(1) Offset

(2) P.C.D.

Specification	Tire size	Wheel size	Offset mm (in)	P.C.D. mm (in)	Tire inflation pressure kPa (kgf/cm ² , psi)	
					Front wheel	Rear wheel
Standard type	P255/55R18 104H	18 × 8JJ	55 (2.17)	114.3 (4.50)	230 (2.3, 33)	220 (2.2, 32)
“T-type” Tire	T165/80R17 104M	17 × 4T	40 (1.57)		—	420 (4.2, 60)

2. SERVICE DATA

Part	Axial runout	Radial runout
Aluminum wheel	1.0 mm (0.039 in)	

General Description

WHEEL AND TIRE SYSTEM

3. ADJUSTING PARTS

Wheel balancing	Standard:	Service limit
Dynamic unbalance	10 g (0.35 oz) or less	

Balance weight part number (Knock-on type weight for aluminum wheel)	Weight
23141GA462	5 g (0.18 oz)
23141GA472	10 g (0.35 oz)
23141GA482	15 g (0.53 oz)
23141GA492	20 g (0.71 oz)
23141GA502	25 g (0.88 oz)
23141GA512	30 g (1.06 oz)
23141GA522	35 g (1.23 oz)
23141GA532	40 g (1.41 oz)
23141GA542	45 g (1.59 oz)
23141GA552	50 g (1.76 oz)
23141GA562	55 g (1.94 oz)
23141GA572	60 g (2.12 oz)


Balance weight part number (Adhesive type weight for aluminum wheel)	Weight
28101AE00B	5 g (0.18 oz)
28101AE01B	7.5 g (0.26 oz)
28101AE02B	10 g (0.35 oz)
28101AE03B	12.5 g (0.44 oz)
28101AE04B	15 g (0.53 oz)
28101AE05B	17.5 g (0.62 oz)
28101AE06B	20 g (0.71 oz)
28101AE07B	22.5 g (0.79 oz)
28101AE08B	25 g (0.88 oz)
28101AE09B	27.5 g (0.97 oz)
28101AE10B	30 g (1.06 oz)
28101AE11B	32.5 g (1.15 oz)
28101AE12B	35 g (1.23 oz)
28101AE13B	37.5 g (1.32 oz)
28101AE14B	40 g (1.41 oz)
28101AE15B	42.5 g (1.50 oz)
28101AE16B	45 g (1.59 oz)
28101AE17B	47.5 g (1.68 oz)
28101AE18B	50 g (1.76 oz)
28101AE19B	52.5 g (1.85 oz)
28101AE20B	55 g (1.94 oz)
28101AE21B	57.5 g (2.03 oz)
28101AE22B	60 g (2.12 oz)
28101AE23B	62.5 g (2.20 oz)
28101AE24B	65 g (2.29 oz)
28101AE25B	67.5 g (2.38 oz)
28101AE26B	70 g (2.47 oz)
28101AE27B	72.5 g (2.56 oz)
28101AE28B	75 g (2.65 oz)
28101AE29B	77.5 g (2.73 oz)
28101AE30B	80 g (2.82 oz)
28101AE31B	82.5 g (2.91 oz)
28101AE32B	85 g (3.00 oz)
28101AE33B	87.5 g (3.09 oz)
28101AE34B	90 g (3.17 oz)
28101AE35B	92.5 g (3.26 oz)
28101AE36B	95 g (3.35 oz)
28101AE37B	97.5 g (3.44 oz)
28101AE38B	100 g (3.53 oz)
28101AG50B	102.5 g (3.62 oz)
28101AG51B	105 g (3.70 oz)
28101AG52B	107.5 g (3.79 oz)
28101AG53B	110 g (3.88 oz)
28101AG54B	112.5 g (3.97 oz)
28101AG55B	115 g (4.06 oz)
28101AG56B	117.5 g (4.14 oz)
28101AG57B	120 g (4.23 oz)

General Description

WHEEL AND TIRE SYSTEM

B: COMPONENT

1. TIRE PRESSURE MONITORING SYSTEM



- (1) Transmitter
- (2) Grommet
- (3) Nut


- (4) Cap
- (5) Tire pressure monitoring control module

Tightening torque: N·m (kgf-m, ft-lb)

T1: 7.5 (0.76, 5.53)

T2: 8 (0.8, 5.8)

2. SPARE TIRE HOIST



(1) Spare tire guide

(2) Spare tire hoist

Tightening torque: N·m (kgf-m, ft-lb)

T1: 33 (3.7, 24.3)

C: PREPARATION TOOL

1. GENERAL TOOL

TOOL NAME	REMARKS
Air pressure gauge	Used for measuring tire air pressure.
Dial gauge with magnet stand	Used for measuring wheel runout.
Wheel balancer	Used for adjusting wheel balance.

2. Tire


A: INSPECTION

1) Take stones, glass, nails etc. out of the tread groove.

2) Replace tires in the following cases.


CAUTION:

- When replacing a tire, make sure to use only tires of the same size, construction and load range as originally installed.
- Use a tire changer when removing the tire from the wheel.
- On models equipped with tire pressure monitoring systems, do not use the bead breaker in a 90° area centered on the transmitter to prevent damaging the transmitter.




- (1) Transmitter
- (2) 90° (use of a bead breaker is prohibited in this area.)

- To prevent damaging the transmitter, set the tire changer boom in the position as shown in the figure.



- (1) Transmitter
- (2) Direction of turn table rotation
- (3) 90°
- (4) Tire changer boom

(2) When the “tread wear indicator” appears as a solid band across the tread.



- (1) Tread wear indicator
- (2) Tire tread

3) When a crack on tire valve is found, replace the tire valve.

(1) If large cracks on side wall, damage or cracks on the tread is found.