


Canister

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)


5. Canister

A: REMOVAL


- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from battery.
- 3) Lift up the vehicle.
- 4) Remove the clip holding the harness.



- 5) Remove the rear suspension assembly. <Ref. to RS-18, REMOVAL, Rear Sub Frame.>
- 6) Disconnect the evaporation hose (A) and connector (B).



- 7) Remove the canister from body.




B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

8 N·m (0.8 kgf·m, 5.9 ft-lb)



C: INSPECTION

Make sure the canister and canister hoses are not cracked or loose.