

16. Cam Sprocket

A: REMOVAL


NOTE:

When replacing the single part, perform the work with the engine installed to body.


- 1) Remove the V-belts. <Ref. to ME(H6DO)-46, REMOVAL, V-belt.>
- 2) Remove the crank pulley. <Ref. to ME(H6DO)-47, REMOVAL, Crank Pulley.>
- 3) Remove the chain cover. <Ref. to ME(H6DO)-48, REMOVAL, Chain Cover.>
- 4) Remove the timing chain assembly. <Ref. to ME(H6DO)-54, REMOVAL, Timing Chain Assembly.>
- 5) Remove the cam sprocket. To lock the camshaft, use the ST.

ST 499977500 CAM SPROCKET WRENCH

- Intake side



- Exhaust side



B: INSTALLATION

- 1) Install the cam sprocket. To lock the camshaft, use the ST.

Tightening torque:

29.5 N·m (3.0 kgf-m, 21.8 ft-lb)


- 2) Further tighten the bolt.

Tightening angle:


45°±5°

ST 499977500 CAM SPROCKET WRENCH

- Intake side



- Exhaust side



- 3) Install the timing chain assembly. <Ref. to ME(H6DO)-60, INSTALLATION, Timing Chain Assembly.>
- 4) Install the chain cover. <Ref. to ME(H6DO)-49, INSTALLATION, Chain Cover.>
- 5) Install the crank pulley. <Ref. to ME(H6DO)-47, INSTALLATION, Crank Pulley.>
- 6) Install the V-belts. <Ref. to ME(H6DO)-46, INSTALLATION, V-belt.>

C: INSPECTION

- 1) Check the cam sprocket teeth for abnormal wear and scratches.
- 2) Make sure there is no free play between cam sprocket and key.