

10. Brake Fluid

A: INSPECTION

- 1) Check that the brake fluid level is between "MIN" and "MAX". If out of the specified range, refill or drain fluid. If the fluid level is close to "MIN", check the brake pad for wear and refill the fluid.
- 2) Check the fluid for discoloration. If the fluid color has changed excessively, drain the fluid and refill with new fluid.

B: REPLACEMENT

CAUTION:

- Do not let brake fluid come into contact with the painted surface of the vehicle body. Wash away with water immediately and wipe off if it is spilled by accident.
- Avoid mixing brake fluids of different brands to prevent fluid performance from degrading.
- Be careful not to allow dirt or dust to enter the reservoir tank.

NOTE:

- During the operation, keep the reservoir tank filled with brake fluid to eliminate entry of air.
- Operate the brake pedal slowly.
- For convenience and safety, two people should work together.
- The required amount of brake fluid is approximately 600 m ℥ (20 US fl oz, 21 Imp fl oz) for entire brake system.

- 1) Lift up the vehicle and set rigid racks at the specified locations, or keep the vehicle lifted.
- 2) Remove both the front and rear wheels.
- 3) Drain brake fluid from the reservoir tank.
- 4) Refill the reservoir tank with the recommended brake fluid.

Recommended brake fluid:

Refer to the specification. <Ref. to BR-2, SPECIFICATION, General Description.>

Perform the same procedure as for bleeding the brake line, until new brake fluid comes out from vinyl tube. <Ref. to BR-32, PROCEDURE, Air Bleeding.>