

9. General Diagnostic Table

A: INSPECTION

| Symptom or trouble | Possible cause | Remedy |
|---|---|---|
| 1. Oil leakage | (1) Worn, scratched, or incorrectly seated front or side oil seal. Scored, battered or excessively worn sliding surface of companion flange. (2) Clogged or damaged air breather. (3) Loose bolts on differential spindle or side retainer, or incorrectly fitted O-ring. (4) Loose rear cover attaching bolts or damaged gasket. (5) Loose oil filler or oil drain plug. (6) Wear, damage or incorrect fitting of spindle, side retainer or oil seal. | Repair or replace. Clean, repair or replace. Tighten the bolts to specified torque. Replace the O-ring. Tighten the bolts to specified torque. Replace gasket and apply liquid gasket. Retighten and apply liquid gasket. Repair or replace. |
| 2. Seizure NOTE: Seized or damaged parts should be replaced, and also other parts should be thoroughly checked for any defect and should be repaired or replaced as required. | (1) Insufficient backlash for hypoid gear. (2) Excessive preload for side, rear or front bearing. (3) Insufficient or improper oil used. | Readjust or replace. Readjust or replace. Add the recommended oil to the specified level. |
| 3. Damage NOTE: Damaged parts should be replaced, and also other parts should be thoroughly checked for any defect and should be repaired or replaced as required. | (1) Improper backlash for hypoid gear. (2) Insufficient or excessive preload for side, rear or front bearing. (3) Excessive backlash for differential gear. (4) Loose bolts and nuts such as hypoid driven gear bolt (5) Damage due to overloading. | Replace. Readjust or replace. Replace gear or thrust washer. Retighten. Replace. |
| 4. Noises when starting or shifting gears NOTE: Noises may be caused by differential assembly, universal joint, wheel bearing, etc. Find out what is actually making noise before disassembling. | (1) Excessive backlash for hypoid gear. (2) Excessive backlash for differential gear. (3) Insufficient preload for front or rear bearing. (4) Loose drive pinion nut. (5) Loose bolts and nuts such as the side retainer attaching bolt. | Readjust. Replace the differential case assembly. Readjust. Tighten to the specified torque. Tighten to the specified torque. |
| 5. Noises when cornering | (1) Damaged differential gear. (2) Excessive wear or damage of thrust washer. (3) Broken pinion mate shaft. (4) Seized or damaged side bearing. | Replace the differential case assembly. Replace the differential case assembly. Replace the differential case assembly. Replace. |

General Diagnostic Table

DIFFERENTIALS

| Symptom or trouble | Possible cause | Remedy |
|---|--|---|
| 6. Gear Noise | (1) Improper tooth contact of hypoid gear. | Readjust or replace hypoid gear set. |
| NOTE: Since noises from engine, muffler, transmission, propeller shaft, wheel bearings, tires, and body are sometimes mistaken for noises from differential assembly, be careful in checking them. Inspection methods to locate noises include coasting, accelerating, cruising, and jacking-up all four wheels. Perform these inspections according to the condition of trouble. When listening to noises, shift gears into four wheel drive and fourth speed position, trying to pick up only differential noise. | (2) Improper backlash of the hypoid gear. | Readjust. |
| | (3) Scored or chipped teeth of hypoid gear. | Replace hypoid gear set. |
| | (4) Seized hypoid gear. | Replace hypoid gear set. |
| | (5) Improper preload for front or rear bearings. | Readjust. |
| | (6) Seized, cut-away or chipped front or rear bearing. | Replace. |
| | (7) Seized, cut-away or chipped side bearing. | Replace. |
| | (8) Differential carrier is vibrating. | Replace the differential case assembly. |

TRANSFER CASE

TC

| | Page |
|--|-------------|
| 1. General Description | 2 |
| 2. Transfer Clutch | 3 |
| 3. Extension Case | 4 |
| 4. Oil Seal | 5 |
| 5. Center Differential Carrier | 6 |
| 6. Reduction Driven Gear | 7 |
| 7. Transfer Clutch Pressure Test | 8 |