

### 5. Steering Gearbox


#### A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from battery.
- 3) Lift up the vehicle, and remove the front wheels.
- 4) Remove the under cover. <Ref. to EI-18, REMOVAL, Front Under Cover.>
- 5) Remove the front exhaust pipe assembly. <Ref. to EX(H6DO)-4, REMOVAL, Front Exhaust Pipe.>

**WARNING:**


**Be careful not to burn yourself because the exhaust pipe is hot.**

- 6) After pulling off the cotter pin and removing the castle nut, use a puller to remove the tie-rod end from the knuckle arm.




(1) Castle nut  
(2) Tie-rod end  
(3) Knuckle arm

- 7) Remove the front crossmember support plate, jack-up plate and front stabilizer. <Ref. to FS-14, REMOVAL, Front Stabilizer.>




(1) Crossmember support plate  
(2) Jack-up plate

- 8) Remove the one pipe joint at the center of the gearbox, and connect the vinyl hose to the pipe and the joint. Discharge the fluid by turning the steering wheel fully clockwise and counterclockwise. Discharge the fluid similarly from other pipes.



(1) Pipe A  
(2) Pipe B

- 9) Remove the universal joint. <Ref. to PS-13, REMOVAL, Universal Joint.>
- 10) Disconnect the pipe C from pressure hose first, then disconnect pipe D from the return hose.




(1) Pipe C  
(2) Pipe D  
(3) Pressure hose  
(4) Return hose

# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

11) Remove the gear box bracket and clamp, and remove the gearbox.



(1) Bracket  
(2) Clamp


## B: INSTALLATION

1) Insert the gearbox into crossmember, being careful not to damage gearbox boot.

2) Attach the gearbox bracket and clamp.

### Tightening torque:

60 N·m (6.1 kgf·m, 44.3 ft-lb)




(1) Bracket  
(2) Clamp

3) Connect the pipe D to return hose first, and the pipe C to pressure hose second.

### Tightening torque:

15 N·m (1.5 kgf·m, 11.1 ft-lb)



(1) Pipe C  
(2) Pipe D  
(3) Pressure hose  
(4) Return hose

4) Install the universal joint. <Ref. to PS-13, INSTALLATION, Universal Joint.>

5) Connect the tie-rod end and knuckle arm, and tighten with castle nut.

### Castle nut tightening torque:

27 N·m (2.8 kgf·m, 19.9 ft-lb)


### CAUTION:

When connecting, do not hit the cap at the bottom of tie-rod end with hammer.

# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

6) After tightening the castle nut to the specified tightening torque, tighten it further within  $60^\circ$  until the cotter pin hole is aligned with slot in the nut. Fit the cotter pin into the nut, and then bend the pin to lock.



(A) Cotter pin  
(B) Castle nut  
(C) Tie-rod end

7) Install the front stabilizer. <Ref. to FS-14, INSTALLATION, Front Stabilizer.>  
8) Install the front crossmember support plate and jack-up plate.  
9) Install the front exhaust pipe assembly. <Ref. to EX(H6DO)-5, INSTALLATION, Front Exhaust Pipe.>  
10) Install the under cover. <Ref. to EI-18, INSTALLATION, Front Under Cover.>  
11) Install the front wheels.  
12) Tighten the wheel nuts to the specified torque.

### Tightening torque:

#### Chromed wheel

150 N·m (15.3 kgf-m, 110.6 ft-lb)

#### Other than above

120 N·m (12.2 kgf-m, 88.5 ft-lb)

13) Lower the vehicle.  
14) Remove the steering wheel. <Ref. to PS-12, REMOVAL, Steering Wheel.>  
15) Align the center position of the roll connector. <Ref. to AB-24, ADJUSTMENT, Roll Connector.>  
16) Install the steering wheel. <Ref. to PS-12, INSTALLATION, Steering Wheel.>  
17) Connect the ground cable to battery.  
18) Pour fluid into the oil tank, and bleed air. <Ref. to PS-47, Power Steering Fluid.>  
19) Check for fluid leaks.  
20) Check the fluid level in oil tank.


21) After adjusting toe-in and steering angle, tighten the lock nut on tie-rod end.

### Tightening torque:

85 N·m (8.7 kgf-m, 62.7 ft-lb)

#### NOTE:

When adjusting toe-in, hold the boot as shown to prevent it from being rotated or twisted. If it becomes twisted, straighten it.



PS-00051

## C: DISASSEMBLY

### 1. RACK HOUSING ASSEMBLY

1) Disconnect the four pipes from gearbox.

#### NOTE:

Remove the pipes C and D, which are fixed to clamp plate, as a unit.


2) Secure the gearbox removed from vehicle in a vise using ST.

ST1 926200000 STAND

ST2 34199AG000 BOSS D

#### CAUTION:

Secure the gearbox in a vise using ST as shown in the figure. Do not secure the gearbox without this ST.




(1) Clamp

3) Remove the tie-rod end and lock nut from gearbox.

# Steering Gearbox


## POWER ASSISTED SYSTEM (POWER STEERING)

4) Remove the small clip from the boot using pliers, and then move the boot to tie-rod end side.



(1) Clip

7) Tighten the adjusting screw until it can no longer be tightened.




(1) Adjusting screw

5) Using a flat tip screwdriver, remove the band from boot.

NOTE:


Replace the boot if there is damage, cracks or deterioration.



(1) Band

6) Using the ST, loosen the lock nut.

ST 926230000 SPANNER




(1) Lock nut


8) Remove the tie-rod.

9) Loosen the adjusting screw, and remove the spring and sleeve.

10) Remove the two bolts securing valve assembly.




11) Carefully draw out the input shaft and remove the valve assembly.



12) Using a drill, release the crimping of holder.

**CAUTION:**

**Make a hole of 2 mm (0.08 in) depth using a drill with 3 mm (0.12 in) diameter.**



PS-00516


13) Remove the holder.

14) Attach the ST on the pinion housing side of rack, and press out the rack with the outer side oil seal.

ST 34199XA030 INSTALLER & REMOVER 44

**NOTE:**

Block the pipe connection of steering body to prevent fluid from flowing out.




PS-00064

(1) Rack piston

(2) Outer side oil seal

15) Insert the ST from pinion housing side and remove the oil seal using a press.

ST 34199XA060 OIL SEAL REMOVER




PS-00138

(1) Press

(2) Oil seal

16) Using a press, remove the bushing of gearbox installation portion.



PS-00517

# Steering Gearbox


## POWER ASSISTED SYSTEM (POWER STEERING)

### 2. CONTROL VALVE

- 1) Disconnect the pipes A and B from gearbox.
- 2) Secure the gearbox removed from vehicle in a vise using ST.  
ST1 926200000 STAND  
ST2 34199AG000 BOSS D

#### CAUTION:


Secure the gearbox in a vise using ST as shown in the figure. Do not secure the gearbox without this ST.



(1) Clamp


- 3) Using the ST, loosen the lock nut.

ST 926230000 SPANNER



(1) Lock nut


- 4) Tighten the adjusting screw until it can no longer be tightened.



(1) Adjusting screw


- 5) Loosen the adjusting screw, and remove the spring and sleeve.

- 6) Remove the two bolts securing valve assembly.




PS-00116

- 7) Carefully draw out the input shaft and remove the valve assembly.



PS-00143


- 8) Put a vinyl tape around the spline portion, and slide the dust cover to remove.



PS-00144

(1) Dust cover

- 9) Using a press, remove the pinion and valve assembly from valve housing.



PS-00149

(1) Pinion and valve ASSY

(2) Valve housing


(3) Cloth

10) Using the ST and a press, remove the bushing and oil seal from the valve housing.

ST 34199AG090 INSTALLER & REMOVER

**CAUTION:**

- **Do not apply a force to the end surface of valve housing.**
- **Do not reuse the oil seal after removal.**




(1) Oil seal

(2) Bushing

11) Using a snap ring pliers, remove the snap ring, valve, oil seal and back-up washer.

**CAUTION:**

**Be careful not to scratch the pinion and valve assembly.**



(1) Snap ring

(2) Valve


(3) Oil seal

(4) Back-up ring

## D: ASSEMBLY


### 1. RACK HOUSING ASSEMBLY

1) Using a press, install the bushing to gearbox installation portion.



2) Insert the ST to rack.

ST 34199XA010 GUIDE 44



(1) Seal ring


(2) Rack

3) Install the seal ring to piston portion of rack.

4) Using the ST, form the seal ring properly.

ST1 34199XA020 FORMER PISTON 44

ST2 34199AG060 GUIDE G (26)



(1) Seal ring

(2) Rack

# Steering Gearbox


## POWER ASSISTED SYSTEM (POWER STEERING)

5) Using the ST B and ST C, attach the oil seal to ST A.

ST 34199FE040 INSTALLER A, B, C


### NOTE:

Face the oil seal in the direction as shown in the figure.




(A) Oil seal

6) Insert the ST A with oil seal assembled from the gear side of rack. Remove the oil seal from ST A near piston, and then remove the ST A from rack.



(A) Oil seal  
(B) Rack  
(C) Piston

7) Install the back-up washer from the gear side of rack.



(1) Oil seal  
(2) Back-up washer  
(3) Rack

8) Check the threaded end of holder and gearbox cylinder end for burrs, damage, etc. Correct if faulty.

9) Apply a coat of grease to the grooves in rack, sliding surface of sleeve and sealing surface of piston. Then insert the rack into steering body from cylinder side.

10) Attach the ST on gearbox cylinder.

ST 34199XA000 INSTALLER 44


11) Set the ST to the end of rack.

ST 34199XA030 INSTALLER & REMOVER 44

12) Using a press, press-fit until the groove of ST1 is aligned to the end surface of ST2.

ST1 34199XA030 INSTALLER & REMOVER 44

ST2 34199XA000 INSTALLER 44



(1) Groove


13) Remove the ST.

14) Insert the outer side oil seal into the rack using the same procedure as steps 5) and 6).

ST 34199FE040 INSTALLER A, B, C

15) Put the ST and pipe through the rack, and press-fit the outer side oil seal using a press.

ST 34199XA000 INSTALLER 44



(1) Pipe  
(2) Outer side oil seal


# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

16) Secure the gearbox in a vise using ST.

ST1 926200000 STAND

ST2 34199AG000 BOSS D



(1) Clamp

17) Tighten the holder.


**Tightening torque:**

**85 N·m (8.7 kgf·m, 62.7 ft-lb)**

18) Using the ST, crimp so that the diameter of punch hole is 2 — 2.5 mm (0.08 — 0.10 in) and is aligned to the position of 2 mm (0.08 in) from gearbox cylinder end surface.

ST1 34099FA060 PUNCH HOLDER

ST2 34199XA050 BASE




(A) Holder

(B) 2 mm (0.08 in)

19) Put a vinyl tape around the spline portion and apply genuine grease to the dust cover and install to valve assembly.

**CAUTION:**


**Be sure to install the dust cover to groove of shaft.**



(1) Dust cover


(2) Groove

20) Apply the genuine grease to the pinion gear and bearing of valve assembly.



PS-00165

21) Install a new gasket on valve assembly. Insert the valve assembly into place while facing the rack teeth toward pinion.



PS-00117

22) Tighten the bolts alternately to secure the valve assembly.

**Tightening torque:**

**20 N·m (2.0 kgf·m, 14.8 ft-lb)**

**CAUTION:**

**Be sure to alternately tighten the bolts.**

# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

23) Temporarily tighten the tie-rod to the rack end, and then operate the rack from lock to lock for two or three times to make it fit in.

### CAUTION:

**Operating the rack from lock to lock without installing tie-rods may damage the oil seal. Always install the left and right tie-rods.**


24) Apply liquid gasket to 1/3 or more of entire perimeter of adjusting screw thread.

### Liquid gasket:

#### THREE BOND 1141

25) Apply a coat of grease to the sliding surface of sleeve and seating surface of spring, and then insert the sleeve into steering body.

Charge the adjusting screw with grease, and then insert the spring into adjusting screw. Then install on the steering body.



PS-00167

- (1) Sleeve
- (2) Spring
- (3) Adjusting screw

26) Tighten the adjusting screw to the specified torque.

### Tightening torque:

#### 5.9 N·m (0.6 kgf-m, 4.4 ft-lb)

27) Tighten the adjusting screw to the specified torque, then loosen it 20°.

28) Remove the tie-rod.

29) Adjust the turning resistance of gearbox so that it is within specification using adjusting screw.  
<Ref. to PS-33, TURNING RESISTANCE OF GEARBOX, INSPECTION, Steering Gearbox.>

30) Apply liquid gasket to lock nut and install it into adjusting screw. While holding the adjusting screw with wrench, tighten the lock nut using ST.

### Liquid gasket:

#### THREE BOND 1141

ST 926230000 SPANNER

### Tightening torque (lock nut):

#### 25 N·m (2.5 kgf-m, 18.4 ft-lb)

### NOTE:


Hold the adjusting screw with a wrench to prevent it from turning while tightening lock nut.

31) Extend the rack approx. 40 mm (1.57 in) from steering body.

32) Install the tie-rod and new lock washer into rack.

### Tightening torque:

#### 128 N·m (13.1 kgf-m, 94.4 ft-lb)




- (1) Lock washer
- (2) Approx. 40 mm (1.57 in)

33) Bend the lock washer and crimp it.

### CAUTION:

**Be careful not to scratch the rack when crimping lock washer.**



- (1) Lock washer


34) Apply a coat of grease to the tie-rod groove, and then install the boot to the housing.

# Steering Gearbox


## POWER ASSISTED SYSTEM (POWER STEERING)

### NOTE:

Make sure that the boot is installed without unusual inflation or deflation.




35) Install a new boot band. Using band clamp pliers, crimp it so that the clearance of crimping portion becomes 2 mm (0.079 in) or less.



(A) Boot band  
(B) 2 mm (0.079 in) or less

36) Fix the boot end with small clip.




(1) Clip

37) After installing, check that the boot end is installed to the groove of the tie-rod.

38) If the tie-rod end has been removed, screw in lock nut and tie-rod end to the screwed portion of tie-rod, and tighten the lock nut temporarily in a position as shown in the figure.

**Installed tie-rod length L:**

**28 mm (1.1 in)**




39) Inspect the gearbox as follows:

“A” Holding the tie-rod end, repeat lock to lock several times as quickly as possible.

“B” Holding the tie-rod end, turn it slowly at a radius several times as large as possible.

Finally, make sure that the boot is installed in the specified position without inflating.



40) Remove the gearbox from ST.

ST1 926200000 STAND

ST2 34199AG000 BOSS D

41) Install the four pipes on gearbox.

(1) Connect the pipes A and B to the four pipe joints of gearbox.

### Tightening torque:

Refer to the component parts. <Ref. to PS-4, POWER ASSISTED SYSTEM, COMPONENT, General Description.>

(2) Connect the pipes C and D to gearbox.


# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

### Tightening torque:

Pipe C: 37 N·m (3.8 kgf-m, 27.3 ft-lb)

Pipe D: 29 N·m (3.0 kgf-m, 21.4 ft-lb)




(1) Pipe C

(2) Pipe D

6) Apply vinyl tape to the groove of pinion.

7) Install the back-up ring and oil seal to pinion, and then remove the vinyl tape.



(1) Oil seal

(2) Vinyl tape


(3) Back-up ring

## 2. CONTROL VALVE ASSEMBLY

### Specified steering grease:

**VALIANT GREASE M2 (Part No. 003608001)**


- 1) Clean all parts and tools before reassembling.
- 2) Apply a coat of specified power steering fluid to the inner wall of valve housing.



(1) Apply fluid.

- 3) Apply grease to the oil seal.
- 4) Verify the direction of oil seal.
- 5) Using the ST and a press, install the oil seal and the bushing in valve housing.

ST 34199AG090 INSTALLER & REMOVER




(1) Bushing

(2) Oil seal

8) Attach the ST to pinion, and install the seal ring.


ST 34199AG020 GUIDE



(1) Seal ring

9) Remove the ST GUIDE, and form the seal ring properly using ST FORMER.

ST 34199AG070 FORMER




(1) Seal ring

10) Put vinyl tape around pinion shaft spline to protect oil seal from damage.

# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)


11) Install the valve to pinion, and install the snap ring.



PS-00531

- (1) Snap ring
- (2) Valve

12) Attach the pinion and valve assembly into the valve housing.




PS-00532

- (1) Valve housing
- (2) Pinion and valve ASSY

13) Using the ST and a press, push the outer race of bearing and press-fit the pinion and valve assembly into housing.

ST 34199XA020 FORMER PISTON 44



PS-00880


- (1) Pinion and valve ASSY
- (2) Bearing
- (3) Housing

14) Apply the specified grease to dust cover.

15) Install the dust cover on valve assembly.

**CAUTION:**


**Be sure to install the dust cover to groove of shaft.**



PS-00534


- (1) Dust cover
- (2) Groove

16) Apply the genuine grease to the pinion gear and bearing of valve assembly.



PS-00165

17) Install new O-ring to valve assembly.




PS-00535

- (1) O-ring

# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

18) Insert the valve assembly into place while facing the rack teeth toward pinion.



19) Tighten the bolts alternately to secure the valve assembly.

### Tightening torque:

20 N·m (2.0 kgf-m, 14.8 ft-lb)

### CAUTION:

Be sure to alternately tighten the bolts.


20) Apply liquid gasket to more than 1/3 of entire perimeter of adjusting screw thread.

### Liquid gasket:

**THREE BOND 1141 (Part No. 004403006)**

21) Apply a coat of grease to the sliding surface of sleeve and seating surface of spring, and then insert the sleeve into steering body.

Charge the adjusting screw with grease, and then insert the spring into adjusting screw. Then install on the steering body.



- (1) Sleeve
- (2) Spring
- (3) Adjusting screw

22) Tighten the adjusting screw to the specified torque.

### Tightening torque:

5.9 N·m (0.6 kgf-m, 4.4 ft-lb)

23) Tighten the adjusting screw to the specified torque, then loosen it 20°.

24) Adjust the turning resistance of gearbox using adjusting screw so that it is within specification.  
<Ref. to PS-33, TURNING RESISTANCE OF GEARBOX, INSPECTION, Steering Gearbox.>

25) Apply liquid gasket to lock nut and install it into adjusting screw. While holding the adjusting screw with wrench, tighten the lock nut using ST.

### Liquid gasket:

**THREE BOND 1141 (Part No. 004403006)**

ST 926230000 SPANNER

### Tightening torque (lock nut):

25 N·m (2.5 kgf-m, 18.4 ft-lb)

### NOTE:

Hold the adjusting screw with a wrench to prevent it from turning while tightening lock nut.

26) Remove the gearbox from ST.

ST1 926200000 STAND

ST2 34199AG000 BOSS D

27) Install the four pipes on gearbox.

(1) Connect the pipes A and B to gearbox.

### Tightening torque:


Refer to the component parts. <Ref. to PS-4, POWER ASSISTED SYSTEM, COMPONENT, General Description.>

(2) Connect the pipes C and D to gearbox.

### Tightening torque:

Pipe C: 37 N·m (3.8 kgf-m, 27.3 ft-lb)

Pipe D: 29 N·m (3.0 kgf-m, 21.4 ft-lb)



- (1) Pipe C
- (2) Pipe D

### E: INSPECTION

#### 1. BASIC INSPECTION

- 1) Clean all the disassembled parts, and check for wear, damage or any other faults, then repair or replace as necessary.
- 2) When disassembling, check the inside of gearbox for water. If any water is found, carefully check the boot for damage, input shaft dust seal, adjusting screw and boot clips for poor sealing. If faulty, replace with new parts.

| No. | Parts                  | Inspection   | Corrective action  |
|-----|------------------------|--|--|
| 1   | Input shaft            | (1) Bent input shaft<br>(2) Damage on serration  | If the bend or damage is excessive, replace the entire gearbox.  |
| 2   | Dust seal              | (1) Crack or damage<br>(2) Wear  | If the outer wall slips, the lip is worn out or damage is found, replace it with a new part.   |
| 3   | Rack and pinion        | Poor mating of rack with pinion  | (1) Adjust the backlash properly.<br>By measuring the turning torque of the gearbox and sliding resistance of rack, check if the rack and pinion engage uniformly and smoothly with each other. (Refer to "Service limit".)<br>(2) Pull out the entire rack to allow viewing of the teeth, and check for damage.<br>Even if abnormality is found in either (1) or (2), replace the entire gearbox. |
| 4   | Gearbox unit           | (1) Bending of the rack shaft<br>(2) Bending of the cylinder portion<br>(3) Crack or damage on the cast iron portion | Replace the gearbox with a new part.   |
|     |                        | (4) Wear or damage on rack bushing   | If the free play of rack shaft in radial direction is out of the specified range, replace the gearbox with new part.<br>(Refer to "Service limit".)  |
|     |                        | (5) Wear on input shaft bearing  | If the free play of input shaft in radial and axial direction is out of the specified range, replace the gearbox with a new part. (Refer to "Service limit".)  |
| 5   | Boot                   | Crack, damage or deterioration   | Replace.   |
| 6   | Tie-rod                | (1) Looseness of ball joint<br>(2) Bend of tie-rod   | Replace.   |
| 7   | Tie-rod end            | Damage or deterioration of dust seal   | Replace.   |
| 8   | Adjusting screw spring | Deterioration  | Replace.   |
| 9   | Boot clip              | Deterioration  | Replace.   |
| 10  | Sleeve                 | Damage   | Replace.   |
| 11  | Pipe                   | (1) Damage to flared surface<br>(2) Damage to flare nut<br>(3) Damage to pipe  | Replace.   |

# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

### 2. LIMIT

Make a measurements as follows. If it exceeds the specified service limits, adjust or replace.

#### NOTE:

When making a measurement, vise the gearbox using ST. Never vise the gearbox by inserting aluminum plates etc. between vise and gearbox.



ST1 926200000 STAND

ST2 34199AG000 BOSS D

#### Sliding resistance of rack shaft:

##### Limit

**400 N (41 kgf, 90 lb) or less**



### 3. RACK SHAFT PLAY IN THE RADIAL DIRECTION

#### Right-turn steering:


##### Limit

**0.19 mm (0.0075 in) or less**

##### Condition

**L: 5 mm (0.20 in)**

**P: 122.6 N (12.5 kgf, 27.6 lb)**



#### Left-turn steering:


##### Limit

**Direction  $\leftrightarrow$**

**0.6 mm (0.024 in) or less**

**Direction  $\leftrightarrow$**

**0.4 mm (0.016 in) or less**



### 4. INPUT SHAFT PLAY


#### In radial direction:

##### Limit

**0.18 mm (0.0071 in) or less**

##### Condition

**P: 98 N (10 kgf, 22 lb)**




#### In axial direction:

##### Service limit

**0.5 mm (0.0197 in) or less**

##### Condition

**P: 20 — 49 N (2 — 5 kgf, 4 — 11 lb)**



### 5. TURNING RESISTANCE OF GEARBOX

Using the ST, measure the gearbox turning resistance.

ST 34099PA100 SPANNER


#### **Service limit:**

**Maximum allowable resistance:**


**10.5 N (1.1 kgf, 2.4 lb) or less**

**Difference between right and left turning resistance:**

**20% or less**



### 6. OIL LEAKAGE



(1) Power cylinder

(2) Cylinder

(3) Rack piston

(4) Rack axle

(5) Input shaft

(6) Valve housing

# Steering Gearbox

## POWER ASSISTED SYSTEM (POWER STEERING)

- 1) Lift up the vehicle.
- 2) If a fluid leak is found, clean the fluid completely from the suspect area, and turn the steering wheel approx. 30 to 40 times to the left and right from lock to lock, with the engine running, and check again for leaks immediately, and also after a few hours have passed.
- 3) Cause and solution for oil leakage from "a"  
The oil seal is damaged. Replace the valve assembly with a new part.
- 4) Cause and solution for oil leakage from "b".  
The torsion bar O-ring is damaged. Replace the valve assembly with a new part.
- 5) Cause and solution for oil leakage from "c".  
The oil seal is damaged. Replace the valve assembly or oil seal with a new part.
- 6) Cause and solution for oil leakage from "d".  
The pipe is damaged. Replace the faulty pipe or O-ring.
- 7) Cause and solution for oil leakage from "g".  
The hose is damaged. Replace the hose with a new part.
- 8) If leak is other than a, b, c, d or g, or if oil is leaking from gearbox, move the right and left boots toward tie-rod end side, respectively, with the gearbox mounted to the vehicle, and remove fluid from surrounding portions. Then, turn the steering wheel from lock to lock about 30 to 40 times with the engine running, and make comparison of the leaked portion immediately after and several hours after this operation.

### (1) Leakage from "e"

The cylinder seal is damaged. Replace the rack bushing with a new part.

### (2) Leakage from "f"

There are two possible causes. Perform the following step first. Remove the pipe assembly B from the valve housing, and close the circuit using ST.

### ST 926420000 PLUG

Turn the steering wheel from lock to lock approx. 30 to 40 times with the engine running, then inspect the leaked portion immediately after and several hours after this operation.

#### • If leakage from "f" is noted again:

The oil seal of pinion and valve assembly is damaged. Replace the pinion and valve assembly with a new part. Or replace the oil seal and the parts that are damaged during disassembly with new parts.

#### • If oil stops leaking from "f":

The oil seal of rack housing is damaged. Replace the oil seal and parts that are damaged during disassembly with new parts.


## F: ADJUSTMENT

- 1) Adjust the front toe.

<Ref. to FS-10, FRONT WHEEL TOE-IN, INSPECTION, Wheel Alignment.>

### Standard of front toe:

**IN 3 — OUT 3 mm (IN 0.12 — OUT 0.12 in)**




(1) Lock nut

- 2) Adjust the steering angle of the wheels.

### Specification of steering angle:

|             |            |
|-------------|------------|
| Inner wheel | 37.0°±1.5° |
| Outer wheel | 32.0°±1.5° |

- 3) If the steering wheel spokes are not horizontal when wheels are set in the straight ahead position, or error is more than 5° on the periphery of the steering wheel, correctly re-install the steering wheel.



(1) Within 5°

- 4) If the steering wheel spokes are not horizontal with vehicle set in the straight ahead position after this adjustment, correct it by turning the right and left tie-rods in the opposite direction from each other by the same angle.