

22. Intake and Exhaust Valve

A: SPECIFICATION

Refer to "Cylinder Head" for removal and installation procedures of intake and exhaust valves. <Ref. to ME(H6DO)-77, REMOVAL, Cylinder Head.>
<Ref. to ME(H6DO)-78, INSTALLATION, Cylinder Head.>