

General Diagnostic Table

LAN SYSTEM (DIAGNOSTICS)

13.General Diagnostic Table

A: INSPECTION

Item	Operation	Specifications		Index
		YES	NO	
Diagnostic code	DTC is not displayed when inspecting all DTCs.	System is normal.	Perform the diagnosis according to DTC.	—
Engine coolant temperature	Engine coolant temperature gauge displays correctly without engine coolant temperature warning light illuminating/blink-ing.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Engine cooling system • LAN system 	Check the current data display of ECM, TCM and body integrated unit, and if three data values differ, it is possible that the driving system CAN is malfunctioning.
Remaining fuel level	Fuel gauge displays correctly without low fuel warning light remaining illuminated.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Combination meter system • LAN system 	Display the current data of body integrated unit, and if the values of "Fuel level resistance" and "Fuel level resistance 2" differ, it is possible that the body integrated unit is malfunctioning.
Ambient air temperature	Ambient air temperature is displayed correctly.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • HVAC system • LAN system 	—
Rear window defogger	Rear window defogger operates by operating the switch. Indicator in the switch illuminates when rear window defogger is operating.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Rear window defogger • HVAC system 	—
Wiper deicer	Wiper deicer operates by operating the switch.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Wiper deicer system • HVAC system 	Operates only when the customization of the body integrated unit "wiperdeicer" is set to "ON".
Rear wiper	Rear wiper operates normally by operating the switch.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Wiper and washer system 	—
Key interlock	Key cannot be removed in other than the parking range. Key can be removed in the parking range.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Shift lock control system • LAN system 	—
Shift Lock	Shift operation is normal.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Shift lock control system • Combination meter system • LAN system 	—
Seat belt warning system	Indicator in the meter illuminate when driver's seat belt is not worn. Alarm sounds when vehicle speed is approx. 15 km/h (9.4 MPH) without seat belt fastened. Indicator in the center display illuminates when passenger's seat is occupied and the passenger's seat belt is not fastened. Alarm sounds when vehicle speed is approx. 15 km/h (9.4 MPH) without seat belt fastened.	System is normal.	Refer to the following to check. <ul style="list-style-type: none"> • Seat belt warning system • Combination meter system • LAN system 	—

General Diagnostic Table

LAN SYSTEM (DIAGNOSTICS)

Item	Operation	Specifications		Index
		YES	NO	
Door lock	Lock/unlock operates by operating the central door lock switch. Rear gate opens by operating the rear gate release switch.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Security and locks• LAN system	—
Keyless Entry	Lock/unlock operates by operating the keyless transmitter. Rear gate unlocks by operating the rear gate unlock button.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Security and locks• LAN system	—
Answer back	Answer back operates by operating lock/unlock with the keyless entry.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Security and locks• LAN system	—
Room light	Turns ON/OFF according to the door open/close operation, the lock/unlock operation with the keyless entry, and the ignition operation.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Room light system• Security and locks• LAN system	—
Map light	Turns ON/OFF according to the door open/close operation, the lock/unlock operation with the keyless entry, and the ignition operation.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Spot map light• Security and locks• LAN system	—
Luggage light	Turns ON/OFF according to the door open/close operation, the lock/unlock operation with the keyless entry, and the ignition operation.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Luggage light• Security and locks• LAN system	—
Key illumination	Turns ON/OFF according to the driver's side door open/close and the ignition operation.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Ignition switch illumination• Security and locks• LAN system	Key illumination blinks when customization of the body integrated unit "Factory initial setting" is set to "Factory".
Illumination control	Illumination volume control is available.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Illumination control• Combination meter system• LAN system	—
Engine start	Engine starts normally.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Engine (diagnostics)• Immobilizer• LAN system	—
Vehicle security	When locked by the keyless entry, security monitor condition starts. When unlocked by the keyless entry, security is released.	System is normal.	Refer to the following to check. <ul style="list-style-type: none">• Security and locks• LAN system	—

WIRING SYSTEM SECTION**WIRING SYSTEM****WI**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

WIRING SYSTEM

WI

	Page
1. Basic Diagnostic Procedure	3
2. Working Precautions	14
3. Power Supply Circuit	15
4. Ground Circuit	22
5. Engine Electrical System	32
6. Vacuum Pump Control System	48
7. AT Control System	50
8. AT Shift Lock Control System	57
9. Vehicle Dynamics Control System	58
10. Tire Pressure Monitoring System	62
11. Air Conditioning System	63
12. Airbag System	68
13. Occupant Detection System	73
14. Immobilizer System	74
15. Cruise Control System	75
16. CAN Communication System	78
17. Radiator Fan System	80
18. Charging System	81
19. Starter System	82
20. Remote Engine Start System	83
21. Power Seat System	86
22. Seat Belt Warning System	89
23. Seat Heater System	90
24. Headlight System	91
25. Headlight Beam Leveler System	94
26. Front Fog Light System	95
27. Back-up Light System	96
28. Stop Light System	97
29. Clearance Light and Illumination Light System	98
30. Turn Signal Light and Hazard Light System	103
31. Interior Light System	105
32. Front Wiper and Washer System	111
33. Rear Wiper and Washer System	112
34. Wiper Deicer System	113
35. Washer Level Warning Light System	114
36. Audio System	115
37. Navigation System	127
38. Rearview Camera System	131
39. Multi-function Display (MFD) System	133
40. Rear Entertainment System	135
41. Front Accessory Power Supply Socket System	138
42. Rear Accessory Power Supply Socket System	139
43. Horn System	140
44. Power Window System	141
45. Rear Defogger System	145

46.	Remote Control Mirror System	146
47.	Combination Meter System	148
48.	Speedometer System	152
49.	Fuel Gauge System	153
50.	Coolant Temperature System	154
51.	Oil Pressure Warning Light System	155
52.	Parking Brake / Brake Fluid Level Warning Light System	156
53.	Sunroof Control System	157
54.	Keyless Entry System	158
55.	Security System	162
56.	Rear Differential Oil Temperature Warning Light System	165
57.	Rearview Mirror System	166
58.	Harness Components Location	168
59.	Front Wiring Harness	169
60.	Bulkhead Wiring Harness (In Engine Compartment)	171
61.	Bulkhead Wiring Harness (In Compartment)	173
62.	Engine Wiring Harness and Transmission Cord	176
63.	Instrument Panel Wiring Harness	178
64.	Rear Wiring Harness	181
65.	Door Cord	186
66.	Rear Wiring Harness and Rear Gate Cord	188