


11. Airbag Warning Light Illumination Pattern

A: INSPECTION

Turn the ignition switch to ON, and confirm that the airbag warning light remains on for approx. 6 seconds then go off afterwards.



(1) Airbag warning light

(2) Approx. 6 sec.

(3) Ignition switch ON