


32. Drive Pinion Shaft Assembly

A: REMOVAL

- 1) Remove the transmission assembly from the vehicle. <Ref. to 5AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter assembly. <Ref. to 5AT-60, REMOVAL, Torque Converter Assembly.>
- 3) Remove the transmission harness connector from stay.
- 4) Remove the ATF AT inlet and outlet pipes. <Ref. to 5AT-55, REMOVAL, ATF Cooler Pipe and Hose.>
- 5) Separate the converter case and transmission case. <Ref. to 5AT-74, REMOVAL, Converter Case.>
- 6) Remove the drive pinion shaft mounting bolts, and then remove the drive pinion shaft assembly from oil pump cover.



- 7) Remove the oil pump cover from AT main case. <Ref. to 5AT-76, Oil Pump Cover.>

B: INSTALLATION


- 1) Assemble the drive pinion assembly to oil pump cover.

NOTE:

Be careful not to bend the shim.

Tightening torque:

70 N·m (7.1 kgf·m, 51.6 ft-lb)



- 2) Adjust the tooth contact between drive pinion shaft assembly and the front differential side gear. <Ref. to 5AT-83, ADJUSTMENT, Drive Pinion Shaft Assembly.>
- 3) Join the converter case with the transmission case. <Ref. to 5AT-74, INSTALLATION, Converter Case.>
- 4) Install the transmission harness connector to the stay.
- 5) Install the ATF AT pipe. <Ref. to 5AT-56, INSTALLATION, ATF Cooler Pipe and Hose.>
- 6) Install the torque converter assembly. <Ref. to 5AT-60, INSTALLATION, Torque Converter Assembly.>
- 7) Install the transmission assembly to the vehicle. <Ref. to 5AT-39, INSTALLATION, Automatic Transmission Assembly.>


C: DISASSEMBLY

1) Flatten the lock nut tab, then remove the lock nut while holding the rear spline part of the shaft using ST1, ST2 and ST3. Pull out the drive pinion collar.

ST1 18667AA010 HOLDER

ST2 499787700 WRENCH


ST3 499787500 ADAPTER



AT-00197

2) Remove the O-ring.

3) Separate the rear roller bearing and outer race from shaft using a press.




AT-00198

(A) Outer race

4) Separate the front roller bearing from the shaft using a press and ST.

ST 498517000 REPLACER




AT-00199

(A) Front roller bearing

D: ASSEMBLY

1) Measure the dimension "A" of drive pinion shaft.
ST 398643600 GAUGE




AT-00200

2) Using a press, press-fit the new roller bearing into the specified position.

NOTE:

If excessive force is applied to roller bearing, the roller bearing will not turn easily.



AT-00201

(A) Drive pinion shaft

(B) Roller bearing

3) After fitting a new O-ring to the shaft, attach the drive pinion collar to the shaft.

Drive Pinion Shaft Assembly

AUTOMATIC TRANSMISSION

4) Tighten the new lock nuts using ST1, ST2 and ST3.

Calculate the tightening torque using following formula.

$$T2 = L2/(L1 + L2) \times T1$$

T1: 116 N·m (11.8 kgf-m, 85.6 ft-lb)

[Required torque setting]

T2: Tightening torque

L1: ST2 length 0.072 m (2.83 in)

L2: Torque wrench length

Example:

Torque wrench length m (in)	Tightening torque N·m (kgf-m, ft-lb)
0.4 (15.75)	98 (10.0, 72.3)
0.45 (17.72)	100 (10.2, 73.8)
0.5 (19.69)	101 (10.3, 74.5)
0.55 (21.65)	102 (10.4, 75.2)


ST1 18667AA010 HOLDER

ST2 499787700 WRENCH

ST3 499787500 ADAPTER

NOTE:

Attach ST2 to torque wrench as straight as possible.




AT-00202

5) Measure the starting torque of the bearing. Make sure the starting torque is within the specified range. If the torque is not within specified range, replace the roller bearing.

Starting torque:

7.6 — 38.1 N (0.775 — 3.88 kgf, 1.7 — 8.6 lbf)




AT-00203

6) Crimp the locknut in 2 locations.

7) Measure the dimension "B" of the drive pinion shaft.

ST 398643600 GAUGE



AT-00204

8) Calculate the thickness "t" mm (in) of the drive pinion shim.

$$t = 6.5 \pm 0.0625 (0.256 \pm 0.0025) - (B - A)$$

9) Select three or less shims from following table.

Drive pinion shim	
Part No.	Thickness mm (in)
31451AA180	0.150 (0.0059)
31451AA190	0.175 (0.0069)
31451AA200	0.200 (0.0079)
31451AA210	0.225 (0.0089)
31451AA220	0.250 (0.0098)
31451AA230	0.275 (0.0108)

E: INSPECTION

- Make sure that all component parts are free of scratches, holes and other faults.
- Adjust the tooth alignment. <Ref. to 5AT-83, ADJUSTMENT, Drive Pinion Shaft Assembly.>

F: ADJUSTMENT

- 1) Assemble the drive pinion shaft assembly to oil pump cover.
- 2) Remove the liquid gasket from the mating surface completely.
- 3) Install the converter case to oil pump cover, and secure them with tightening four bolts evenly.

NOTE:


Use an old gasket or aluminum washer to prevent damaging the mating surface of the housing.

Tightening torque:

41 N·m (4.2 kgf·m, 30.2 ft-lb)

- 4) Rotate the drive pinion a few times using ST1 and ST2.


ST1 18667AA010 HOLDER
ST2 499787700 WRENCH



- 5) Adjust the drive pinion and hypoid driven gear backlash. <Ref. to 5AT-88, ADJUSTMENT, Front Differential Assembly.>
- 6) Apply lead-free red dye evenly on the surface of three to four teeth of the hypoid driven gear. Rotate the drive pinion in the leftward and rightward for several times. Remove the oil pump cover, and check the tooth contact pattern. If the teeth contact is inappropriate, adjust the backlash or thickness of the shim. <Ref. to 5AT-88, ADJUSTMENT, Front Differential Assembly.>

- Correct tooth contact


Check item: Tooth contact surface is slightly shifted toward the toe side under a no-load condition. (When driving, it moves towards the heel side.)




(A) Toe side
(B) Heel side

- Face contact

Check item: Backlash is too large.
Contact pattern



Adjustment: Increase the thickness of the shim according to the procedures for moving the drive pinion closer to the driven gear.




Drive Pinion Shaft Assembly

AUTOMATIC TRANSMISSION

- Flank contact


Check item: Backlash is too small.

Contact pattern



AT-00209

Adjustment: Reduce the thickness of the shim according to the procedure for moving the drive pinion away from the driven gear.




AT-00213

- Toe contact (inside contact)


Check item: Teeth contact area is too small.

Contact pattern



AT-00210

Adjustment: Reduce the thickness of the shim according to the procedure for moving the drive pinion away from the driven gear.




AT-00213

- Heel contact (outside end contact)


Check item: Teeth contact area is too small.

Contact pattern



AT-00211

Adjustment: Increase the thickness of the shim according to the procedures for moving the drive pinion closer to the driven gear.




AT-00212

7) If tooth contact is correct, mark the retainer position and loosen it. After fitting a new O-ring and oil seal, screw in the retainer to the marked position. Install the lock plate, and tighten the bolts to the specified torque.

Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft-lb)



AT-01988

(A) Lock plate