

### 4. Seat Belt Warning System

#### A: WIRING DIAGRAM

<Ref. to WI-89, WIRING DIAGRAM, Seat Belt Warning System.>

#### B: INSPECTION

##### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait 60 seconds or more before starting to work.
- When replacing the airbag module, seat belt pretensioner, roll connector, control module and sensor, reconnect each part and check that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the airbag module connectors of the driver's and passenger's seats for safety.
- When inspecting the airbag rear harness, disconnect the side airbag module connector, curtain airbag module connector and seat belt pretensioner connector for safety reasons.

##### TROUBLE SYMPTOM:

- Driver's side seat belt warning light does not illuminate or it remains illuminating.
- Warning buzzer does not beep.

Step	Check	Yes	No
1 <b>CHECK CURRENT SETTINGS.</b> 1) Prepare the Subaru Select Monitor. 2) Turn the ignition switch to ON (engine OFF) and run the "PC application for Subaru Select Monitor". 3) Select the "current data display" and read the data of the "Belt Warning Switch".	Is the belt warning display ON?	Go to step 2.	Turn the belt warning ON with unit customization.
2 <b>CHECK CURRENT DATA.</b> 1) Select the "current data display" and read the data of the "IG power supply voltage". 2) Turn the ignition switch ON ↔ OFF.	Does the voltage change between 10 V or higher ↔ less than 1.5 V, matching the ignition switch ON ↔ OFF operation?	Go to step 3.	Check the ignition switch circuit.
3 <b>CHECK FUNCTION.</b> 1) Sit on the driver's seat and passenger's seat and disconnect the seat belts of the both. 2) Turn the ignition switch to ON (engine OFF). 3) Check the illumination of the driver's seat belt warning light in the combination meter, and the passenger's seat belt warning light in the warning light box RH, and the sounding of the buzzer.	Do the driver's warning light and passenger's warning light blink and the buzzer sound while blinking?	Go to step 4.	<ul style="list-style-type: none"> <li>• Malfunction of the driver's seat belt warning light → Go to step 10.</li> <li>• Malfunction of the passenger's seat belt warning light → Go to step 16.</li> <li>• The buzzer does not sound → Go to step 6.</li> </ul>
4 <b>CHECK FUNCTION.</b> 1) Wait until the buzzer stops sounding in step 3. (for approximately six seconds after starting sounding) 2) Connect and disconnect the seat belts of the driver's and passenger's. 3) Check the illumination of the driver's seat belt warning light in the combination meter, and the passenger's seat belt warning light in the warning light box RH, and the sounding of the buzzer.	Do the seat belts warning light illuminate ↔ go off according to the operation?	Go to step 5.	<ul style="list-style-type: none"> <li>• Malfunction of the driver's seat belt warning light → Go to step 6.</li> <li>• Malfunction of the passenger's seat belt warning light → Go to step 12.</li> </ul>

# Seat Belt Warning System

## SEAT BELT SYSTEM

Step	Check	Yes	No
5 <b>CHECK FUNCTION.</b> 1) Wait until the buzzer stops sounding in step 3. (for approximately six seconds after starting sounding) 2) Start the engine, and set the vehicle speed at 15 km/h (9 MPH) or more. 3) Check the seat belt warning lights of the driver's and the passenger's, and if the warning buzzer sounds.	Do the driver's warning light and passenger's warning light blink and the buzzer sound while blinking?	Seat belt warning system is normal.	Go to step 19.
6 <b>CHECK CURRENT DATA.</b> 1) Select the "current data display" and read the data of the seat belt switch of the driver's. 2) Connect and disconnect the seat belt buckle.	Does the seat belt SW display turn ON $\leftrightarrow$ OFF according to the operation?	Go to step 10.	Go to step 7.
7 <b>CHECK HARNESS.</b> 1) Disconnect the negative terminal from the battery, and wait for 60 seconds or more. 2) Disconnect the connector of body integrated unit and the seat belt buckle switch. 3) Check for short circuit to battery, open circuit and short circuit to ground between the body integrated unit and the seat belt buckle switch LH.  <i>Connector &amp; terminal (i84) No. 4 — (R8) No. 3:</i>	Is the harness normal?	Go to step 8.	Repair or replace the harness.
8 <b>CHECK HARNESS.</b> Measure the resistance between the seat belt buckle switch LH and chassis ground.  <i>Connector &amp; terminal (R8) No. 1 — Chassis ground:</i>	Is the resistance less than 10 $\Omega$ ?	Go to step 9.	Repair or replace the harness.
9 <b>CHECK SEAT BELT BUCKLE SWITCH LH.</b> Measure the resistance between the connector terminals of the driver's seat belt switch when the driver's seat belt is fastened and detached.  <i>Connector &amp; terminal (R8) No. 1 — (R8) No. 3:</i>	Is the resistance when the belt is fastened 1 M $\Omega$ or more, and less than 10 $\Omega$ when the belt is detached?	Replace the body integrated unit. <Ref. to SL-48, REMOVAL, Body Integrated Unit.>	Replace the inner belt assembly LH. <Ref. to SB-18, INNER SEAT BELT ASSEMBLY, REMOVAL, Front Seat Belt.>
10 <b>CHECK HARNESS.</b> 1) Disconnect the negative terminal from the battery, and wait for 60 seconds or more. 2) Disconnect the connector of the combination meter and the connector of the body integrated unit. 3) Check the harness between the combination meter and body integrated unit.  <i>Connector &amp; terminal (i84) No. 20 — (i11) No. 5:</i>	Is the resistance less than 10 $\Omega$ ?	Go to step 11.	Repair or replace the harness.
11 <b>CHECK COMBINATION METER.</b> 1) Install the connector of the combination meter and the connector of the body integrated unit. 2) Connect the battery. 3) Connect the harness between the combination meter and body integrated unit.  <i>Connector &amp; terminal (i11) No. 5 — Chassis ground: or (i84) No. 20 — Chassis ground:</i>	Does the driver's seat belt warning light turn on?	Replace the body integrated unit. <Ref. to SL-48, REMOVAL, Body Integrated Unit.>	Replace the combination meter. <Ref. to IDI-11, REMOVAL, Combination Meter.>

# Seat Belt Warning System

## SEAT BELT SYSTEM

Step	Check	Yes	No
12 <b>CHECK CURRENT DATA.</b> 1) Sit in the passenger's seat. 2) Select "Current Data Display" and display the data of "P seatbelt SW input". 3) Fasten and detach the passenger's side seat belt buckle, and read the data of the seat belt switch. <Ref. to LAN(diag)-29, OPERATION, Read Current Data.>	Does the seat belt switch display turn ON ↔ OFF according to the operation of the seat belt buckle?	Go to step 16.	Go to step 13.
13 <b>CHECK AIRBAG SYSTEM AND OCCUPANT DETECTION SYSTEM.</b> Perform the check in accordance with the diagnostic procedure DTC 27 of the airbag system. <Ref. to AB(diag)-52, DTC 27 ODS COMMUNICATION ERROR, Diagnostic Chart with Trouble Code.>	Is there any problem on the inspection result?	Go to step 14.	Repair or replace the harness.
14 <b>CHECK BUCKLE SWITCH RH.</b> Perform the check in accordance with the diagnostic procedure DTC 37 of the occupant detection system. <Ref. to OD(diag)-26, DTC 37 BUCKLE SWITCH RH FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any problem on the inspection result?	Go to step 15.	Repair or replace the harness.
15 <b>CHECK AIRBAG CONTROL MODULE AND BODY INTEGRATED UNIT.</b> Check the airbag control module, occupant detection sensor and seat belt buckle switch RH. Perform the check in accordance with the diagnostic procedure DTC 39 of the airbag system. <Ref. to AB(diag)-55, DTC 39 SEAT BELT WARNING FAILURE, Diagnostic Chart with Trouble Code.>	Is there any problem on the inspection result?	Replace the body integrated unit. <Ref. to SL-48, REMOVAL, Body Integrated Unit.>	Repair or replace the harness.
16 <b>CHECK HARNESS.</b> 1) Disconnect the warning light box RH connector. 2) Turn the ignition switch to ON. 3) Measure the voltage between body integrated unit and warning light box RH. <i>Connector &amp; terminal</i> <i>(i116) No. 3 (+) — Chassis ground (-):</i>	Is the voltage 10 V or more?	Go to step 17.	Repair or replace the harness.
17 <b>CHECK HARNESS.</b> 1) Turn the ignition switch to ON. 2) Disconnect the connector of body integrated unit. 3) Check for short circuit to battery, open circuit and short circuit to ground between the body integrated unit and the warning light box RH. <i>Connector &amp; terminal</i> <i>(B280) No. 27 — (i116) No. 9:</i>	Is the harness normal?	Go to step 19.	Repair or replace the harness.
18 <b>CHECK WARNING LIGHT BOX RH.</b> 1) Connect the warning light box RH connector. 2) Turn the ignition switch to ON. 3) Use an appropriate wiring harness to create a short between the body integrated unit and the warning box light RH. <i>Connector &amp; terminal</i> <i>(i116) No. 9 — Chassis ground:</i>	Does passenger's seat belt warning light in the warning light box RH illuminate?	Replace the body integrated unit. <Ref. to SL-48, REMOVAL, Body Integrated Unit.>	Replace the warning light box RH. <Ref. to IDI-17, REMOVAL, Warning Box.>

# Seat Belt Warning System

## SEAT BELT SYSTEM

Step	Check	Yes	No
<b>19 CHECK DTC.</b> Read the DTCs for all systems using the Subaru Select Monitor.	Is a DTC detected?	Perform a check according to the DTC.	Go to step <b>20</b> .
<b>20 CHECK CURRENT DATA.</b> Select "Current Data Display" and read the data of the "Front Wheel Speed". <Ref. to LAN(diag)-29, OPERATION, Read Current Data.>	Does the data display the wheel speed data correctly?	Go to step <b>11</b> .  Check the following items. <ul style="list-style-type: none"><li>• LAN system &lt;Ref. to LAN(diag)-62, DTC U1223 CAN-HS VDC/ABS NO-RECEIVE DATA, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</li><li>• Check VDC or ABS. VDC &lt;Ref. to VDC(diag)-2, Basic Diagnostic Procedure.&gt;</li></ul>	