


## 4. Engine Coolant Temperature Sensor

### A: REMOVAL

- 1) Remove the collector cover.
- 2) Disconnect the ground cable from battery.
- 3) Drain engine coolant. <Ref. to CO(H6DO)-12, DRAINING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>
- 4) Disconnect the connectors from the engine coolant temperature sensor.



- 5) Remove the engine coolant temperature sensor.

### B: INSTALLATION


Install in the reverse order of removal.

**NOTE:**

Use a new gasket.

**Tightening torque:**

**22 N·m (2.2 kgf·m, 16.2 ft-lb)**




### C: INSPECTION

- 1) Check that the engine coolant temperature sensor has no deformation, cracks or other damages.
- 2) Immerse the engine coolant temperature sensor and a thermometer in water.

**CAUTION:**

Take care not to allow water to get into the engine coolant temperature sensor connector. Completely remove any water inside.



(A) Thermometer

(B) Engine coolant temperature sensor

(C) Hexagonal part height: To approx.  $\frac{1}{3}$


## Engine Coolant Temperature Sensor

### FUEL INJECTION (FUEL SYSTEMS)

3) Raise water temperature gradually, measure the resistance between the engine coolant temperature sensor terminals when the temperature is 20°C (68°F) and 80°C (176°F).

**NOTE:**

Agitate the water for even temperature distribution.



Water temperature	Terminal No.	Standard
20°C (68°F)	1 and 2	$2.45 \pm 0.2 \text{ k}\Omega$
80°C (176°F)		$0.318 \pm 0.013 \text{ k}\Omega$