




ON-VEHICLE INSPECTION

1. CHECK BATTERY ELECTROLYTE LEVEL


Check the electrolyte quantity of each cell.

Maintenance-Free Battery:

If under the lower level, replace the battery (or add distilled water if possible) and check the charging system.

Except Maintenance-Free Battery:

If under the lower level, add distilled water.



2. Except Maintenance-Free Battery:


CHECK BATTERY SPECIFIC GRAVITY

Check the specific gravity of each cell.

Standard specific gravity:

1.25 - 1.29 at 20°C (68 °F)

If the specific gravity is less than specification, charge the battery.



3. CHECK BATTERY VOLTAGE

- After having driven the vehicle and in the case that 20 minutes have not passed after having stopped the engine, turn the ignition switch ON and turn on the electrical system (headlight, blower motor, rear defogger etc.) for 60 seconds to remove the surface charge.
- Turn the ignition switch OFF and turn off the electrical systems.
- Measure the battery voltage between the negative (-) and positive (+) terminals of the battery.


Standard voltage:

12.5 - 12.9 V at 20°C (68°F)

If the voltage is less than specification, charge the battery.


HINT:

Check the indicator as shown in illustration.



4. CHECK BATTERY TERMINALS, FUSIBLE LINK AND FUSES

- Check that the battery terminals are not loose or corroded.
- Check the fusible link, H-fuses and fuses for continuity.





5. INSPECT DRIVE BELT

- (a) Visually check the belt for excessive wear, frayed cords etc.

If any defect has been found, replace the drive belt.


HINT:

- Cracks on the rib side of a belt are considered acceptable. If the belt has chunks missing from the ribs, it should be replaced.
- The drive belt tension can be released by turning the belt tensioner clockwise.



- (b) Check the belt tensioner operation.
- Check that belt tensioner moves downward when the drive belt is pressed down at the points indicated in the illustration.
 - Check the alignment of the belt tensioner pulley to make sure the drive belt will not slip off the pulley.

If necessary, replace the belt tensioner.



HINT:

- After installing a belt, check that it fits properly in the ribbed grooves.
- Check with your hand to confirm that the belt has not slipped out of the groove on the bottom of the pulley.

6. VISUALLY CHECK GENERATOR WIRING AND LISTEN FOR ABNORMAL NOISES

- (a) Check that the wiring is in good condition.
- (b) Check that there is no abnormal noise from the generator while the engine is running.

7. INSPECT DISCHARGE WARNING LIGHT CIRCUIT

- (a) Turn the ignition switch "ON". Check that the discharge warning light comes on.
- (b) Start the engine. Check that the light goes off.

If the light does not operate as specified, troubleshoot the discharge warning light circuit.

8. INSPECT CHARGING CIRCUIT WITHOUT LOAD**HINT:**

If a battery/generator tester is available, connect the tester to the charging circuit as per manufacturer's instructions.

(a) If a tester is not available, connect a voltmeter to the charging circuit as follows:

- Disconnect the wire from terminal B of the generator and connect it to the negative (-) lead of the ammeter.
- Connect the positive (+) lead of the ammeter to terminal B of the generator.
- Connect the positive (+) lead of the voltmeter to terminal B of the generator.
- Ground the negative (-) lead of the voltmeter.

(b) Check the charging circuit as follows:

With the engine running from idle to 2,000 rpm, check the reading on the ammeter and voltmeter.

Standard amperage:



10A or less

Standard voltage:

13.2 – 14.8 V

If the voltmeter reading is more than standard voltage, replace the voltage regulator.

If the voltmeter reading is less than the standard voltage, check the voltage regulator and generator as follows:



- With terminal F grounded, start the engine and check the voltmeter reading of terminal B.
- If the voltmeter reading is more than standard voltage, replace the voltage regulator.
- If the voltmeter reading is less than standard voltage, check the generator.

9. INSPECT CHARGING CIRCUIT WITH LOAD

(a) With the engine running at 2,000 rpm, turn on the high beam headlights and place the heater blower switch at "H".

(b) Check the reading on the ammeter.

Standard amperage:

30 A or more

If the ammeter reading is less than standard amperage, repair the generator.

HINT:

If the battery is fully charged, the indication will sometimes be less than standard amperage.