

RADIATOR

ON-VEHICLE CLEANING

C004N-01

CLEAN RADIATOR

Using water or a steam cleaner, remove any mud or dirt from the radiator core.

NOTICE:

If using a high pressure type cleaner, be careful not to deform the fins of the radiator core (i.e. Maintain a distance between the cleaner nozzle and radiator core.).