





PRE-CHECK

1. DIAGNOSIS SYSTEM

(a) Description for Euro-OBD (European spec.)

- When troubleshooting Euro-OBD vehicles, the only difference from the usual troubleshooting procedure is that you connect to the vehicle the OBD scan tool complying with ISO 15031-4 or hand-held tester, and read off various data output from the vehicle's engine ECU.
- Euro-OBD regulations require that the vehicle's on-board computer lights up the check engine warning light on the instrument panel when the computer detects a malfunction in the emission control system / components or in the power train control components which affect vehicle emissions, or a malfunction in the computer. In addition to the check engine warning light lighting up when a malfunction is detected, the applicable Diagnostic Trouble Codes (DTC) prescribed by ISO 15031-4 are recorded in the engine ECU memory (See page DI-18). If the malfunction does not reoccur in 3 consecutive trips, the check engine warning light goes off automatically but the DTCs remain recorded in the engine ECU memory.



- To check the DTCs, connect the OBD scan tool or hand-held tester to Data Link Connector 3 (DLC3) on the vehicle. The OBD scan tool or hand-held tester also enables you to erase the DTCs and check freeze frame data and various forms of engine data. (For operating instructions, see the OBD scan tool's instruction book.)
DTCs include ISO controlled codes and manufacturer controlled codes. ISO controlled codes must be set as prescribed by the ISO, while manufacturer controlled codes can be set freely by the manufacturer within the prescribed limits. (See DTC chart on page DI-18)
- The diagnosis system operates in normal mode during normal vehicle use. It also has a check mode for technicians to simulate malfunction symptoms and troubleshoot. Most DTCs use 2 trip detection logic* to prevent erroneous detection, and ensure thorough malfunction detection. By switching the engine ECU to check mode when troubleshooting,

the technician can cause the check engine warning light to light up for a malfunction that is only detected once or momentarily. (hand-held tester only) (See step 2)

- *2 trip detection logic: When a malfunction is 1st detected, the malfunction is temporarily stored in the engine ECU memory. (1st trip) If the same malfunction is detected again during the second drive test, this 2nd detection causes the check engine warning light to light up. (2nd trip)
(However, the IG switch must be turned OFF between the 1st trip and the 2nd trip.)
- Freeze frame data:
Freeze frame data records the engine condition when a misfire (DTCs P0300/93 – P0304/93) or fuel trim malfunction (DTCs P0171/25) or other malfunction (first malfunction only), is detected.
Because freeze frame data records the engine conditions (fuel system, calculated load, engine coolant temperature, fuel trim, engine speed, vehicle speed, etc.) when the malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air-fuel ratio lean or rich, etc. at the time of the malfunction.
- Priorities for troubleshooting:
If troubleshooting priorities for multiple DTCs are given in the applicable DTC chart, these should be followed.


If no instructions are given troubleshoot DTCs according to the following priorities.

- (1) DTCs other than fuel trim malfunction (DTCs P0171/25) and misfire (DTCs P0300/93 – P0304/93).
 - (2) Fuel trim malfunction (DTCs P0171/25).
 - (3) Misfire (DTCs P0300/93 – P0304/93).
- (b) Description for M-OBD (Except European spec.)
- When troubleshooting Multiplex OBD (M-OBD) vehicles, the only difference from the usual troubleshooting procedure is that you connect the hand-held tester to the vehicle, and read off various data output from the vehicle's engine ECU.
 - The vehicle's on-board computer lights up the check engine warning light (CHK ENG) on the instrument panel when the computer detects a malfunction in the computer itself or in drive system components. In addition to the check engine warning light lighting up when a malfunction is detected, the applicable Diagnosis Trouble Code (DTC) are recorded in the engine ECU memory.

(See page DI-18)

If the malfunction has been repaired, the check engine warning light goes off automatically but the DTCs remain recorded in the engine ECU memory.

- To check the DTCs, connect the hand-held tester to Data Link Connector 3 (DLC3) on the vehicle. or read the number of blinks of the check engine warning light when TC and CG terminals on the DLC3 are connected. The hand-held tester also enables you to erase the DTCs and activate the several actuators and check freeze frame data and various forms of engine data (For operating instructions, see the hand-held tester instruction book.)
- The diagnosis system operates in normal mode during normal vehicle use. It also has a check (test) mode for technician to simulate malfunction symptoms and troubleshoot. Most DTCs use 2 trip detection logic to prevent erroneous detection and ensure thorough malfunction detection. By switching the engine ECU to check (test) mode using hand-held tester when troubleshooting, the technician can cause the check engine warning (CHK ENG) to light up for a malfunction that is only detected once or momentarily. (Hand-held tester only)
(See step 3.)
- * 2 trip detection logic
When a logic malfunction is first detected, the malfunction is temporally stored in the engine ECU memory. If the same malfunction is detected again during the second drive test, this second detection causes the check engine warning (CHK ENG) to light up.
The 2 trip repeats the same mode for 2 times. (However, the IG switch must be turned OFF between the 1st trip and 2nd trip)
- Freeze frame data:
Freeze frame data records the engine condition when malfunction is detected.
Because freeze frame data records the engine conditions (fuel system, calculator load, water temperature, fuel trim, engine speed, vehicle speed, etc.) when the malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air-fuel ratio lean or rich, etc. at the time of the malfunction.



(c) Check the DLC3.


The vehicle's engine ECU uses the ISO 9141-2(Euro-OBD) / ISO 14230(M-OBD) communication protocol. The terminal arrangement of DLC3 complies with ISO 15031-03 and matches the ISO 9141-2 / ISO 14230 format.

Terminal No.	Connection / Voltage or Resistance	Condition
7	Bus ⊕ Line / Pulse generation	During transmission
4	Chassis Ground / ↔ Body Ground 1 Ω or less	Always
16	Battery Positive / ↔ Body Ground 9 – 14 V	Always

HINT:

If your display shows "UNABLE TO CONNECT TO VEHICLE" when you have connected the cable of the OBD scan tool or hand-held tester to DLC3, turned the ignition switch ON and operated the hand-held tester, there is a problem on the vehicle side or tool side.

- If communication is normal when the tool is connected to another vehicle, inspect DLC3 on the original vehicle.
- If communication is still not possible is when the tool is connected to another vehicle, the problem is probably in the tool itself, so consult the Service Debarment listed in the tool,s instruction manual.

**2. INSPECT DIAGNOSIS (Normal Mode)**

(a) Check the check engine warning light.

- (1) The check engine warning (CHK ENG) comes on when the ignition switch is turned ON and the engine is not running.

HINT:

If the check engine warning (CHK ENG) does not light up, troubleshoot the combination meter.


- (2) When the engine is started, the check engine warning light should go off. If the lamp remains on, the diagnosis system has detected a malfunction or abnormality in the system

(b) Check the DTC, using hand-held tester.

NOTICE:

(Hand-held tester only): When the diagnosis system is switched from normal mode to check (test) mode, it erases all DTCs and freeze frame data recorded in normal mode. So before switching modes, always check the DTCs and freeze frame data, and note them down.


- (1) Prepare the hand-held tester.
- (2) Connect the hand-held tester to DLC3.
- (3) Turn the ignition switch ON and switch the hand-held tester main switch ON.
- (4) Use the hand-held tester to check the DTCs and freeze frame data; note them down. (For operating instructions, see the hand-held tester's instruction book.)
- (5) See page DI-18 to confirm the details of the DTCs.




(c) If you have no hand-held tester, perform the following step (1) to (6).

- (1) Turn the ignition switch ON.
- (2) Using SST, connect between terminals 13 (TC) and 4 (CG) of DLC3.

SST 09843 - 18040



(3) Read the DTC from the check engine warning light (CHK ENG).



- (4) As an example, the blinking patterns for codes, normal, 12 and 31 are as shown on the illustration.
- (5) Check the details of the malfunction using the DTC chart on page DI-18.
- (6) After completing the check, disconnect terminals 13 (TC) and 4 (CG) and turn off the display.

HINT:

In the event of 2 or more malfunction codes, indication will begin from the smaller numbered code and continue in order to the larger.

NOTICE:

- When simulating symptoms without a hand-held tester to check the DTCs, use normal mode. For codes on the DTCs, chart subject to "2 trip detection logic", turn the ignition switch OFF after the symptom is simulated the first time. Then repeat the simulation process again. When the problem has been simulated twice, the check engine warning light lights up and the DTCs, are recorded in the engine ECU
- Check the 1st trip DTC using Mode7 for ISO 15031 (Continuous Test Results of Euro-OBD function in hand-held tester).

3. INSPECT DIAGNOSIS (Check (Test) Mode)**HINT:**


Hand-held tester only:

Compared to the normal mode, the check mode has an increased sensitivity to detect malfunctions.

Furthermore, the same diagnostic items which are detected in the normal mode can also be detected in the check (test) mode.

(a) Check the DTC.**(1) Initial conditions**

- Battery positive voltage 11V or more.
- Throttle valve fully closed.
- Transmission in "P" or "N" position.
- Air conditioning switched OFF.

(2) Turn ignition switch OFF.**(3) Prepare the hand-held tester.****(4) Connect the hand-held tester to DLC3 on the at the lower left of the instrument panel.****(5) Turn the ignition switch ON and switch the push the hand-held tester ON.**

- (6)** Switch the hand-held tester normal mode to check (test) mode. (Check that the check engine warning light (CHK ENG) flashes.)
- (7)** Start the engine. (The check engine warning (CHK ENG) light goes out after the engine start.)
- (8)** Simulate the conditions of the malfunction described by the customer.

NOTICE:

Leave the ignition switch ON until you have checked the DTC, etc.

- (9) After simulating the malfunction conditions, use the hand-held tester diagnosis selector to check the DTCs and frozen frame data, etc.

HINT:


Take care not to turn the ignition switch OFF. Turning the ignition switch OFF switches the diagnosis system from check (test) mode to normal mode. so all DTCs, etc. are erased.

- (10) After checking the DTCs, inspect the applicable circuit.
- (b) Clear the DTC.
- The following actions will erase the DTCs and frozen frame data.

- Operating the hand-held tester to erase the codes. (See the hand-held tester's instruction book for operating instructions.)
- Disconnecting the battery terminals or EFI fuse.

NOTICE:

If the hand-held tester switches the engine ECU from normal mode to check mode or vice-versa, or if the ignition switch is turned from ON to ACC or OFF during check mode, the DTCs and frozen frame data will be erased.



- (c) Using break-out-box and hand-held tester
- (1) Hook up the break-out-box and hand-held tester to the vehicle.
 - (2) Read the engine ECU input/output values following the prompts on the tester screen.

HINT:

Hand-held tester has a "Snapshot" function. This records the measured values and is effective in the diagnosis of intermittent problems.

Please refer to the hand-held tester/break-out-box operator's manual for further details.

4. FAIL-SAFE CHART

If any of the following codes is recorded, the engine ECU enters fail-safe mode.

DTC No.	Fail-Safe Operation	Fail-Safe Deactivation Conditions
P0110/24	Intake air temp. is fixed at 20°C (68°F)	Returned to normal condition
P0115/22	Water temp. is fixed at 80° (176°F)	Returned to normal condition
P0120/41	VTA is fixed at 0°	The following condition must be repeated at least 2 times consecutively When closed throttle position switch is ON: $0.1\text{ V} \leq \text{VTA}$ and 0.95 V
P0325/52	Max. timing retardation	IG switch OFF
P0500/42	High RPM for cut is prohibited ISC control prohibited	Returned to normal condition
P1300/14 P1305/15 P1310/14 P1315/15	Fuel cut	Returned to normal condition

5. CHECK FOR INTERMITTENT PROBLEMS


HAND-HELD TESTER only:

By putting the vehicle's engine ECU in check (test) mode, 1 trip detection logic is possible instead of 2 trip detection logic and sensitivity to detect open circuits is increased. This makes it easier to detect intermittent problems.

- (1) Clear the DTC (See step 3.).
- (2) Set the check (test) mode (See step 3.).
- (3) Perform a simulation test (See page IN-10).
- (4) Check the connector and terminal (See page IN-20).
- (5) Check the visual check and contact pressure (See page IN-20).
- (6) Handle the connector (See page IN-20).

6. BASIC INSPECTION

When the malfunction code is not confirmed in the DTC check, troubleshooting should be carried out in the order for all possible circuits to be considered as the causes of the problems. In many cases, by carrying out the basic engine check shown in the following flow chart, the location causing the problem can be found quickly and efficiently. Therefore, use of this check is essential in engine troubleshooting.



2 Is engine cranked ?

NO

Proceed to problem table on [page DI-24](#).

YES


3 Does engine start ?

NO

Go to step 7.

YES

4 Check air filter.



PREPARATION:

Remove the air filter.

CHECK:

Visually check that the air filter is not excessively dirty or oily.

HINT:


If necessary, clean the filter with compressed air. First blow from inside thoroughly, then blow from outside of filter.

NG

Repair or replace.

OK

5 Check engine idle speed.



PREPARATION:

- Warm up engine to normal operating temperature.
 - Switch off all accessories.
 - Switch off air conditioning.
 - Shift transmission into the "N" position.
 - Connect the hand-held tester to DLC3 on the vehicle.
 - If you have no hand-held tester, connect tachometer test probe to terminal 9 (TAC) of DLC3.
- SST 09843-18030

NOTICE:

As some tachometer are not compatible with this ignition system, we recommend that you confirm the compatibility of your until before use.

CHECK:

Check the idle speed.

OK:

Idle speed:

1ZZ-FE: 650 – 750 rpm


2ZZ-GE (M/T): 750 – 850 rpm

2ZZ-GE (A/T): 700 – 800 rpm

NG

Proceed to problem symptoms table on [page DI-24](#).

OK

6 Check ignition timing.**PREPARATION:**

- Warm up engine to normal operating temperature.
- Switch off all accessories.
- Switch off air conditioning
- Shift transmission into the "N" or "P" position.
- Using SST, connect terminals 13 (TC) and 4 (CG) of DLC3.
SST 09843-18040
- Connect the timing light.

CHECK:

Check ignition timing.

OK:**Ignition timing:**

1ZZ-FE: 10 – 18° BTDC at idle

2ZZ-GE: 8 – 12° BTDC at idle


NG

Proceed to [page IG-1](#) and continue to trouble-shoot.

OK

Proceed to problem symptoms table on [page DI-24](#).

7 Check fuel pressure.



PREPARATION:

- (a) Be sure that enough fuel is in the tank.
- (b) Turn the ignition switch ON.
- (c) Connect the hand-held tester to the DLC3.
- (d) Use ACTIVE TEST mode to operate the fuel pump.
- (e) If you have no hand-held tester, connect the positive (+) and negative (–) leads from the battery to the fuel pump connector (See page FI-6).

CHECK:


Check that the pulsation damper screw rises up when the fuel pump operates.

NG

Proceed to [page FI-6](#), and continue to trouble-shoot.

OK

8 Check for spark.



PREPARATION:

- (a) Remove ignition coil.
- (b) Remove the spark plug.
- (c) Install the spark plug to the ignition coil, and connect the ignition coil connector.
- (d) Hold the end about 12.5 mm (0.5 in.) from the ground.
- (e) Disconnect the injector connector.

CHECK:

Check if spark occurs while engine is being cranked.

NOTICE:

To prevent excess fuel being injected from the injectors during this test, don't crank the engine for more than 5 ~ 10 seconds at a time.

NG

Proceed to [page IG-1](#) and continue to trouble-shoot.

OK

Proceed to problem symptoms table on [page DI-24](#).

7. ENGINE OPERATING CONDITION

NOTICE:

The values given below for "Normal Condition" are representative values, so a vehicle may still be normal even if its value from those listed here. So do not decide whether a part is faulty or not solely according to the "Normal Condition" here.

Hand-held tester display	Measurement Item	Normal Condition*1
FUEL SYS #1	Fuel System Bank 1 OPEN: Air-fuel ratio feedback stopped CLOSED: Air-fuel ratio feedback operating	Idling after warming up: CLOSED
CALC LOAD	Calculator Load: Current intake air volume as a proportion of max. intake air volume	Idling: 1ZZ-FE: 11.3 – 16.0 % 2ZZ-GE: 9.1 – 20.0 % Racing without load (2,500rpm): 1ZZ-FE: 12.3 – 17.9 % 2ZZ-GE: 11.0 – 23.0 %
COOLANT TEMP/WATER TEMP.	Water Temp. Sensor Value	After warming up: 80 – 95°C (176 – 203°F)
SHORT FT #1	Short-term Fuel Trim Bank 1	0 ± 20%
LONG FT #1	Long-term Fuel Trim Bank 1	0 ± 20%
MAF/AFM	Air Flow Rate Through Mass Air Flow Meter	Idling: 1ZZ-FE: 1.4 – 2.0 gm/sec. 2ZZ-GE: 1.5 – 5.0 gm/sec. Racing without load (2,500 rpm): 1ZZ-FE: 5.4 – 7.9 gm/sec. 2ZZ-GE: 5.0 – 15.0 gm/sec.
ENGINE SPD	Engine Speed	Idling: 1ZZ-FE: 650 – 750 rpm 2ZZ-GE (MT): 750 – 850 rpm 2ZZ-GE (AT): 700 – 800 rpm
VEHICLE SPD	Vehicle Speed	Vehicle Stopped: 0 km/h (0 mph)
IGN ADVANCE	Ignition Advance: Ignition Timing of Cylinder No. 1	Idling: BTDC 10 – 18°
INTAKE AIR	Intake Air Temp. Sensor Value	Equivalent to Ambient Temp.
THROTTLE POS	Voltage Output of Throttle Position Sensor Calculated as a percentage: 0 V → 0%, 5 V → 100%	Throttle Fully Closed: 6 – 16 % Throttle Fully Open: 64 – 98 %
INJECTOR	Fuel injection time for cylinder No.1	Idling: 1ZZ-FE: 1.1 – 2.1 ms 2ZZ-GE: 0.8 – 2.0 ms
O2S B1, S1	Voltage Output of Oxygen Sensor Bank 1, Sensor 1	Idling: 0.05 – 0.95 V
O2FT B1, S1	Oxygen Sensor Fuel Trim Bank 1, Sensor 1 (Same as SHORT FT #1)	0 ± 20 %
O2S B1, S2*3	Voltage Output of Oxygen Sensor Bank 1 Sensor 2	Driving 50 km/h (31 mph): 0.05 – 0.95 V
MIL ON RUN DIST	Distance since activation of check engine warning light	When there is no DTC: 0 km (0 mile)
ISC DUTY RATIO	Intake Air Control Valve Duty Ratio Opening ratio rotary solenoid type IAC valve	Idling: 1ZZ-FE: 25 – 35 % 2ZZ-GE: 22 – 35 %
STARTER SIG	Starter Signal	Cranking: ON
CTP SW	Closed Throttle Position Switch Signal	Throttle Fully Closed: ON
A/C SIG	A/C Switch Signal	A/C ON: ON

1ZZ-FE, 2ZZ-GE ENGINE (RM733E)

DIAGNOSTICS – ENGINE

STOP LIGHT SW	Stop Light Switch Signal	Stop light switch ON: ON
FC IDL	Fuel Cut Idle: Fuel cut when throttle valve fully closed, during deceleration	Fuel cut operating: ON
PNP SW/NSW *2	Neutral start switch signal	P or N position: ON
FC TAU	Fuel Cut TAU: Fuel cut during very light load	Fuel cut operating: ON
CYL#1, CYL#2, CYL#3, CYL#4	Abnormal revolution variation for each cylinder	0 %
A/C CUT SIG	A/C Cut Signal	A/C S/W OFF: ON
FUEL PUMP	Fuel Pump Signal	Idling: ON
EVAP (PURGE) VSV	EVAP VSV Signal	VSV operation: Above 30 %
TOTAL FT B1*3	Total Fuel Trim Bank 1: Average value for fuel trim system of bank 1	Idling: 0.8 – 1.2 V

*1: If no conditions are specifically stated for "Idling", it means the shift lever is at N or P position, the A/C switch is OFF and all accessory switches are OFF.

*2: A/T only

*3: European spec. only.