

COMPRESSOR AND MAGNETIC CLUTCH

AC1GA-02

ON-VEHICLE INSPECTION

1. INSPECT COMPRESSOR FOR METALLIC SOUND

Check there is abnormal metallic sound from the compressor when the A/C switch is ON.


If abnormal metallic sound is heard, replace the compressor assembly.

2. INSPECT REFRIGERANT PRESSURE

(See page AC-3)

3. INSPECT VISUALLY FOR LEAKAGE OF REFRIGERANT

Using a gas leak detector, check for leakage of refrigerant. If there is any leakage, replace the compressor assembly.



4. INSPECT COMPRESSOR LOCK SENSOR RESISTANCE

- Disconnect the connector.
- Measure resistance between terminals 1 and 2.

Standard resistance:

165 – 205 Ω at 20 °C (68 °F)

If resistance is not as specified, replace the sensor.


5. CHECK FOR LEAKAGE OF GREASE FROM CLUTCH BEARING

6. CHECK FOR SIGNS OF OIL ON PRESSURE PLATE OR ROTOR

7. INSPECT MAGNETIC CLUTCH BEARING FOR NOISE

- Start engine.
- Check for abnormal noise from the compressor when the A/C switch is OFF.

If abnormal noise is being emitted, replace the magnetic clutch.



8. INSPECT MAGNETIC CLUTCH OPERATION

- Disconnect the connector.
- Connect the positive (+) lead from the battery to terminal 3 and the negative (-) lead to the body ground.
- Check that the magnetic clutch energized.

If operation is not as specified, replace the magnetic clutch.