


DTC	C1241/41	IG Power Source Circuit
------------	-----------------	--------------------------------


CIRCUIT DESCRIPTION

This is the power source for the ECU, hence the actuators.

DTC No.	DTC Detecting Condition	Trouble Area
C1241/41	Condition 1. or 2. is detected: - Vehicle speed is at 3 km/h (1.9 mph) or more and ECU terminal IG1 voltage is 9.5 V or less , which continues for 10 sec. or more. - When IG1 terminal voltage is less than 9.5 V, there is open circuit in the motor relay or in the solenoid relay, or the solenoid circuit malfunction.	• Battery • Charging system • Power source circuit

WIRING DIAGRAM



INSPECTION PROCEDURE**1 Check ABS-IG fuse.****PREPARATION:**

Remove ABS-IG fuse from Instrument Panel J/B.

CHECK:

Check continuity of ABS-IG fuse.

OK:

Continuity

NG

Check for short circuit in all the harness and components connected to ABS-IG fuse (See attached wiring diagram).

OK

2 Check battery voltage.**OK:**

Voltage: 10 – 14 V

NG

Check and repair the charging system.

OK

3 Check voltage of the ABS-IG power source.

In case of using hand-held tester:

PREPARATION:


- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and push the hand-held tester main switch ON.
- Select the DATALIST mode on the hand-held tester.

CHECK:

Check the voltage condition output from the ECU displayed on the hand-held tester.

OK:

"Normal" is displayed.



In case of not using hand-held tester:

PREPARATION:

Remove ABS ECU with connectors still connected.

CHECK:

- Turn the ignition switch ON.
- Measure voltage between terminals A20 – 13 and A20 – 12, 25 of ABS ECU connector.

OK:


Voltage: 10 – 14 V

OK

Check and replace ABS ECU.

NG

4 Check continuity between terminals GND (A20 – 12, 25) of ABS ECU connector and body ground.



PREPARATION:

Disconnect the connector from the ABS ECU.

CHECK:

Measure resistance between terminal A20 – 12, 25 of ABS ECU harness side connector and body ground.

OK:

Resistance: 1 Ω or less

NG

Repair or replace harness or connector.

OK

Check for open circuit in harness and connector between ABS ECU and ECU-IG fuse (See page IN-30).