


Diagnosis Circuit

CIRCUIT DESCRIPTION


This circuit sends a signal to the ECU that outputs DTC.

WIRING DIAGRAM



INSPECTION PROCEDURE

- 1 Check voltage between terminals Tc and E₁ of DLC3.

**PREPARATION:**

Turn ignition switch ON.

CHECK:

Measure voltage between terminals Tc and E₁ of DLC3.

OK:

Voltage: 10 - 14 V

OK

Proceed to next circuit inspection shown in problem symptom table ([See page DI-286](#)).

NG

- 2 Check harness and connector between cruise control ECU and DLC3, DLC3 and body ground ([See page IN-30](#)).

NG

Repair or replace harness or connector.

OK

Check and replace cruise control ECU ([See page IN-30](#)).