


DTC	B1412/12	Ambient Temperature Sensor Circuit
-----	----------	------------------------------------

CIRCUIT DESCRIPTION

This sensor detects the ambient temperature and sends the appropriate signals to the A/C control assembly.


DTC No.	Detection Item	Trouble Area
12	Open or short in ambient temperature sensor circuit.	• Ambient temperature sensor. • Harness or connector between ambient temperature sensor and A/C control assembly. • A/C control assembly.

WIRING DIAGRAM



INSPECTION PROCEDURE

- | | |
|---|--|
| 1 | Check voltage between terminals TAM and SG of A/C control assembly connector. |
|---|--|

**PREPARATION:**

- (a) Remove A/C control assembly with connectors still connected.
- (b) Turn ignition switch ON.

CHECK:

Check voltage between terminals TAM and SG of A/C control assembly connector at each temperature .

OK:**Voltage**

at 25 °C (77 °F) : 1.35 – 1.75 V

at 40 °C (104 °F) : 0.85 – 1.25 V


HINT:

As the temperature increases, the voltage decreases.

NG**Go to step 2.****OK**

Proceed to the next circuit inspection shown on problem symptoms table (See page DI-432). However, if DTC 12 is displayed, check and replace A/C control assembly.

- | | |
|---|--|
| 2 | Check ambient temperature sensor. |
|---|--|

**PREPARATION:**

Disconnect ambient temperature sensor connector.

CHECK:

Check resistance between terminals 1 and 2 of ambient temperature sensor connector at each temperature.

OK:**Resistance**

at 25 °C (77 °F) : 1.6 – 1.8 kΩ

at 40 °C (104 °F) : 0.5 – 0.7 kΩ

HINT:

As the temperature increases, the resistance decreases.

NG**Replace ambient temperature sensor.****OK**

3

Check harness and connector between A/C control assembly and ambient temperature sensor ([See page IN-20](#)).

NG

Repair or replace harness or connector.

OK

Check and replace A/C control assembly.