




REASSEMBLY

HINT:


Coat all of the sliding and rotating surfaces with gear oil before reassembly.

1. ASSEMBLE NO. 2 HUB SLEEVE ASSEMBLY

- Install the 3 No. 2 shifting key springs and No. 2 shifting keys to the No. 2 clutch hub.
- Install the No. 2 hub sleeve to the No. 2 clutch hub.

NOTICE:

Assemble the No. 2 hub sleeve and No. 2 clutch hub in the direction shown in the illustration.



2. INSTALL NEEDLE ROLLER BEARING, 3RD GEAR, NO. 2 SYNCHRONIZER RING (FOR 3RD GEAR) AND NO. 2 HUB SLEEVE ASSEMBLY TO INPUT SHAFT

- Apply gear oil to the needle roller bearings and install it.
- Install the 3rd gear and No. 2 synchronizer ring (for the 3rd gear).


NOTICE:

Distinguish the No. 2 synchronizer ring (for the 3rd gear) by the teeth on the synchronizer ring.


- Install the No. 2 hub sleeve assembly so that the No. 2 synchronizer ring slots and No. 2 shifting keys are aligned.

NOTICE:

Be sure to install the No. 2 hub sleeve assembly in the correct direction, as shown in the illustration.



- Using a press, install the No. 2 hub sleeve assembly.



3. INSTALL SNAP RING

- (a) Select a snap ring from the table below that will make the thrust clearance of the No. 2 clutch hub less than 0.1 mm (0.0039 in.).

Mark	Thickness mm (in.)	Mark	Thickness mm (in.)
0	2.30 (0.0906)	3	2.48 (0.0976)
1	2.36 (0.0929)	4	2.54 (0.1000)
2	2.42 (0.0953)	5	2.60 (0.1024)


- (b) Using a screwdriver and hammer, tap in the snap ring.

HINT:

Take care not to damage the journal surface of the input shaft.

4. INSPECT 3RD GEAR THRUST CLEARANCE

(See page MX-32)




5. INSTALL SPACER, NEEDLE ROLLER BEARING, NO. 2 SYNCHRONIZER RING (FOR 4TH GEAR), 4TH GEAR AND CENTER RADIAL BALL BEARING

- (a) Install the spacer.
 (b) Apply gear oil to the needle roller bearings and install it.
 (c) Place the No. 2 synchronizer ring (for the 4th gear) on the No. 2 hub sleeve assembly and align the No. 2 synchronizer ring slots with the No. 2 shifting keys.
 (d) Install the 4th gear.

NOTICE:

Distinguish the No. 2 synchronizer ring (for the 4th gear) by the teeth on the synchronizer ring.



- (e) Using SST and a press, install the center radial ball bearing.


SST 09608-00071

NOTICE:

Be sure to install the center radial ball bearing in the correct direction, as shown in the illustration.

HINT:

Set SST to the bearing inner race securely.

**6. INSTALL SNAP RING**

- (a) Select a snap ring from the table below that will make the thrust clearance of the center radial ball bearing less than 0.1 mm (0.0039 in.).

Mark	Thickness mm (in.)	Mark	Thickness mm (in.)
A	2.29 (0.0902)	D	2.47 (0.0972)
B	2.35 (0.0925)	E	2.53 (0.0996)
C	2.41 (0.0949)	F	2.59 (0.1020)

- (b) Using a screwdriver and hammer, tap in the snap ring.

HINT:

Take care not to damage the journal surface of the input shaft.

7. INSPECT 4TH GEAR THRUST CLEARANCE

(See page MX-32)