

REMOVAL


1. REMOVE FRONT WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

2. M/T or A/T RH side:


REMOVE LOWER SUSPENSION ARM

- (a) Remove the engine under cover.



- (b) Remove the bolt and 2 nuts, and disconnect the lower suspension arm from the lower ball joint.

Torque: 142 N·m (1,450 kgf·cm, 105 ft·lbf)



- (c) Remove the 2 bolts, nut and lower suspension arm.

Torque: 137 N·m (1,397 kgf·cm, 101 ft·lbf)

HINT:

At the time of installation, after stabilizing the suspension, torque the bolts.

3. A/T LH side:


REMOVE LOWER SUSPENSION ARM

- (a) Remove the engine under covers.
 (b) Disconnect the RH and LH tie rod ends.
 (1) Remove the cotter pin and nut.

Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)

HINT:


At the time of installation, if the holes for a new cotter pin are not aligned, tighten the nut further up to 60°.



- (2) Using SST, disconnect the tie rod end from the steering knuckle.

SST 09610-20012

- (3) Employ the same manner described above to the other side.




- (c) Disconnect the RH and LH stabilizer bar links.
 (1) Remove the nut and disconnect the stabilizer bar link from the shock absorber.

Torque: 44 N·m (449 kgf·cm, 32 ft·lbf)

HINT:

If the ball joint turns together with the nut, use a hexagon (5 mm) wrench to hold the stud.

- (2) Employ the same manner described above to the other side.




- (d) Disconnect the RH and LH lower suspension arms from the lower ball joints.

- (1) Remove the bolt and 2 nuts, and disconnect the lower suspension arm from the lower ball joint.

Torque: 142 N·m (1,450 kgf·cm, 105 ft·lbf)

- (2) Employ the same manner described above to the other side.




- (e) Loosen the lower suspension arm set bolts.

Torque: 137 N·m (1,397 kgf·cm, 101 ft·lbf)

HINT:

At the time of installation, after stabilizing the suspension, torque the bolts.

- (f) Remove the engine hood ([See page BO-9](#)).



- (g) Attach the engine sling device to the engine hangers.

- (1) Disconnect the 2 PCV hoses.
 (2) Install the No. 1 and No. 2 engine hangers in the correct direction.

Parts No. : (1ZZ-FE engine)

No. 1 engine hanger: 12281-22021

No. 2 engine hanger: 12281-15040 or 12281-15050

Bolt: 91512-B1016

Parts No. : (2ZZ-GE engine)

No. 1 engine hanger: 12281-88600

No. 2 engine hanger: 12282-88600


Bolt: 91512-61020

Torque: 38 N·m (387 kgf·cm, 28 ft·lbf)

- (3) Attach the engine chain hoist to the engine hangers.

CAUTION:

Do not attempt to hang the engine by hooking the chain to any other part.




- (h) Disconnect the PS gear assembly from the suspension member.

(1) Remove the 4 set bolts.

Torque: 58 N·m (591 kgf·cm, 43 ft·lbf)

(2) Tie the PS gear assembly to suspend it securely.



- (i) Remove the bolt A and 3 nuts, and disconnect the engine rear mount.

Torque: 52 N·m (530 kgf·cm, 38 ft·lbf)

- (j) Remove the 2 bolts (B) and disconnect the engine front mount.

Torque: 52 N·m (530 kgf·cm, 38 ft·lbf)

- (k) Using a transmission jack, support the suspension member.

- (l) Remove the 6 bolts (C and D) and lower the suspension member.

Torque:

Bolt C: 157 N·m (1,600 kgf·cm, 116 ft·lbf)

Bolt D: 39 N·m (400 kgf·cm, 29 ft·lbf)

- (m) Remove the 2 bolts, nut and lower suspension arm.