




## INSPECTION

### NOTICE:

**When using a vise, do not overtighten it.**

### INSPECT STEERING RACK

- (a) Using a dial indicator, check the rack for runout, teeth wear and damage.

**Maximum runout: 0.1 mm (0.004 in.)**

- (b) Check the back surface for wear and damage.