

INSTALLATION

Installation is in the reverse order of removal. (See page [ST-4](#))