

DTC	P0136	Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 2)
------------	--------------	--

DTC	P0137	Oxygen Sensor Circuit Low Voltage (Bank 1 Sensor 2)
------------	--------------	--

DTC	P0138	Oxygen Sensor Circuit High Voltage (Bank 1 Sensor 2)
------------	--------------	---

DTC	P0156	Oxygen Sensor Circuit Malfunction (Bank 2 Sensor 2)
------------	--------------	--

DTC	P0157	Oxygen Sensor Circuit Low Voltage (Bank 2 Sensor 2)
------------	--------------	--

DTC	P0158	Oxygen Sensor Circuit High Voltage (Bank 2 Sensor 2)
------------	--------------	---

HINT:

Sensor 2 refers to the sensor mounted behind the Three-Way Catalytic Converter (TWC) and located far from the engine assembly.

CIRCUIT DESCRIPTION

In order to obtain a high purification rate of the carbon monoxide (CO), hydrocarbon (HC) and nitrogen oxide (NOx) components in the exhaust gas, a TWC is used. For the most efficient use of the TWC, the air–fuel ratio must be precisely controlled so that it is always close to the stoichiometric air–fuel level. For the purpose of helping the ECM to deliver accurate air–fuel ratio control, a Heated Oxygen (HO2) sensor is used.


The HO2 sensor is located behind the TWC, and detects the oxygen concentration in the exhaust gas. Since the sensor is integrated with the heater that heats the sensing portion, it is possible to detect the oxygen concentration even when the intake air volume is low (the exhaust gas temperature is low).

When the air–fuel ratio becomes lean, the oxygen concentration in the exhaust gas is rich. The HO2 sensor informs the ECM that the post–TWC air–fuel ratio is lean (low voltage, i.e. less than 0.45 V).

Conversely, when the air–fuel ratio is richer than the stoichiometric air–fuel level, the oxygen concentration in the exhaust gas becomes lean. The HO2 sensor informs the ECM that the post–TWC air–fuel ratio is rich (high voltage, i.e. more than 0.45 V). The HO2 sensor has the property of changing its output voltage drastically when the air–fuel ratio is close to the stoichiometric level.

The ECM uses the supplementary information from the HO2 sensor to determine whether the air–fuel ratio after the TWC is rich or lean, and adjusts the fuel injection time accordingly. Thus, if the HO2 sensor is work-

ing improperly due to internal malfunctions, the ECM is unable to compensate for deviations in the primary air–fuel ratio control.



P

B17386

DTC No.	DTC Detecting Condition	Trouble Area
P0136 P0156	The rear heated oxygen sensor voltage during active control is 0.2 V or less, or 0.6 V or more. (2 trip detection logic)	<ul style="list-style-type: none"> • Open or short in HO2 sensor (sensor 2) circuit • HO2 sensor (sensor 2) • HO2 sensor heater (sensor 2) • Air–Fuel Ratio (A/F) sensor (sensor 1) • EFI relay • Gas leakage from exhaust system
P0136 P0156	(a) and (b) is met for more than 30 seconds : (a) Estimated rear oxygen sensor temperature is less than 800°C (1,472°F). (b) Rear oxygen sensor impedance is less than 5 Ω.	<ul style="list-style-type: none"> • Open or short in HO2 sensor (sensor 2) circuit • HO2 sensor (sensor 2) • HO2 sensor heater (sensor 2) • Air–Fuel Ratio (A/F) sensor (sensor 1) • EFI relay • Gas leakage from exhaust system
P0137 P0157	The rear heated oxygen sensor voltage during active control is 0.2 V or less. (2 trip detection logic)	<ul style="list-style-type: none"> • Open or short in HO2 sensor (sensor 2) circuit • HO2 sensor (sensor 2) • HO2 sensor heater (sensor 2) • Air–Fuel Ratio (A/F) sensor (sensor 1) • EFI relay • Gas leakage from exhaust system
P0137 P0157	(a) and (b) is met for more than 90 seconds : (a) Estimated rear oxygen sensor temperature is less than 450°C (842°F). (b) Rear oxygen sensor impedance is less than 15 kΩ.	<ul style="list-style-type: none"> • Open or short in HO2 sensor (sensor 2) circuit • HO2 sensor (sensor 2) • HO2 sensor heater (sensor 2) • Air–Fuel Ratio (A/F) sensor (sensor 1) • EFI relay • Gas leakage from exhaust system
P0138 P0158	The rear heated oxygen sensor voltage during active control is 0.6 V or more. (2 trip detection logic)	<ul style="list-style-type: none"> • Open or short in HO2 sensor (sensor 2) circuit • HO2 sensor (sensor 2) • HO2 sensor heater (sensor 2) • Air–Fuel Ratio (A/F) sensor (sensor 1) • EFI relay • Gas leakage from exhaust system
P0138 P0158	The rear heated oxygen sensor output voltage 1.2 V or higher for more than 30 seconds. (2 trip detection logic)	<ul style="list-style-type: none"> • Open or short in HO2 sensor (sensor 2) circuit • HO2 sensor (sensor 2) • HO2 sensor heater (sensor 2) • Air–Fuel Ratio (A/F) sensor (sensor 1) • EFI relay • Gas leakage from exhaust system

MONITOR DESCRIPTION


Active Air-Fuel Ratio Control

The ECM usually performs air-fuel ratio feedback control so that the Air-Fuel Ratio (A/F) sensor output indicates a near stoichiometric air-fuel level. This vehicle includes active air-fuel ratio control in addition to regular air-fuel ratio control. The ECM performs active air-fuel ratio control to detect any deterioration in the Three-Way Catalytic Converter (TWC) and Heated Oxygen (HO2) sensor malfunctions (refer to the diagram below).

Active air-fuel ratio control is performed for approximately 15 to 20 seconds while driving with a warm engine. During active air-fuel ratio control, the air-fuel ratio is forcibly regulated to become lean or rich by the ECM. If the ECM detects a malfunction, one of the following DTCs is set: DTC P0136, P0156 (abnormal voltage output), P0137, P0157 (open circuit) and P0138, P0158 (short circuit).

Abnormal Voltage Output of HO2 Sensor (DTC P0136, P0156)

While the ECM is performing active air-fuel ratio control, the air-fuel ratio is forcibly regulated to become rich or lean. If the sensor is not functioning properly, the voltage output variation is small. For example, when the HO2 sensor voltage does not decrease to less than 0.21 V and does not increase to more than 0.59 V during active air-fuel ratio control, the ECM determines that the sensor voltage output is abnormal and sets DTC P0136.



Open or Short in the Heated Oxygen (HO2) Sensor Circuit (DTC P0137, P0157, P0138 or P0158)

During active air-fuel ratio control, the ECM calculates the Oxygen Storage Capacity (OSC)* of the Three-Way Catalytic Converter (TWC) by forcibly regulating the air-fuel ratio to become rich or lean.



If the HO2 sensor has an open or short, or the voltage output of the sensor noticeably decreases, the OSC indicates an extraordinarily high value. Even if the ECM attempts to continue regulating the air-fuel ratio to become rich or lean, the HO2 sensor output does not change.

While performing active air-fuel ratio control, when the target air-fuel ratio is rich and the HO2 sensor voltage output is 0.21 V or less (lean), the ECM interprets this as an abnormally low sensor output voltage and sets DTC P0137 or P0157. When the target air-fuel ratio is lean and the voltage output is 0.59 V or more (rich) during active air-fuel ratio control, the ECM determines that the sensor voltage output is abnormally high, and sets DTC P0138 or P0158.

HINT:


DTC P0138 or P0158 is also set if the HO2 sensor voltage output is more than 1.2 V for 30 seconds or more.

*: The TWC has the capability to store oxygen. The OSC and the emission purification capacity of the TWC are mutually related. The ECM determines whether the catalyst has deteriorated, based on the calculated OSC value (see page [DI-228](#)).

HO2 SENSOR CIRCUIT LOW VOLTAGE (P0137, P0157: OPEN)**HO2 SENSOR CIRCUIT HIGH VOLTAGE (P0138, P0158: SHORT)**

High or Low Impedance of Heated Oxygen (HO2) Sensor (DTC P0136, P0156, P0137 or P0157)

Interrelation between temperature of the element and impedance:



During normal air–fuel ratio feedback control, there are small variations in the exhaust gas oxygen concentration. In order to continuously monitor the slight variation of the HO2 sensor signal while the engine is running, the impedance* of the sensor is measured by the ECM. The ECM determines that there is a malfunction in the sensor when the measured impedance deviates from the standard range.

*: The effective resistance in an alternating current electrical circuit.

HINT:

- The impedance can not be measured using an ohmmeter.
- DTC P0136 or P0156 indicates the deterioration of the HO2 sensor. The ECM sets the DTC by calculating the impedance of the sensor when the typical enabling conditions are satisfied (1 driving cycle).
- DTC P0137 or P0157 indicates an open or short circuit in the HO2 sensor (1 driving cycle). The ECM sets this DTC when the impedance of the sensor exceeds the threshold 15 kΩ.

MONITOR STRATEGY

Related DTCs	P0136	Heated rear oxygen sensor (Bank 1) output voltage (Output voltage)
		Heated rear oxygen sensor (Bank 1) impedance (Low)
	P0137	Heated rear oxygen sensor (Bank 1) output voltage (Low voltage)
		Heated rear oxygen sensor (Bank 1) impedance (High)
	P0138	Heated rear oxygen sensor (Bank 1) output voltage (High voltage)
		Heated rear oxygen sensor (Bank 1) output voltage (Extremely high)
	P0156	Heated rear oxygen sensor (Bank 2) output voltage (Output voltage)
		Heated rear oxygen sensor (Bank 2) impedance (Low)
	P0157	Heated rear oxygen sensor (Bank 2) output voltage (Low voltage)
		Heated rear oxygen sensor (Bank 2) impedance (High)
	P0158	Heated rear oxygen sensor (Bank 2) output voltage (High voltage)
		Heated rear oxygen sensor (Bank 2) output voltage (Extremely high)
Required sensors/components	Main sensors/components	Heated rear oxygen sensor
	Related sensors/components	Mass air flow meter
Frequency of operation	Once per driving cycle: Active air–fuel ratio control detection Continuous: Others	
Duration	20 sec.: Heated oxygen sensor output (Output voltage, High voltage, Low voltage) 30 sec.: Heated oxygen sensor impedance (Low) 90 sec.: Heated oxygen sensor impedance (High) 10 sec.: Heated oxygen sensor voltage (Extremely high)	
MIL operation	2 driving cycles	
Sequence of operation	None	

TYPICAL ENABLING CONDITIONS

Item	Specification	
	Minimum	Maximum
The monitor will run whenever these DTCs are not present	See page DI-18	
Heated oxygen sensor output voltage (Output voltage, High voltage and Low voltage):		
Active air–fuel ratio control	Performing	
Active air–fuel ratio control being when all of following conditions met	–	
Battery voltage	11 V	–
ECT	75°C (167°F)	–
Idle	OFF	
Engine RPM	–	3,200 rpm
A/F sensor status	Activated	

Fuel system status	Closed loop	
Fuel-cut	OFF	
Engine load	10 to 70%	
Heated oxygen sensor impedance (Low):		
Battery voltage	11 V	–
Estimated sensor temperature	–	700°C (1,292°F)
ECM monitor	Completed	
P0606	Not set	
Heated oxygen sensor impedance (High):		
Battery voltage	11 V	–
Estimated sensor temperature	520°C (968°F)	–
ECM monitor	Completed	
P0606	Not set	
Heated oxygen sensor output voltage (Extremely high):		
Battery voltage	11 V	–
Time after engine start	2 sec.	–

TYPICAL MALFUNCTION THRESHOLDS

Detection Criteria	Threshold
Heated oxygen sensor output voltage (Output voltage):	
Either of the following conditions is met:	Condition 1 or 2
1. All of the following conditions are met:	Condition (a), (b) and (c)
(a) Commanded air-fuel ratio	14.3 or less
(b) Rear HO2S voltage	0.21 to 0.59 V
(c) OSC (Oxygen Storage Capacity of catalyst)	2.5 g or more
2. All of the following conditions are met:	Condition (a), (b) and (c)
(a) Commanded air-fuel ratio	14.9 or more
(b) Rear HO2S voltage	0.21 to 0.59 V
(c) OSC (Oxygen Storage Capacity of catalyst)	2.5 g or more
Heated oxygen sensor output voltage (Low voltage):	
All of the following conditions are met:	Condition 1, 2 and 3
1. Commanded air-fuel ratio	14.3 or less
2. Rear HO2S voltage	Less than 0.21 V
3. OSC (Oxygen Storage Capacity of catalyst)	2.5 g or more
Heated oxygen sensor output voltage (High voltage):	
All of the following conditions are met:	Condition 1, 2 and 3
1. Commanded air-fuel ratio	14.9 or more
2. Rear HO2S voltage	More than 0.59 V
3. OSC (Oxygen Storage Capacity of catalyst)	2.5 g or more
Heated oxygen sensor impedance (Low):	
Duration of following condition	30 sec. or more
Heated oxygen sensor impedance	Less than 5 Ω
Heated oxygen sensor impedance (High):	
Duration of following condition	90 sec. or more
Rear oxygen sensor impedance	15 kΩ or more

Heated oxygen sensor output voltage (Extremely high):	
Duration of following condition	10 sec. or more
Rear oxygen sensor voltage	More than 1.2 V

COMPONENT OPERATING RANGE

Parameter	Standard Value
Rear oxygen sensor voltage	1.2 V or more

O2S TEST RESULT

Refer to page [DI-24](#) for detailed information on O2S TEST RESULT.

Test ID	Test Item	Description	Unit Conversion	Unit	Standard Value
\$07	Output Voltage	Minimum rear HO2 sensor output voltage	Multiply by 0.005	V	Less than TEST LIMIT
\$08	Output Voltage	Maximum rear HO2 sensor output voltage	Multiply by 0.005	V	More than TEST LIMIT
\$91	OSC	Maximum OSC in catalytic converter	Multiply by 0.0156	g	Less than TEST LIMIT

If the sensor voltage is outside the standard values, the ECM interprets this as a malfunction and sets a DTC.


WIRING DIAGRAM

Refer to DTC P2195 on page [DI-312](#).

CONFIRMATION DRIVING PATTERN

HINT:

- This confirmation driving pattern is used in steps 5, 8 and 11 of the following diagnostic troubleshooting procedure when using a hand-held tester.
- Performing this confirmation pattern will activate the Heated Oxygen (HO2) sensor monitor. (The catalyst monitor is performed simultaneously.) This is very useful for verifying the completion of a repair.



READINESS TESTS	
MISFIRE MON	AVAIL
FUEL SYS MON	AVAIL
COMP MON	AVAIL
CAT EVAL	INCMPL
HTD CAT EVAL	N/A
EVAP EVAL	INCMPL
2nd AIR EVAL	N/A
A/C EVAL	N/A
O2S EVAL	INCMPL
O2S HTR EVAL	INCMPL
EGR EVAL	N/A

- (a) Connect a hand-held tester to the DLC3.
- (b) Turn the ignition switch to ON.
- (c) Turn the tester ON.
- (d) Clear DTCs (where set) (see page [DI-42](#)).
- (e) Select the following menu items: DIAGNOSIS / CARB OBD II / READINESS TESTS.
- (f) Check that O2S EVAL is INCMPL (incomplete).
- (g) Start the engine and warm it up.
- (h) Drive the vehicle at 40 mph to 70 mph (64 km/h to 113 km/h) for at least 10 minutes.
- (i) Note the state of the Readiness Tests items. Those items will change to COMPL (complete) as O2S EVAL monitor operates.
- (j) On the tester, select the following menu items: DIAGNOSIS / ENHANCED OBD II / DTC INFO / PENDING CODES and check if any DTCs (any pending DTCs) are set.

HINT:

If O2S EVAL does not change to COMPL, and any pending DTCs fail to set, extend the driving time.

INSPECTION PROCEDURE**HINT:**

Hand-held tester only:

Narrowing down the trouble area is possible by performing ACTIVE TEST of the following "A/F CONTROL" (Heated oxygen sensor or another can be distinguished).

- (a) Perform ACTIVE TEST by hand-held tester (A/F CONTROL).

HINT:

"A/F CONTROL" is the ACTIVE TEST which changes the injection volume to -12.5 % or +25 %.

- (1) Connect the hand-held tester to the DLC3 on the vehicle.
- (2) Turn the ignition switch ON.
- (3) Warm up the engine with the engine speed at 2,500 rpm for approximately 90 seconds.
- (4) Select the menu "DIAGNOSIS / ENHANCED OBD II / ACTIVE TEST / A/F CONTROL".
- (5) Perform "A/F CONTROL" with the engine in an idle condition (press the right or left button).

RESULT:

Heated oxygen sensor reacts in accordance with increase and decrease of injection volume

+25 % → rich output: More than 0.5 V

















-12.5 % → lean output: Less than 0.4 V

NOTICE:

There is a few seconds delay in the sensor 1 (front sensor) output. And there is approximately 20 seconds delay in the sensor 2 (rear sensor).

The following A/F CONTROL procedure enables the technician to check and graph the voltage output of the heated oxygen sensors.

For displaying the graph indication, first enter "ACTIVE TEST / A/F CONTROL / USER DATA," then select "O2S B1S1 and O2S B1S2" by pressing "YES" button, and push "ENTER" button before pressing "F4" button.

	Output voltage of heated oxygen sensor (sensor 1: front sensor)	Output voltage of heated oxygen sensor (sensor 2: rear sensor)	Mainly suspected trouble area
Case 1	Injection volume +25 % ↑ -12.5 %  Output voltage More than 0.5 V Less than 0.4 V  OK	Injection volume +25 % ↑ -12.5 %  Output voltage More than 0.5 V Less than 0.4 V  OK	—
Case 2	Injection volume +25 % ↑ -12.5 %  Output voltage Almost no reaction  NG	Injection volume +25 % ↑ -12.5 %  Output voltage More than 0.5 V Less than 0.4 V  OK	Sensor 1: front sensor (sensor 1, heater, sensor 1 circuit)
Case 3	Injection volume +25 % ↑ -12.5 %  Output voltage More than 0.5 V Less than 0.4 V  OK	Injection volume +25 % ↑ -12.5 %  Output voltage Almost no reaction  NG	Sensor 2: rear sensor (sensor 2, heater, sensor 2 circuit)
Case 4	Injection volume +25 % ↑ -12.5 %  Output voltage Almost no reaction  NG	Injection volume +25 % ↑ -12.5 %  Output voltage Almost no reaction  NG	Extremely rich or lean actual air-fuel ratio (Injector, fuel pressure, gas leakage in exhaust system, etc.)

HINT:

- If different DTCs that are related to different system are output simultaneously while terminal E2 is used as a ground terminal, terminal E2 may be open.
- Read freeze frame data using the hand-held tester. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. when a malfunction occurred.

1	Read output DTC.
----------	-------------------------

PREPARATION:

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch to ON and push the hand-held tester main switch ON.
- (c) When using hand-held tester, enter the following menu: DIAGNOSIS / ENHANCED OBD II / DTC INFO / CURRENT CODES.

CHECK:



Read the DTC using the hand-held tester.

RESULT:

Display (DTC Output)	Proceed to
P0138, P0158	A
P0137, P0157	B
P0136, P0156	C

HINT:

If any other codes besides P0136, P0137, P0138, P0156, P0157 and/or P0158 are output, perform the troubleshooting for those DTCs first.



2	Check output voltage of heated oxygen sensor.
----------	--

PREPARATION:


- (a) Connect the hand-held tester to the DLC3.
- (b) After warming up the engine, run the engine at 2,500 rpm for 3 minutes.
- (c) When using hand-held tester, enter the following menu: DIAGNOSIS / ENHANCED OBD II / DATA LIST / ALL / O2S B1S2 or B2S2.
- (d) Allow the engine to idle.


CHECK:

Read the Heated Oxygen (HO2) sensor output voltage while idling.

RESULT:

HO2 Sensor Output Voltages	Proceed To
More than 1.2 V	A
Less than 1.0 V	B



3**Check for short in harness and connector between terminal OX1B and HT1B, OX2B and HT2B of ECM.****PREPARATION:**


- (a) Turn the ignition switch to OFF and wait for 5 minutes.
 (b) Disconnect the E6 and E7 ECM connectors.

CHECK:

Check the resistance.

OK:**Standard:**

Tester Connections	Specified Conditions
HT1B (E7-1) – OX1B (E7-18)	10 kΩ or higher
HT2B (E6-5) – OX2B (E6-33)	10 kΩ or higher

NG**Replace ECM (See page SF-66).****NG****4****Check resistance of heated oxygen sensor heater.****PREPARATION:**

Disconnect the heated oxygen sensor connector.

CHECK:

Measure resistance between terminals of the heated oxygen sensor.

OK:**Standard:**

Tester Connection	Specified Condition
HT (1) – +B (2)	11 to 16 Ω at 20°C (68°F)
+B (2) – OX (3)	10 kΩ or higher

NG**Replace heated oxygen sensor.****OK****Repair or replace harness or connector.****5****Perform confirmation driving pattern.****NEXT**

6 Check whether DTC output recurs (DTC P0138, P0158)**CHECK:**

- (a) On the hand-held tester, select the following menu items: DIAGNOSIS / ENHANCED OBD II / DTC INFO / CURRENT CODES.
- (b) Read DTCs.

RESULT:

Display (DTC Output)	Proceed To
P0138 or P0158	A
No output	B

B**Check for intermittent problems
(See page [DI-11](#)).****A****Replace heated oxygen sensor.****7 Check output voltage of heated oxygen sensor.****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch to ON and turn the tester ON.
- (c) Start the engine.
- (d) Select the following menu items: DIAGNOSIS / ENHANCED OBD II / DATA LIST / ALL / O2S B1S2.
- (e) After warming up the engine, run the engine at an engine speed of 2,500 rpm for 3 minutes.

CHECK:

Read the output voltage of the HO2 sensor when the engine rpm is suddenly increased.

HINT:

Quickly accelerate the engine to 4,000 rpm 3 times using the accelerator pedal.

Standard: Fluctuates between 0.4 V or less and 0.5 V or more.

NG**Go to step 14.****OK****8 Perform confirmation driving pattern.****NEXT**

9 Check whether DTC output recurs (DTC P0136, P0156)**CHECK:**

- (a) On the hand-held tester, select the following menu items: DIAGNOSIS / ENHANCED OBD II / DTC INFO / CURRENT CODES.
- (b) Read DTCs.

RESULT:

Display (DTC Output)	Proceed To
P0136 or P0156	A
No output	B

B

**Check for intermittent problems
(See page DI-11).**

A**10 Replace heated oxygen sensor.****NEXT****11 Perform confirmation driving pattern.****NEXT****12 Check whether DTC output recurs (DTC P0136, P0156)****CHECK:**

- (a) On the hand-held tester, select the following menu items: DIAGNOSIS / ENHANCED OBD II / DTC INFO / CURRENT CODES.
- (b) Read DTCs.

RESULT:

Display (DTC Output)	Proceed To
P0136 or P0156	A
No output	B

B

Repair completed.

A

13 Perform active test (injection volume).
PREPARATION:

- Connect the hand-held tester to the DLC3.
- Start the engine and turn the tester ON.
- Warm up the engine.
- Select the following menu items: DIAGNOSIS / ENHANCED OBD II / ACTIVE TEST / INJ VOL.

CHECK:

Change the fuel injection volume using the tester, monitoring the voltage output of Air-Fuel Ratio (A/F) and HO2 sensors displayed on the tester.

HINT:


- Change the fuel injection volume within the range of -12 % and +12 %. The injection volume can be changed in 1 % graduations within the range.
- The A/F sensor is displayed as AFS B1S1, and the HO2 sensor is displayed as O2S B1S2, on hand-held testers.

RESULT:

Tester Display (Sensor)	Voltage Variations	Proceed To
AFS B1S1 (AFS B2S1) (A/F)	Alternates between more and less than 3.3 V	OK
AFS B1S1 (AFS B2S1) (A/F)	Remains at more than 3.3 V	NG
AFS B1S1 (AFS B2S1) (A/F)	Remains at less than 3.3 V	NG

HINT:

A normal HO2 sensor voltage (O2S B1S2) reacts in accordance with increases and decreases in fuel injection volumes. When the A/F sensor voltage remains at either less or more than 3.3 V despite the HO2 sensor indicating a normal reaction, the A/F sensor is malfunctioning.



P

B17391

NG
Replace air-fuel ratio (A/F) sensor.
OK

Check and repair extremely rich or lean actural air fuel ratio (injector, fuse pressure, gas leakages from exhaust system, etc.)

14 Check for exhaust gas leakage.

CHECK:

Check for exhaust gas leakage from the exhaust manifold and pipe.

OK:

No exhaust gas leakage.


NG

Repair or replace exhaust gas leakage point.

OK

15 Inspect heated oxygen sensor.

Components Side:



C

A21341

PREPARATION:

Disconnect the HO2 sensor connector.

CHECK:

Measure the resistance between the terminals of the HO2 sensor connector.

OK:

Standard:

Tester Connections	Specified Conditions
HT (2) – +B (1)	11 to 16 Ω at 20°C (68°F)
HT (2) – E (3)	10 k Ω or higher


NG

Replace heated oxygen sensor.

OK

16

Check EFI relay.



PREPARATION:
Remove the EFI relay from the engine room J/B.

CHECK:
Inspect the EFI relay.

OK:

Standard:		
Terminal No.	Condition	Specified Condition
3 – 5	Usually	10 KΩ or higher
3 – 5	Apply B+ between terminals 1 and 2	Below 1 Ω

NG


Replace EFI relay.

OK

17

Check for open and short in harness and connector between ECM and heated oxygen sensor.

Component Side:



B17392

PREPARATION:

- (a) Disconnect the heated oxygen sensor connector.
- (b) Disconnect the E6 and E7 ECM connectors.

CHECK:


Measure the resistance between the wire harness side connectors.

OK:

Standard:


Tester Connection	Specified Condition
OX (H4-3) - OX1B (E7-18)	Below 1 Ω
HT (H4-1) - HT1B (E7-1)	Below 1 Ω
OX (H6-3) - OX2B (E6-33)	Below 1 Ω
HT (H6-1) - HT2B (E6-5)	Below 1 Ω
OX (H4-3) or OX1B (E7-18) - Body ground	10 k Ω or higher
HT (H4-1) or HT1B (E7-1) - Body ground	10 k Ω or higher
OX (H6-3) or OX2B (E6-33) - Body ground	10 k Ω or higher
HT (H6-1) or HT2B (E6-5) - Body ground	10 k Ω or higher

E7 E6 ECM Connector



B17416

Reference (Bank 1 Sensor 2 System Drawing)



Y

A21040

NG

Repair or replace harness or connector.

OK

Replace heated oxygen sensor.