

Driveshaft and Axe

| | |
|------------------|--------|
| GENERAL | DS - 2 |
| DRIVESHAFT | DS - 6 |
| FRONT AXLE | DS -11 |
| REAR AXLE | DS -15 |

GENERAL

SPECIFICATIONS EINC0100

| Driveshaft | 1.6L M/T, A/T | 1.8L M/T, A/T |
|---|------------------------|---------------|
| Joint type | | |
| Outer | B.J. | B.J. |
| Inner | T.J. | T.J. |
| Maximum permissible angle | | |
| B.J. | 45° or more | 45.8° or more |
| T.J. | 22.5° or more | 23° or more |
| Hub end play mm (in.) | 0.008 (0.0003) or less | |
| Wheel bearing starting torque Nm (kg·cm, lb·in) | 1.8 (18, 16) or less | |

B. J. : Birfield joint

M/T : Manual transaxle

T. J. : Tripod joint

A/T : Automatic transaxle

TIGHTENING TORQUE EINC0200

| | Nm | Kgf·cm | lb·ft |
|---|---------|-----------|---------|
| Driveshaft nut | 200-260 | 2200-2600 | 159-192 |
| Knuckle to strut assembly nut | 110-130 | 1100-1300 | 81-96 |
| Lower arm ball joint to knuckle nut | 60-72 | 600-720 | 44-53 |
| Tie rod end to knuckle | 16-34 | 160-340 | 12-25 |
| Brake caliper to knuckle | 69-85 | 690-850 | 51-63 |
| Wheel nut | 90-110 | 900-1100 | 66-81 |
| Rear hub bearing flange nut | 200-260 | 2000-2600 | 159-192 |
| Rear brake to rear axle carrier mounting bolt | 65-75 | 650-750 | 48-56 |
| Rear strut to carrier nut | 110-130 | 1100-1300 | 81-96 |
| Trailing arm to rear axle carrier mounting nut | 100-120 | 1000-1200 | 74-88 |
| Rear suspension arm to rear axle carrier mounting nut | 130-150 | 1300-1500 | 96-110 |





CAUTION



Replace self-locking nuts with new ones after removal.

LUBRICANTS EINC0300

| Items | Recommended | Quantity |
|---|---------------------|------------|
| B.J.87+T.J.87 Type driveshaft (For 1.6L M/T, A/T) | | |
| B.J. boot grease | CENTOPLEX 278M/136K | 95 ± 6gr. |
| T.J. boot grease | KLK T.J. 41-182 | 105 ± 6gr. |
| B.J.92+T.J.92 Type driveshaft (For 1.8L M/T, A/T) | | |
| B.J. boot grease | CENTOPLEX 278M/136K | 110 ± 6gr. |
| T.J. boot grease | KLK T.J. 41-182 | 120 ± 6gr. |

SPECIAL TOOLS EIDA1400

| Tool (Number and Name) | Illustration | Use |
|---|---|---|
| 09495-33000 Puller |  EIDA140A | Removal of wheel bearing inner race from the hub. |
| 09495-33100 Center bearing remover and installer |  EIDA140B | <ol style="list-style-type: none"> 1. Removal of wheel bearing from the knuckle. (use with 09517-29000) 2. Installation of hub to the knuckle. |
| 09517-21500 Front hub remover and installer |  EIDA140C | <ol style="list-style-type: none"> 1. Removal of front hub from the knuckle. (use with 09517-29000) 2. Measurement of front wheel bearing pre-load. (use with 09532-11600) |
| 09517-29000 Knuckle arm bridge |  EIDA140D | <ol style="list-style-type: none"> 1. Removal of front hub from the knuckle. (use with 09517-21500) 2. Removal of wheel bearing outer race from the knuckle. (use with 09495-33100) |

| Tool (Number and Name) | Illustration | Use |
|------------------------------------|---|--|
| 09532-11600 Preload socket |  EIDA140E | Measurement of front wheel bearing pre-load. (use with 09517-21500) |
| 09532-31200A Oil seal installer |  EIDA140F | Installation of wheel bearing to the knuckle. |
| 09568-34000 Ball joint puller |  EIDA140G | Separation of front lower arm and tie rod end ball joint. |

TROUBLESHOOTING

EIDA1500


| Symptom | Possible cause | Remedy |
|---------------------------|--|--|
| Vehicle pulls to one side | Galling of drive shaft ball joint Wear, rattle or galling of wheel bearing Defective front suspension and steering | Replace Replace Adjust or replace |
| Vibration | Wear, damage or bending of drive shaft Drive shaft rattle and hub serration Wear, rattle or scratching of wheel bearing | Replace Replace Replace |
| Shimmy | Improper wheel balance Defective front suspension and steering | Adjust or replace Adjust or replace |
| Excessive noise | Wear, damage or bending of drive shaft Drive shaft rattle and hub serration Drive shaft rattle and side gear serration Wear, rattle or galling of wheel bearing Loose hub nut Defective front suspension and steering | Replace Replace Replace Replace Adjust or replace Adjust or replace |

DRIVESHAFT

FRONT DRIVESHAFT ASSEMBLY

COMPONENTS

EINC0600




TORQUE : Nm (kgf·m, lb·ft)

EINC060A

REMOVAL

EIKB0054


1. Raise the vehicle and remove the front wheel.
2. Remove the split pin and driveshaft nut from the front hub.
3. Drain the transaxle fluid.
4. Using a plastic hammer, disconnect the driveshaft from the axle hub.



EIDA210A

5. Push the axle hub toward the outside of the vehicle, and separate the driveshaft from the axle hub.

6. Insert a pry bar between the transaxle case and joint case, and separate the driveshaft from the transaxle case.



EXDA210B



EIDA211A

INSTALLATION

EIKB0060

1. Apply gear oil on the driveshaft splines and differential case contacting surface.
2. Before installing the driveshaft, set the opening side of the circlip facing downward.
3. After installation, check that the driveshaft cannot be removed by hand.
4. Position the convex side of the washer to face outside and install the nut and split pin.
5. Replace the self-locking nuts and split pin with new ones after removal.

7. Pull out the driveshaft from the transaxle case.


CAUTION

- **Plug the hole of the transaxle case with the oil seal cap to prevent contamination.**
- **Support the driveshaft properly.**
- **Replace the retainer ring whenever the driveshaft is removed from the transaxle case.**

INSPECTION

EIKB0057

1. Check the driveshaft boots for damage and deterioration.
2. Check the ball joints for wear and damage.
3. Check the splines for wear and damage.
4. Check the dynamic damper for cracks and wear.




EIDA212A

FRONT DRIVESHAFT (T.J-BJ TYPE)

COMPONENTS

EINC1000



TORQUE : Nm (kgf·cm, lb·ft)

EINC100A

DISASSEMBLY

EIKB0094

- The boot band should be replaced with a new one.


 **NOTE**

- Do not disassemble the B.J. assembly.
- Special grease must be applied to the driveshaft joint. Do not substitute with another type of grease.

1. Remove the T.J. boot bands and pull the T.J. boot from the T.J. case.


 **NOTE**

Be careful not to damage the boot.



EIDA301A

2. Remove the snap ring and spider assembly from the driveshaft.




EIDA301B

3. Clean the spider assembly.
4. Remove the B.J. boot bands and pull out the T.J. boot and B.J. boot.

 **NOTE**

If the boot is to be reused, wrap tape around the driveshaft splines to protect the boot.




EIDA251D

INSPECTION

EIKB0097

1. Check the driveshaft spline for wear or damage.
2. Check that there is no water or foreign material in the B.J.
3. Check the spider assembly for roller rotation, wear or corrosion.
4. Check the groove inside the T.J. case for wear or corrosion.
5. Check the dynamic damper for damage or cracks.



EIDA252A

REASSEMBLY

EINC1300


1. Wrap tape around the driveshaft splines (T.J. side) to prevent damage to the boots.
2. Apply grease to the driveshaft and install the boots.

Recommended lubricant

B.J. Boot grease : Centoplex 278M/136K
 T.J. Boot grease : KLKTJ41-182 (MS511-50,
 KOREA KLUBER)

3. To install the dynamic damper, keep the B.J. and driveshaft in a straight line and secure the dynamic damper with the dynamic damper band in the direction illustrated.

| | Standard value (LH, RH) | mm (in.) |
|----|--------------------------|---------------------------|
| | 1.6L M/T, A/T | 1.8L M/T, A/T |
| LH | 246 ± 3 (9.69 ± 0.12) | - |
| RH | 475 ± 3 (18.7 ± 0.12) | 439 ± 3 (17.28 ± 0.12) |



EFCDS05A

4. Apply grease into the T.J. boot and install the boot.

| T.J. boot grease gr. | | |
|----------------------|---------------|---------------|
| | 1.6L M/T, A/T | 1.8L M/T, A/T |
| Total | 105 ± 6 | 120 ± 6 |
| In the joint | 65 ± 3 | 75 ± 3 |
| In the boot | 40 ± 3 | 45 ± 3 |

5. Tighten the T.J. boot bands.


6. Add the specified grease to the B.J. as much as was wiped away at inspection.

7. Install the boots.

8. Tighten the B.J. boot bands.

9. To control the air in the T.J. boot, keep the specified distance between the boot bands when they are tightened.

| Standard value (A) | | mm (in.) | |
|--------------------|-----------------------------|-----------------------------|---------------|
| | | 1.6L M/T, A/T | 1.8L M/T, A/T |
| LH | 508.7 ± 2 (20.03 ± 0.08) | 502.5 ± 2 (19.78 ± 0.08) | |
| RH | 806.2 ± 2 (31.73 ± 0.08) | 806 ± 2 (31.73 ± 0.08) | |




EIDA253D

FRONT AXLE

FRONT HUB/KNUCKLE

COMPONENTS

EINC1400



TORQUE : Nm (kgf·m, lb·ft)

EINC140A


REMOVAL

EIKB0120

1. Remove the front wheel.
2. Remove the split pin and driveshaft nut from the front hub.
3. Remove the front brake assembly from the knuckle and suspend it with a wire.
4. Remove the vehicle speed sensor from the knuckle.
5. Disconnect the tie rod end ball joint from the knuckle by using the Special Tool (09568 - 34000).


NOTE

Be sure to tie the special tool (09568 - 34000) to the near part with cord not to fall.




EIDA401A

6. Disconnect the strut assembly from the knuckle.



EIDA401B


- *Install the washer behind the driveshaft nut with the convex side outward as shown in the illustration.*



EIA9212A

7. Disconnect the driveshaft from the hub.

8. Disconnect the lower arm ball joint from the knuckle by using the Special Tool (09568 - 34000).



09568-34000

EIDA401C

9. Remove the hub and knuckle as an assembly.

INSTALLATION

EINC1600

1. Installation is the reverse of removal.



NOTE


- *Tighten the components below to the specified torque as follows :*

| Items | Torque Nm (kgf·cm, lb·ft) |
|-------------------------------------|------------------------------|
| Driveshaft nut | 200-260 (2000-2600, 159-192) |
| Lower arm ball joint to knuckle nut | 60-72 (600-720, 44-53) |
| Knuckle to strut assembly nut | 110-130 (1100-1300, 81-96) |

DISASSEMBLY


EIKB0134

1. After removing the screws(2) mounting the brake disc, remove the brake disc from the hub.
2. Remove the snap ring.




EIDA403A

3. Install the Special Tools as illustrated.




EIDA403B

4. Remove the hub from the knuckle by turning the Special Tool.
5. Remove the Special Tool and dust cover.
6. Remove the bearing inner race from the hub by using the Special Tool.



EIDA403C

7. Using the Special Tool (09495 - 33100, 09517 - 29000), remove the wheel bearing outer race from the knuckle.



EIDA403D


REASSEMBLY

EINC1900

1. Apply multi-purpose grease to the contacting surface of the knuckle hub and bearing thinly.
2. Using the Special Tool (09495 - 33100, 09517 - 29000), press-in the bearing to the knuckle.

NOTE

- *Press-in the outer race of the wheel bearing to prevent damage to the bearing assembly.*
- *When installing a bearing assembly, always use a new one.*




EIKB014A

3. Install the dust cover.
4. Using the Special Tool (09495 - 33100), press-in the hub to the knuckle.

NOTE

Press-in the inner race of the wheel bearing to prevent damage to the bearing assembly.



EIDA405B

INSPECTION


EIKB0137

1. Check the hub for cracks and the splines for wear.
2. Check the brake disc for scoring and damage.
3. Check the knuckle for cracks.
4. Check the bearing for cracks or damage.

5. Install the brake disc.
6. Tighten the hub and the knuckle to the specified torque by using the Special Tool (09517 - 21500).

Specified torque Nm (kgf.cm, ft.lb) :

200-260 (2000-2600, 159-192)




EIDA405C

7. Rotate the hub several times to seat the bearing.
8. Measure the hub bearing starting torque.


Hub bearing starting torque [Limit] :

1.8 Nm (18 kgf.cm, 16 lb.in) or less



EIDA405D

9. If the starting torque is 0 Ncm (0 in.lbs.), measure the hub bearing axial play.



S5DS022E

10. If the hub axial play exceeds the limit while the nut is tightened to 200-260 Nm (2000-2600Kg.cm, 159-192 ft.lb), the bearing, hub and knuckle are not installed correctly. Repeat the disassembly and assembly procedure.

Hub bearing axial play [Limit] :

0.008 mm (0.0031 in.) or less


11. Remove the Special Tool (09517 - 21500).

REAR AXLE

REAR AXLE/HUB

COMPONENTS

EINC2000

**TORQUE : Nm (kgf·m, lb·ft)**

EINC200A

REMOVAL

EINC2100

1. Remove the rear wheel speed sensor (for vehicles equipped with ABS).


CAUTION

When removing the speed sensor from the adapter, be careful so that the end of the pole piece doesn't strike teeth on the rotor or other components.

2. Remove the brake drum.
3. Remove the hub cap, wheel bearing nut and tongue washer.
4. Remove the hub assembly.

⚠ CAUTION

- **The rear hub assembly should not be disassembled.**
- **(For vehicles equipped with ABS)**
Care must be taken not to scratch or damage the teeth of the rotor. The rotor must never be dropped. If the teeth of the rotor are chipped, it results in deformation of the rotor. It will make it impossible to detect the wheel rotation speed accurately and to operate the system normally.



S5SS051B

INSTALLATION


EINC2300

Installation is the reverse of removal.

1. After tightening the flange nut, caulk the concave portion of the spindle by crimping the nut.


⚠ CAUTION

Replace the flange nut with new ones after removal.



S5SS053A

2. Installation of the rear speed sensor (For vehicles equipped with ABS)



KFCDS01A

3. Install the hub cap.

INSPECTION EIKB0170

1. Check the oil seal for cracks or damage.
2. Check the rear hub bearing for wear or damage.
3. Check the rear rotor for chipped teeth.
4. Check the rear carrier for cracks.