

Fuel System

GENERAL	FL -
MFI CONTROL SYSTEM	FL -2
FUEL DELIVERY SYSTEM	FL -8
TROUBLESHOOTING FOR DTC	FL -9

GENERAL

EFHA0010

GENERAL SPECIFICATIONS

Items				Specifications
Throttle body	Throttle position sensor (TPS)	Type		Variable resistor
		Resistance at curb idle	2.0 I4	3.5 ~ 6.5 K Ω
			2.7 V6	1.6 ~ 2.4 K Ω
		Output voltage at curb idle	2.0 I4	300 ~ 900 mV
			2.7 V6	250 ~ 800 mV
	Idle speed control (ISC) actuator	Type		Double Coil
		Resistance		90 ~ 110 Hz
Sensors	Air flow sensor	Type	2.0 I4	MAP sensor
			2.7 V6	HOT Film sensor
	Intake air temperature (IAT) sensor	Type	2.0 I4 & 2.7 V6	Thermistor type
		Resistance		2.33 ~ 2.97 K Ω at 20°C (68°F)
	Engine coolant temperature (ECT) sensor	Type		Thermistor type
		Resistance		2.5 K Ω at 20°C (68°F)
				0.3 K Ω at 80°C (176°F)
	Heated oxygen sensor (HO2S)	Type	2.0 I4	Zirconia type
			2.7 V6	Titania type
	Vehicle speed sensor	Type		Hall effect type
Actuators	Injector	Type, number	2.0 I4	Electromagnetic type, 4
			2.7 V6	Electromagnetic type, 6
		Resistance		13 ~ 16 Ω at 20°C (68°F)
	Evaporative emission purge solenoid	Type		Duty cycle type
Fuel pressure regulator	Pressure regulator			300 $\pm$ 1.5 kPa (3.35 $\pm$ 0.06 kg/cm ²)
Fuel tank	Tank capacity (2.0 I4) Tank capacity (2.7 V6) Return system			65 lit (14.3 Imp.gal) 75 lit (16.5 Imp.gal) Equipped
Canister	Volume/Nominal working capacity			3.0 liter/150g

SEALANT

EFA90020

Item	Specified sealant
Engine coolant temperature sensor	LOCTITE 962T or equivalent

SERVICE STANDARDS

EFHA0030

Items			Standard value
Basic ignition timing	2.0 I4		BTDC 10° ± 5° at curb idle
	2.7 V6		BTDC 12° ± 8° at curb idle
Curb idle speed (rpm)	2.0 I4	D-range (A/T)	750 ± 100
		P,N-range	800 ± 100 (A/CON OFF)
		(A/T, M/T)	900 ± 100 (A/CON ON)
	2.7 V6	D-range (A/T)	725 ± 100
		P,N-range	725 ± 100 (A/CON OFF)
		(A/T, M/T)	900 ± 100 (A/CON ON)
Fuel pressure kPa (psi)	Vacuum hose disconnection		330 ~ 350 (47-50) at curb idle
	Vacuum hose connection		Approx. 270 (38) at curb idle
Evap canister purge solenoid valve resistance			20-32Ω



TIGHTENING TORQUE

EFA90040

Item	Nm	Kg.cm	lb.ft
Delivery pipe installation bolt	10-15	100-150	7-11
Engine coolant temperature sensor	20-40	200-400	14-29
Heated oxygen sensor	40-50	400-500	29-36
Heated oxygen sensor connector bracket bolt	8-12	80-120	5.8-8.7
Fuel pressure regulator installation bolt	4-6	40-60	2.9-4.4
High pressure hose and fuel main pipe	30-40	300-400	22-29
High pressure hose and fuel filter	25-35	250-350	18-25
High pressure hose to delivery pip	3-4	30-40	2.2-3
Fuel pump assembly to fuel tank	2-3	20-30	1.4-2.2
High pressure hose at fuel tank	30-40	300-400	22-29
Throttle body to surge tank	15-20	150-200	11-14
Fuel tank drain plug	15-25	150-250	11-18
Fuel filter mounting bolts	9-14	90-140	6.5-10
Accelerator arm bracket bolts	8-12	80-120	5.8-8.7
ISC actuator	6-8	60-80	4.4-5.8
Fuel sender to fuel tank	2-3	20-30	1.4-2.2

SPECIAL TOOLS

EFA90050

Tool (Number and name)	Illustration	Use
09353-38000 Fuel pressure gauge adapter	 EFA9005A	Connection of fuel pressure gauge to delivery pipe for measurement of fuel pressure.
09353-24100 Fuel pressure gauge & hose	 EFA9005B	

TROUBLESHOOTING EFA90060

When checking engine trouble, it is important to start with an inspection of the basic systems. If one of the following conditions exists, (A) engine start failure, (B) unstable idling or (C) poor acceleration, begin by checking the following basic systems.

1. Power supply
 - Battery
 - Fusible link
 - Fuse
2. Body ground
3. Fuel supply
 - Fuel line
 - Fuel filter
 - Fuel pump
4. Ignition system
 - Spark plug
 - High-tension cable
 - Ignition coil
5. Emission control system
 - PCV system
 - Vacuum leak
6. Others
 - ignition timing
 - Idle speed

Trouble with the MFI system is often caused by poor contact of the harness connectors. It is important to check all harness connectors and verify that they are securely connected.

TROUBLESHOOTING GUIDE

CHART EFDA0070

Main Symptoms Sub-Symptoms Check points	STARTING							Poor Idling					Poor Driving	
	Unable to start			Difficult to start										
	Engine does not turn over	Starter runs but engine does not turn over	Incomplete combustion	Engine turns over	Always	When the engine is cold	When the engine is hot	Incorrect fast idle	High idle speed	Low idle speed	Rough idling	Engine hesitates or accelerates poorly	Surging	Knocking
Starter relay	1													
Starter	2	2		1										
PNP SW [A/T] or Clutch start SW [M/T]	3													
Flywheel [M/T] or Drive plate [A/T]		4												
Mass air flow sensor circuit			3							3	10	7		
Idle speed control actuator			4		3	3	3	3	3	2	7			2
Fuel pressure regulator			5		5	5	5				4	11	1	
ECT sensor circuit			6		4	1	1	2	2	1	2	8	6	
Compression			7		8						8	5		
Piston ring			8		9						9			
Ignition timing					10						11	14		
Timing mark			9								12			
Injectors			10		13	8	8		7	4	13	15	4	
ECM			11		14	9	9	4	8	5	14	16	5	
A/C circuit				2					6					
Connecting rod bearing				3										
Crankshaft bearing				4										
Fuel quality					1	2	2				1	3	3	
Spark plugs					2						3	4	2	
Fuel pump					6	6	6				5	12		
Fuel lines					7	7	7				6	13		
Ignition circuit			2		11									3
Intake air temp. sensor circuit					12	4	4		4			9		1
Accelerator pedal link								1	1					
TP Sensor circuit									5			6		
Cylinder head											15			
Clutch [M/T]												1		
Brakes not releasing properly												2		
Oxygen sensor circuit												10		
Crankshaft position sensor		3												
Battery voltage		1	1											

Main Symptoms Sub-Symptoms Check points	Engine Stalls				Others			Refueling
	Soon after starting	After accelerator pedal is depressed	After accelerator pedal is released	During A/C ON	Excessive fuel consumption	Engine overheats	Engine too cool	Hard to refuel Overflowing spit-Back
Fuel quality	1							
Fuel pressure regulator	2	4			2			
Fuel pump	3							
Fuel lines	4	5						
ISC actuator	5		1	2				
MAF sensor circuit	6	1	2		13			
ECT sensor circuit	7				11			
Injectors	8	6			10			
ECM	9	7	3	3	17			
TP Sensor circuit		2			12			
Spark plug		3			6	8		
A/C circuit				1	14			
Fuel leakage					1			
Accelerator pedal link					3			
Clutch [M/T]					4			
Brakes drag when released					5			
Compression					7			
Piston ring					8			
Ignition timing					9			
Oxygen sensor circuit					15			
Intake air temp. sensor circuit					16			
Coolant leakage						1		
Cooling fan						2	1	
Thermo switch						3		
Radiator and radiator cap						4	2	
Thermostat						5		
Timing belt						6		
Engine coolant pump						7		
Oil pump						9		
Cylinder head						10		
Cylinder block						11		
ECT sender						12	3	
Crankshaft position sensor	11	8	4	4				
Fill vent valve hose-clogging								1
Canister filter-Contamination								2
Fuel shut off valve-operation								3

EFDA007B

NOTE


The number herein means the check order.

MFI TROUBLESHOOTING PROCEDURES

EFA90080

PROBLEM

Communication with scan tool is not possible.
(Communication with all system is not possible)




EFA9008A

SCAN TOOL COMMUNICATION WITH ECM IS NOT POSSIBLE

EFA90090

Comment	Probable cause
One of the following causes may be suspected • No power supply to ECM • Defective ground circuit of ECM • Defective ECM • Improper communication line between ECM and scan tool	• Malfunction of ECM power supply circuit. • Malfunction of the ECM. • Open circuit between ECM and DLC.


ENGINE WILL NOT START EFA90100




EFA9010A

**DIFFICULT TO START
(ENGINE TURNS OVER)**


EFA0110






ROUGH IDLE OR ENGINE STALLS


EFHA0120






**ENGINE HESITATES OR ACCELERATES
POORLY**

EFHA0130





TROUBLESHOOTING

EFA90140

Trouble symptom	Probable cause	Remedy
Engine will not crank.	Battery charge low	Charge or replace battery
	Battery cables loose, corroded or worn	Repair or replace cables
	Transaxle range switch faulty (Vehicle with automatic transaxle only)	Adjust or replace switch
	Fusible link blown	Replace fusible link
	Starter motor faulty	Repair starter motor
	Ignition switch faulty	Replace ignition switch
Engine cranks slowly	Battery charge low	Charge or replace battery
	Battery cables loose, corroded or worn	Repair or replace cables
	Starter motor faulty	Repair starter motor
Starter keeps running	Starter motor faulty	Repair starter motor
	Ignition switch faulty	Replace ignition switch
Starter spins but engine will not crank	Short in wiring	Repair wiring
	Pinion gear teeth broken or starter motor faulty	Repair starter motor
	Ring gear teeth broken	Replace flywheel ring gear or torque converter

FUEL TANK AND FUEL LINE

EFA90150

Trouble symptom	Probable cause	Remedy
Engine malfunctions due to insufficient fuel supply	Bent or kinked fuel pipe or hose	Repair or replace
	Clogged fuel pipe or hose	Clean or replace.
	Clogged fuel filter or in-tank fuel filter	Replace
	Water in fuel filter	Replace the fuel filter or clean the fuel tank and fuel lines
	Dirty or rusted fuel tank interior	Clean or replace
	Malfunctioning fuel pump (Clogged filter in the pump)	Replace
Evaporative emission system malfunctions (when fuel filler cap is removed, pressure is released)	Incorrect routing of a vapor line	Correct
	Disconnected vapor line	Correct
	Folded, bent, cracked or clogged vapor line	Replace
	Faulty fuel tank cap	Replace
	Malfunctioning overfill limiter (Two-way valve)	Replace

MULTIPOINT FUEL INJECTION (MFI) EFA90160**GENERAL INFORMATION**

The Multiport Fuel Injection System consists of sensors which detect the engine conditions, the ENGINE CONTROL MODULE (ECM) which controls the system based on signals from these sensors, and actuators which operate under the control of the ECM. The ECM carries out activities such as fuel injection control, idle air control and ignition timing control. In addition, the ECM is equipped with several diagnostic test modes which simplify troubleshooting when a problem occurs.

FUEL INJECTION CONTROL

The injector drive times and injector timing are controlled so that the optimum air/fuel mixture is supplied to the engine to correspond to the continually-changing engine operation conditions. A single injector is mounted at the intake port of each cylinder. Fuel is sent under pressure from the fuel tank by the fuel pump, with the pressure being regulated by the fuel pressure regulator. The fuel thus regulated is distributed to each of the injectors. Fuel injection is normally carried out once for each cylinder for every two rotations of the crankshaft. The firing order is 1-3-4-2. This is called multiport. The ECM provides a richer air/fuel mixture by carrying out "open-loop" control when the engine is cold or operating under high load conditions in order to maintain engine performance. In addition, when the engine is warm or operating under normal conditions, the ECM controls the air/fuel mixture by using the heated oxygen sensor signal to carry out "closed-loop" control in order to obtain the theoretical air/fuel mixture ratio that provides the maximum cleaning performance from the three way catalyst.

IDLE SPEED CONTROL

The idle speed is kept at the optimum speed by controlling the amount of air that bypasses the throttle valve in accordance with changes in idling conditions and engine load during idling. The ECM drives the idle speed control (ISC) motor to keep the engine running at the pre-set idle target speed in accordance with the engine coolant temperature and air conditioning load. In addition, when the air conditioning switch is turned off and on while the engine is idling, the ISC motor operates to adjust the throttle valve bypass air amount in accordance with the engine load conditions in order to avoid fluctuations in the engine speed.

IGNITION TIMING CONTROL

The ignition power transistor located in the ignition primary circuit turns ON and OFF to control the primary current flow to the ignition coil. This controls the ignition timing in order to provide the optimum ignition timing with respect to the engine operating conditions. The

ignition timing is determined by the ECM from the engine speed, intake air volume, engine coolant temperature and atmospheric pressure.

OTHER CONTROL FUNCTIONS EFA90170

1. **Fuel Pump Control. :**
Turns the fuel pump relay ON so that current is supplied to the fuel pump while the engine is cranking or running.
2. **A/C Compressor Clutch Relay Control. :**
Turns the compressor clutch of the A/C ON and OFF.
3. **Fan Relay Control. :**
The radiator fan and condenser fan speeds are controlled in response to the engine coolant temperature and vehicle speed.
4. **Evaporative Emission Purge Control (Refer to GROUP EC).**

DIAGNOSTIC TEST MODE EFA90180

- When an abnormality is detected in one of the sensors or actuators related to emission control, the CHECK ENGINE/MALFUNCTION INDICATOR LAMP illuminates as a warning to the driver.
- When an abnormality is detected in one of the sensors or actuators, a diagnostic trouble code corresponding to the abnormality is output.
- The RAM data inside the ECM that is related to the sensors and actuators can be read by means of the scan tool. In addition, the actuators can be controlled under certain circumstances.

HOW TO COPE WITH INTERMITTENT MALFUNCTIONS EFA90190

Most intermittent malfunctions occur under certain conditions. If those conditions can be identified, the cause will be easier to find.

TO COPE WITH INTERMITTENT MALFUNCTION;

1. **Ask the customer about the malfunction.**
Ask what it feels like, what it sounds like, etc. Then ask about driving conditions, weather, frequency of occurrence, and so on.
2. **Determine the conditions from the customer's responses.**
Typically, almost all intermittent malfunctions occur from conditions like vibration, temperature and/or moisture change, poor connections. From the customer's replies, it should be reasoned which condition is influenced.
3. **Use the simulation test**

In the cases of vibration or poor connections, use the simulation tests below to attempt to duplicate the customer's complaint. Determine the most likely circuit(s) and perform the simulation tests on the connectors and parts of that circuit(s). Be sure to use the inspection procedures provided for diagnostic trouble codes and trouble symptoms. For temperature and/or moisture conditions related intermittent malfunctions, using common sense, try to change the conditions of the suspected circuit components, then use the simulation tests below.

4. Verify the intermittent malfunction is eliminated. Repair the malfunctioning part and try to duplicate the condition(s) again to verify the intermittent malfunction has been eliminated.

SIMULATION TESTS

For these simulation tests, shake, then gently bend, pull and twist the wiring of each of these examples to duplicate the intermittent malfunction.

- Shake the connector up-and-down, right-and-left.
- Shake the wiring harness up-and-down, right-and-left.
- Vibrate the part or sensor.

SERVICE POINTS IN INSPECTING A BLOWN FUSE

EFAA0200

Remove the fuse and measure the resistance between the load side of the fuse and ground. Set the switches of all circuits which are connected to this fuse to a condition of continuity. If the resistance is almost 0Ω at this time, there is a shortage somewhere between these switches and the load. If the resistance is not 0Ω , there is no shortage at the present time, but a momentary shortage has probably caused the fuse to blow.

The main causes of a short circuit are the following.

- Harness being clamped by the vehicle body.
- Damage to the outer casing of the harness due to wear or heat.
- Water getting into the connector or circuitry.
- Human error (mistakenly shorting a circuit, etc.).

INSPECTING THE MFI SYSTEM

EFHA0210

If the MFI system components (sensors, ECM, injector, etc.) fail, the interruption or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered:

1. Engine is hard to start or does not start at all
2. Unstable idle
3. Poor driveability

If any of the above conditions is noted, first perform an inspection by self-diagnosis and subsequent basic engine checks (ignition system malfunction, incorrect engine adjustment, etc.), and then inspect the MFI system components.

ON-BOARD DIAGNOSTICS

- The recording condition of diagnostic trouble code. After the ECM first detects a malfunction, a diagnostic trouble code is recorded when the engine is restarted and the same malfunction is re-detected. (Malfunction is detected in driving cycle). However, for fuel system rich/lean misfiring, a diagnostic trouble code is recorded on the first detection of the malfunction.
- The erasing condition of diagnostic trouble code. After recording the diagnostic trouble code, if the ECM does not re-detect the malfunction for 40 driving cycles, the diagnostic trouble code will be erased from the ECM memory. However, for fuel system rich/lean or misfiring, the diagnostic trouble code will be erased under the following conditions.
 - When driving conditions (engine speed, engine coolant temperature, etc.) are similar to those when the malfunction was first recorded.
 - When the ECM does not re-detect the malfunction for 80 driving cycles.

NOTE

A "driving cycle" consists of the engine start, vehicle operation beyond the beginning of closed loop operation.

MALFUNCTION INDICATOR LIGHT (MIL)

An On Board Diagnostic lamp lights up to notify the driver that there is a problem with the vehicle.


However MIL will go off automatically after 3 subsequent sequential driving cycles that do not re-detected the same malfunctions.

Immediately after the ignition switch is turned on, the malfunction indicator light is lit for 5 seconds to indicate that the malfunction indicator light operates normally.

Following items will be indicated by the MIL

- Catalyst
- Fuel system
- Air flow sensor (MAF sensor)
- Intake Air Temperature Sensor (IAT sensor)
- Engine Coolant Temperature Sensor (ECT sensor)
- Throttle Position Sensor (TPS)
- Upstream Oxygen Sensor
- Downstream Oxygen Sensor Heater
- Downstream Oxygen Sensor
- Upstream Oxygen Sensor Heater

- Injector
- Misfire
- Crankshaft Position Sensor (CKP sensor)
- Camshaft Position Sensor (CMP sensor)
- Evaporative Emission Control System
- Vehicle Speed Sensor (VSS)
- Idle Speed Control
- ECM
- Manifold Absolute Pressure (MAP) Sensor (Except 2.5L V6 engine)
- Idle Switch
- EGR System (Except 2.5L V6 engine)



EFA9021A

INSPECTING THE MALFUNCTION INDICATOR LAMP (MIL)

1. After turning on the ignition key, check that the light illuminates for 5 seconds without the engine running.
2. If the light does not illuminate, check for an open circuit in harness, blown fuse and blown bulb.

SELF-DIAGNOSIS

The ECM monitors the input/output signals (some signals at all times and others under specified conditions). When the ECM detects that an irregularity, it memorizes the diagnostic trouble code, and outputs the signal to the self-diagnosis output terminal. The diagnosis results can be read by the Generic Scan Tool (GST). Diagnostic trouble code (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble code will however be erased when the battery terminal or the engine control module (ECM) connector is disconnected or erased by the Generic Scan Tool.


CHECKING PROCEDURE (SELF-DIAGNOSIS)

NOTE

1. When battery voltage is low, diagnostic trouble codes can not be read. Be sure to check the battery for voltage and charging system before starting the test.
2. Diagnosis memory is erased if the battery or the ECM connector is disconnected. Do not disconnect the battery before the diagnostic trouble codes are completely read and recorded.

Inspection Procedure (Using Generic Scan Tool)

1. Turn OFF the ignition switch.
2. Connect the scan tool to the data link connector on the lower crash pad.
3. Turn ON the ignition switch.
4. Use the GST to check the diagnostic trouble code.
5. Repair the faulty part from the diagnosis chart.
6. Erase the diagnostic trouble code.
7. Disconnect the GST.




EFHA021B

MFI CONTROL SYSTEM

TROUBLESHOOTING EFHA0220

DIAGNOSTIC TROUBLESHOOTING FLOW



INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (FOR 2.0 I4 OBD-II)

EFHA0240

[FOR 2.0 I4 OBD-II]

DTC NO.	CONTENT	Memory	MIL
P0107	Manifold Absolute Pressure Sensor Low Voltage	O	O
P0108	Manifold Absolute Pressure Sensor High Voltage	O	O
P0112	Intake Air Temp. Low Voltage	O	O
P0113	Intake Air Temp. High Voltage	O	O
P0115 (FL-106)	Engine Coolant Temp. Circuit Malfunction	O	O
P0116	Engine Coolant Temp. Sensor Drift	O	O
P0122	Throttle Position Sensor Low Voltage	O	O
P0123	Throttle Position Sensor High Voltage	O	O
P0132	Oxygen Sensor Circuit Open (Bank 1, Sensor 1)	O	O
P0133 (FL-114)	Oxygen Sensor Circuit Malfunction (Bank 1, Sensor 1)	O	O
P0134 (FL-119)	Excessive Time to Enter Closed Loop Fuel Control	O	O
P0135 (FL-122)	Oxygen Sensor Heater Circuit Malfunction (Bank 1, Sensor 1)	O	O
P0136 (FL-125)	Oxygen Sensor Circuit Open (Bank 1, Sensor 2)	O	O
P0140	Oxygen Sensor Circuit Short (Bank 1, Sensor 2)	O	O
P0141 (FL-130)	Oxygen Sensor Heater Circuit Malfunction (Bank 1, Sensor 2)	O	O
P0171	Fuel System Too Lean	O	O
P0172	Fuel System Too Rich	O	O
P0201 (FL-133)	Injector Circuit Malfunction (Cylinder -1,)	O	O
P0202 (FL-133)	Injector Circuit Malfunction (Cylinder -2)	O	O
P0203 (FL-133)	Injector Circuit Malfunction (Cylinder -3)	O	O
P0204 (FL-133)	Injector Circuit Malfunction (Cylinder -4)	O	O
P0300 (FL-137)	Random Misfire Detected	O	O
P0301 (FL-142)	Misfire Detected (Cylinder -1)	O	O
P0302 (FL-142)	Misfire Detected (Cylinder -2)	O	O
P0303 (FL-142)	Misfire Detected (Cylinder -3)	O	O
P0304 (FL-142)	Misfire Detected (Cylinder -4)	O	O
P0325	Knock Sensor Circuit Malfunction	O	X
P0335 (FL-145)	Crankshaft Position Sensor Circuit Malfunction	O	O
P0340 (FL-148)	Camshaft Position Sensor Circuit Malfunction	O	O
P0350	Ignition Coil Malfunction	O	O
P0421 (FL-150)	Warm-up Catalyst Efficiency Below Threshold	O	O

DTC NO.	CONTENT	Memory	MIL
P0443 (FL-152)	Evaporative Emission Control System Purge Control Valve Circuit Malfunction	O	O
P0500 (FL-155)	Vehicle Speed Sensor Malfunction	O	O
P0507	Idle Speed Control - High RPM	O	O
P1330	Spark Timing Adjust Malfunction	O	O

[FOR 2.0 I4 NON OBD-II]

DTC NO.	CONTENT	Memory	MIL
P0105 (FL-99)	Manifold Absolute Pressure Sensor Malfunction	O	O
P0110 (FL-103)	Intake Air Temp. Circuit Malfunction	O	O
P0115 (FL-106)	Engine Coolant Temp. Circuit Malfunction	O	O
P0120 (FL-110)	Throttle Position Circuit Malfunction	O	O
P0130 (FL-114)	Oxygen Sensor Circuit Malfunction (Bank 1, Sensor 1)	O	O
P0136 (FL-125)	Oxygen Sensor Circuit Malfunction (Bank 1, Sensor 2)	O	O
P0201 (FL-133)	Injector Circuit Malfunction (Cylinder -1,)	O	O
P0202 (FL-133)	Injector Circuit Malfunction (Cylinder -2)	O	O
P0203 (FL-133)	Injector Circuit Malfunction (Cylinder -3)	O	O
P0204 (FL-133)	Injector Circuit Malfunction (Cylinder -4)	O	O
P0325	Knock Sensor Circuit Malfunction	O	X
P0335 (FL-145)	Crankshaft Position Sensor Circuit Malfunction	O	O
P0340 (FL-148)	Camshaft Position Sensor Circuit Malfunction	O	O
P0350	Ignition Coil Malfunction	O	O
P0500 (FL-155)	Vehicle Speed Sensor Malfunction	O	X
P1330	Spark Timing Adjust Malfunction	O	O

**INSPECTION CHART FOR DIAGNOSTIC
TROUBLE CODES (FOR 2.7 V6)**

EFHA0242

[FOR 2.7 V6 OBD-II]

DTC NO.	CONTENT	Memory	MIL
P0100	Mass or Volume Air Flow Circuit Malfunction	O	O
P0101	Mass or volume Air Flow Circuit Range/Performance Problem	O	X
P0110	Intake Air Temperature Circuit Malfunction	O	O
P0115	Engine Coolant Temperature Circuit Malfunction	O	O
P0120	Throttle Pedal Position Circuit Malfunction	O	O
P0121	Throttle/Pedal Position Circuit Range/Performance problem	O	X
P0130	O2 Sensor Circuit Malfunction (Bank 1 Sensor 1)	O	O

INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (FOR 2.0 I4 OBD-II)

EFHA0240

[FOR 2.0 I4 OBD-II]

DTC NO.	CONTENT	Memory	MIL
P0107	Manifold Absolute Pressure Sensor Low Voltage	O	O
P0108	Manifold Absolute Pressure Sensor High Voltage	O	O
P0112	Intake Air Temp. Low Voltage	O	O
P0113	Intake Air Temp. High Voltage	O	O
P0115 (FL-106)	Engine Coolant Temp. Circuit Malfunction	O	O
P0116	Engine Coolant Temp. Sensor Drift	O	O
P0122	Throttle Position Sensor Low Voltage	O	O
P0123	Throttle Position Sensor High Voltage	O	O
P0132	Oxygen Sensor Circuit Open (Bank 1, Sensor 1)	O	O
P0133 (FL-114)	Oxygen Sensor Circuit Malfunction (Bank 1, Sensor 1)	O	O
P0134 (FL-119)	Excessive Time to Enter Closed Loop Fuel Control	O	O
P0135 (FL-122)	Oxygen Sensor Heater Circuit Malfunction (Bank 1, Sensor 1)	O	O
P0136 (FL-125)	Oxygen Sensor Circuit Open (Bank 1, Sensor 2)	O	O
P0140	Oxygen Sensor Circuit Short (Bank 1, Sensor 2)	O	O
P0141 (FL-130)	Oxygen Sensor Heater Circuit Malfunction (Bank 1, Sensor 2)	O	O
P0171	Fuel System Too Lean	O	O
P0172	Fuel System Too Rich	O	O
P0201 (FL-133)	Injector Circuit Malfunction (Cylinder -1,)	O	O
P0202 (FL-133)	Injector Circuit Malfunction (Cylinder -2)	O	O
P0203 (FL-133)	Injector Circuit Malfunction (Cylinder -3)	O	O
P0204 (FL-133)	Injector Circuit Malfunction (Cylinder -4)	O	O
P0300 (FL-137)	Random Misfire Detected	O	O
P0301 (FL-142)	Misfire Detected (Cylinder -1)	O	O
P0302 (FL-142)	Misfire Detected (Cylinder -2)	O	O
P0303 (FL-142)	Misfire Detected (Cylinder -3)	O	O
P0304 (FL-142)	Misfire Detected (Cylinder -4)	O	O
P0325	Knock Sensor Circuit Malfunction	O	X
P0335 (FL-145)	Crankshaft Position Sensor Circuit Malfunction	O	O
P0340 (FL-148)	Camshaft Position Sensor Circuit Malfunction	O	O
P0350	Ignition Coil Malfunction	O	O
P0421 (FL-150)	Warm-up Catalyst Efficiency Below Threshold	O	O

DTC NO.	CONTENT	Memory	MIL
P0443 (FL-152)	Evaporative Emission Control System Purge Control Valve Circuit Malfunction	O	O
P0500 (FL-155)	Vehicle Speed Sensor Malfunction	O	O
P0507	Idle Speed Control - High RPM	O	O
P1330	Spark Timing Adjust Malfunction	O	O

[FOR 2.0 I4 NON OBD-II]

DTC NO.	CONTENT	Memory	MIL
P0105 (FL-99)	Manifold Absolute Pressure Sensor Malfunction	O	O
P0110 (FL-103)	Intake Air Temp. Circuit Malfunction	O	O
P0115 (FL-106)	Engine Coolant Temp. Circuit Malfunction	O	O
P0120 (FL-110)	Throttle Position Circuit Malfunction	O	O
P0130 (FL-114)	Oxygen Sensor Circuit Malfunction (Bank 1, Sensor 1)	O	O
P0136 (FL-125)	Oxygen Sensor Circuit Malfunction (Bank 1, Sensor 2)	O	O
P0201 (FL-133)	Injector Circuit Malfunction (Cylinder -1,)	O	O
P0202 (FL-133)	Injector Circuit Malfunction (Cylinder -2)	O	O
P0203 (FL-133)	Injector Circuit Malfunction (Cylinder -3)	O	O
P0204 (FL-133)	Injector Circuit Malfunction (Cylinder -4)	O	O
P0325	Knock Sensor Circuit Malfunction	O	X
P0335 (FL-145)	Crankshaft Position Sensor Circuit Malfunction	O	O
P0340 (FL-148)	Camshaft Position Sensor Circuit Malfunction	O	O
P0350	Ignition Coil Malfunction	O	O
P0500 (FL-155)	Vehicle Speed Sensor Malfunction	O	X
P1330	Spark Timing Adjust Malfunction	O	O

**INSPECTION CHART FOR DIAGNOSTIC
TROUBLE CODES (FOR 2.7 V6)**

EFHA0242

[FOR 2.7 V6 OBD-II]

DTC NO.	CONTENT	Memory	MIL
P0100	Mass or Volume Air Flow Circuit Malfunction	O	O
P0101	Mass or volume Air Flow Circuit Range/Performance Problem	O	X
P0110	Intake Air Temperature Circuit Malfunction	O	O
P0115	Engine Coolant Temperature Circuit Malfunction	O	O
P0120	Throttle Pedal Position Circuit Malfunction	O	O
P0121	Throttle/Pedal Position Circuit Range/Performance problem	O	X
P0130	O2 Sensor Circuit Malfunction (Bank 1 Sensor 1)	O	O

DTC NO.	CONTENT	Memory	MIL
P0150	O2 Sensor Circuit Malfunction (Bank 2 Sensor 1)	O	O
P0133	O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)	O	O
P0153	O2 Sensor Circuit Slow Response (Bank 2 Sensor 1)	O	O
P0134	O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)	O	X
P0154	O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 1)	O	X
P0135	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)	O	O
P0155	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)	O	O
P0136	O2 Sensor Circuit Malfunction (Bank 1 Sensor 2)	O	O
P0156	O2 Sensor Circuit Malfunction (Bank 2 Sensor 2)	O	O
P0140	Downstream O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 2)	O	X
P0160	Downstream O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 2)	O	X
P0141	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)	O	O
P0161	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 2)	O	O
P0170	Fuel Trim Malfunction (Bank 1)	O	O
P0173	Fuel Trim Malfunction (Bank 2)	O	O
P0201	Cylinder 1 - Injector Circuit Malfunction	O	O
P0202	Cylinder 2 - Injector Circuit Malfunction	O	O
P0203	Cylinder 3 - Injector Circuit Malfunction	O	O
P0204	Cylinder 4 - Injector Circuit Malfunction	O	O
P0205	Cylinder 5 - Injector Circuit Malfunction	O	O
P0206	Cylinder 6 - Injector Circuit Malfunction	O	O
P0230	Fuel Pump Circuit Malfunction	O	X
P0301	Cylinder 1 - Misfire Detected	O	O
P0302	Cylinder 2 - Misfire Detected	O	O
P0303	Cylinder 3 - Misfire Detected	O	O
P0304	Cylinder 4 - Misfire Detected	O	O
P0305	Cylinder 5 - Misfire Detected	O	O
P0306	Cylinder 6 - Misfire Detected	O	O
P0325	Knock Sensor 1 Circuit Malfunction	O	X
P0330	Knock Sensor 2 Circuit Malfunction	O	X
P0335	Crankshaft Position Sensor 'A' Circuit Malfunction	O	O
P0340	Camshaft Position Sensor (TDC Sensor) Circuit Malfunction	O	O
P0350	Ignition Coil Primary/Secondary Circuit Malfunction	O	X
P0351	Ignition Coil 'A' Primary/Secondary Circuit Malfunction	O	X
P0352	Ignition Coil 'B' Primary/Secondary Circuit Malfunction	O	X

DTC NO.	CONTENT	Memory	MIL
P0353	Ignition Coil 'C' Primary/Secondary Circuit Malfunction	O	X
P0354	Ignition Coil 'D' Primary/Secondary Circuit Malfunction	O	X
P0355	Ignition Coil 'E' Primary/Secondary Circuit Malfunction	O	X
P0356	Ignition Coil 'F' Primary/Secondary Circuit Malfunction	O	X
P0420	Catalyst System Efficiency Below Threshold (Bank 1)	O	O
P0430	Catalyst System Efficiency Below Threshold (Bank 2)	O	O
P0443	Purge Control Valve Circuit Malfunction	O	O
P0500	For OBD2 Rough Road Detection, Vehicle Speed Malfunction From ABS/TCS	O	O
	For OBD2 Rough Road Detection, Vehicle Speed Malfunction From Front Right Inductive Wheel Sensor	O	O
P0505	Idle Control System Malfunction (Mechanical Error)	O	X
P0506	Idle Speed Control RPM Lower Than Expected	O	X
P0507	Idle Speed Control RPM Higher Than Expected	O	X
P0550	Powersteering Pressure Sensor Circuit Malfunction	O	X
P1134	O2 Sensor Circuit - Transition Switch Time Malfunction/Slop (Bank 1 Sensor 1)	O	O
P1154	O2 Sensor Circuit - Transition Switch Time Malfunction/Slop (Bank 2 Sensor 1)	O	O
P1166	O2 Sensor - Controller Adaption Diagnosis Malfunction (Bank 1)	O	O
P1167	O2 Sensor - Controller Adaption Diagnosis Malfunction (Bank 2)	O	O
P1372	Segment Time Acquisition Incorrect	O	O
P1510	Idle Charge Actuator Command Signal Incorrect (Coil 1)	O	O
P1511	Idle Charge Actuator Command Signal Incorrect (Coil 2)	O	O
P1529	Customer Snapshot (MIL Request/Freeze Frame) Request VIA CAN	O	O
P1602	Serial Communication Problem With TCU (TIMEOUT)	O	O
P1613	ECU - Selftest Failed	O	X
P1616	Main Relay Malfunction	O	X
P1623	Diagnostic Lamp powerstage Malfunction	O	X
P1624	Cooling Fan Relay - Circuit Malfunction ("LOW" Circuit)	O	X
P1625	Cooling Fan Relay - Circuit Malfunction ("HIGH" Circuit)	O	X

[FOR 2.7 V6 NON OBD-II]

DTC NO.	CONTENT	Memory	MIL
P0100	Mass or Volume Air Flow Circuit Malfunction	O	X
P0110	Intake Air Temperature Circuit Malfunction	O	X
P0115	Engine Coolant Temperature Circuit Malfunction	O	X

DTC NO.	CONTENT	Memory	MIL
P0120	Throttle Pedal Position Circuit Malfunction	O	X
P0130	O2 Sensor Circuit Malfunction (Bank 1 Sensor 1)	O	X
P0150	O2 Sensor Circuit Malfunction (Bank 2 Sensor 1)	O	X
P0134	O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)	O	X
P0154	O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 1)	O	X
P0135	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)	O	X
P0155	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)	O	X
P0201	Cylinder 1 - Injector Circuit Malfunction	O	X
P0202	Cylinder 2 - Injector Circuit Malfunction	O	X
P0203	Cylinder 3 - Injector Circuit Malfunction	O	X
P0204	Cylinder 4 - Injector Circuit Malfunction	O	X
P0205	Cylinder 5 - Injector Circuit Malfunction	O	X
P0206	Cylinder 6 - Injector Circuit Malfunction	O	X
P0230	Fuel Pump Circuit Malfunction	O	X
P0325	Knock Sensor 1 Circuit Malfunction	O	X
P0330	Knock Sensor 2 Circuit Malfunction	O	X
P0335	Crankshaft Position Sensor 'A' Circuit Malfunction	O	X
P0340	Camshaft Position Sensor (TDC Sensor) Circuit Malfunction	O	X
P0350	Ignition Coil Primary/Secondary Circuit Malfunction	O	X
P0351	Ignition Coil 'A' Primary/Secondary Circuit Malfunction	O	X
P0352	Ignition Coil 'B' Primary/Secondary Circuit Malfunction	O	X
P0353	Ignition Coil 'C' Primary/Secondary Circuit Malfunction	O	X
P0354	Ignition Coil 'D' Primary/Secondary Circuit Malfunction	O	X
P0355	Ignition Coil 'E' Primary/Secondary Circuit Malfunction	O	X
P0356	Ignition Coil 'F' Primary/Secondary Circuit Malfunction	O	X
P0500	For OBD2 Rough Road Detection, Vehicle Speed Malfunction From ABS/TCS	O	X
	For OBD2 Rough Road Detection, Vehicle Speed Malfunction From Front Right Inductive Wheel Sensor	O	X
P1166	O2 Sensor - Controller Adaption Diagnosis Malfunction (Bank 1)	O	X
P1167	O2 Sensor - Controller Adaption Diagnosis Malfunction (Bank 2)	O	X
P1510	Idle Charge Actuator Command Signal Incorrect (Coil 1)	O	X
P1511	Idle Charge Actuator Command Signal Incorrect (Coil 2)	O	X
P1602	Serial Communication Problem With TCU (TIMEOUT)	O	X
P1613	ECU - Self-test Failed	O	X
P1616	Main Relay Malfunction	O	X

TROUBLE AREA RELATED TO DTC (FOR 2.0 I4)

EFHA0243

DTC No.	Diagnostic items	Check items (Remedy)
P0110	Intake Air Temperature Circuit Malfunction	• Harness and connector • Intake air temperature sensor • Open or short in intake air temp. sensor circuit • Intake air temp. sensor • ECM
P0115	Engine Coolant Temperature Circuit Malfunction	• Harness and connector • Engine coolant temperature sensor • Open or short in engine coolant temp. sensor circuit • ECM
P0120	Throttle Position Circuit Malfunction	• Harness and connector • Throttle position sensor • Idle switch • Open or short in throttle position sensor circuit • ECM
P0130	Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 1)	• Harness and connector • Oxygen sensor
P0133	Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 1)	
P0136	Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 2)	• Harness and connector • Oxygen sensor (rear)
P0201	Injector Circuit Malfunction - Cylinder 1	• Harness and connector • Injector
P0202	Injector Circuit Malfunction - Cylinder 2	
P0203	Injector Circuit Malfunction - Cylinder 3	
P0204	Injector Circuit Malfunction - Cylinder 4	
P0325	Knock Sensor 1 Circuit Malfunction	• Open or short between knock sensor and ECM • Harness and connector • Knock sensor
P0335	Crankshaft Position Sensor Circuit Malfunction	• Harness and connector • Open or short in crankshaft position sensor • Crankshaft position sensor • ECM
P0340	Camshaft Position Sensor Circuit Malfunction	• Harness and connector (If harness and connector are normal replace camshaft position sensor)
P0500	Vehicle Speed Sensor Malfunction	• Harness and connector • Vehicle speed sensor

**TROUBLE AREA RELATED TO DTC
(FOR 2.7 V6)**

EFHA0244

DTC No.	Diagnostic items	Trouble Area (Check Point)
P0100	Mass or Volume Air Flow Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor
P0101	Mass or Volume Air Flow Circuit Range/Performance Problem	• Foreign material deposit in the sensor • Bad connection of connectors/bad wiring
P0110	Intake Air Temperature Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor
P0115	Engine Coolant Temperature Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor
P0120	Throttle/Pedal Position Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor
P0121	Throttle/Pedal Position Circuit Range/Performance Problem	• Sensor's weariness or improper installation • Bad connection of connectors/bad wiring • Malfunction of the sensor
P0130	O2 Sensor Circuit Malfunction (Bank 1 Sensor 1)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B1/S1)
P0150	O2 Sensor Circuit Malfunction (Bank 2 Sensor 1)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B2/S1)
P0133	O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)	• Sensor deteriorated or contamination deposit • Sensor pin corrosion
P0153	O2 Sensor Circuit Slow Response (Bank 2 Sensor 1)	• Sensor deteriorated or contamination deposit (B2/S1) • Sensor pin corrosion
P0134	O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)	• Sensor deteriorated or contamination deposit (B1/S1) • Sensor pin corrosion
P0154	O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 1)	• Sensor deteriorated or foreign material deposit (B2/S1) • Sensor pin corrosion
P0135	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B1/S1)
P0155	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B2/S1)
P0136	O2 Sensor Circuit Malfunction (Bank 1 Sensor 2)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B1/S2)
P0156	O2 Sensor Circuit Malfunction (Bank 2 Sensor 2)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B2/S2)

DTC No.	Diagnostic items	Trouble Area (Check Point)
P0140	Downstream O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 2)	• Sensor deteriorated or contamination deposit
P0160	Downstream O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 2)	• Sensor deteriorated or contamination deposit
P0141	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B1/S2)
P0161	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 2)	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Malfunction of the sensor (B2/S2)
P0170	Fuel Trim Malfunction (Bank 1)	• Fuel system (Fuel tank/Press. regulator/Fuel pump/PCSV) • Connection of the fuel line hose/sealing/cut • Sealing between the purge valve and fuel tank • Air leak in the exhaust system • Ignition system • Engine
P0173	Fuel Trim Malfunction (Bank 2)	• Fuel system (Fuel tank/Press. regulator/Fuel pump/PCSV) • Connection of the fuel line hose/sealing/cut • Sealing between the purge valve and fuel tank • Air leak in the exhaust system • Ignition system • Engine
P0201	Cylinder 1 - Injector Circuit Malfunction	• Open or short between the injector and ECM • Bad connection of connectors/bad wiring • Bad No.1 injector
P0202	Cylinder 2 - Injector Circuit Malfunction	• Open or short between the injector and ECM • Bad connection of connectors/bad wiring • Bad No.2 injector
P0203	Cylinder 3 - Injector Circuit Malfunction	• Open or short between the injector and ECM • Bad connection of connectors/bad wiring • Bad No.3 injector
P0204	Cylinder 4 - Injector Circuit Malfunction	• Open or short between the injector and ECM • Bad connection of connectors/bad wiring • Bad No.4 injector
P0205	Cylinder 5 - Injector Circuit Malfunction	• Open or short between the injector and ECM • Bad connection of connectors/bad wiring • Bad No.5 injector
P0206	Cylinder 6 - Injector Circuit Malfunction	• Open or short between the injector and ECM • Bad connection of connectors/bad wiring • Bad No.6 injector
P0230	Fuel Pump Circuit Malfunction	• Open or short between the pump and ECM • Bad connection of connectors/bad wiring • Bad pump relay
P0301	Cylinder 1 - Misfire Detected	• Bad ignition system (Spark plug to ECM) • Check the injector #1 • Check the moving time of HLA plunger

DTC No.	Diagnostic items	Trouble Area (Check Point)
P0302	Cylinder 2 - Misfire Detected	• Bad ignition system (Spark plug to ECM) • Check the injector #2 • Check the moving time of HLA plunger
P0303	Cylinder 3 - Misfire Detected	• Bad ignition system (Spark plug to ECM) • Check the injector #3 • Check the moving time of HLA plunger
P0304	Cylinder 4 - Misfire Detected	• Bad ignition system (Spark plug to ECM) • Check the injector #4 • Check the moving time of HLA plunger
P0305	Cylinder 5 - Misfire Detected	• Bad ignition system (Spark plug to ECM) • Check the injector #5 • Check the moving time of HLA plunger
P0306	Cylinder 6 - Misfire Detected	• Bad ignition system (Spark plug to ECM) • Check the injector #6 • Check the moving time of HLA plunger
P0325	Knock Sensor 1 Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Bad knock sensor in bank 1
P0330	Knock Sensor 2 Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Bad knock sensor in bank 2
P0335	Crankshaft Position Sensor 'A' Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Bad CKP sensor
P0340	Camshaft Position Sensor (TDC Sensor) Circuit Malfunction	• Open or short between the sensor and ECM • Bad connection of connectors/bad wiring • Bad CMP sensor
P0350	Ignition Coil Primary/Secondary Circuit Malfunction	• Bad ignition system (Spark plug to ECM) • Bad connection of connectors/bad wiring
P0351	Ignition Coil 'A' Primary/Secondary Circuit Malfunction	• Bad ignition system (Spark plug to ECM) • Bad connection of connectors/bad wiring
P0352	Ignition Coil 'B' Primary/Secondary Circuit Malfunction	• Bad ignition system (Spark plug to ECM) • Bad connection of connectors/bad wiring
P0353	Ignition Coil 'C' Primary/Secondary Circuit Malfunction	• Bad ignition system (Spark plug to ECM) • Bad connection of connectors/bad wiring
P0354	Ignition Coil 'D' Primary/Secondary Circuit Malfunction	• Bad ignition system (Spark plug to ECM) • Bad connection of connectors/bad wiring
P0355	Ignition Coil 'E' Primary/Secondary Circuit Malfunction	• Bad ignition system (Spark plug to ECM) • Bad connection of connectors/bad wiring
P0356	Ignition Coil 'F' Primary/Secondary Circuit Malfunction	• Bad ignition system (Spark plug to ECM) • Bad connection of connectors/bad wiring
P0420	Catalyst System Efficiency Below Threshold (Bank 1)	• Catalytic converter melting/broken
P0430	Catalyst System Efficiency Below Threshold (Bank 2)	• Catalytic converter melting/broken



DTC No.	Diagnostic items	Trouble Area (Check Point)
P0443	Evap. Emission Control System - Purge Control Valve Circuit Malfunction	• Open or short between the PCSV and ECM • Bad connection of connectors/bad wiring • Bad PCSV
P0500	For OBD2 Rough Road Detection, Vehicle Speed Malfunction From ABS/TCS	• Open or short between the TCS or ABS and ECM • Check the connection of related parts • Check the open or short • Bad wheel sensor or TCS/ABS
	For OBD2 Rough Road Detection, Vehicle Speed Malfunction From Front Right Inductive Wheel Sensor	• Check the connection of related parts • Check the open or short • Bad wheel sensor
P0505	Idle Control System Malfunction (Mechanical Error)	• ISA stick in the open position
P0506	Idle Speed Control RPM Lower Than Expected	• Bad return spring of ISA or foreign material deposit
P0507	Idle Speed Control RPM Higher Than Expected	• Bad return spring of ISA or foreign material deposit
P1134	O2 Sensor circuit - Transition Switch Time Mulfuction/Slop (B1/S1)	• O2 sensor deteriorated or foreign material deposit
P1154	O2 Sensor circuit - Transition Switch Time Mulfuction/Slop (B2/S1)	• O2 sensor deteriorated or foreign material deposit
P1166	O2 Sensor - Controller Adaption diagnosis Malfunction (Bank 1)	• Fuel system (Fuel tank/Press. regulator/Fuel pump/PCSV) • Connection of the fuel line hose/sealing/cut • Sealing between the purge valve and fuel tank • Air leak in the exhaust system • Ignition system • Engine
P1167	O2 Sensor - Controller Adaption diagnosis Malfunction (Bank 2)	• Fuel system (Fuel tank/Press. regulator/Fuel pump/PCSV) • Connection of the fuel line hose/sealing/cut • Sealing between the purge valve and fuel tank • Air leak in the exhaust system • Ignition system • Engine
P1372	Segment Time Acquisition Incorrect	• Bad installation of target wheel in crankshaft • Bad signal of the CKP sensor • Bad connection of connectors/bad wiring
P1510	Idle Charge Actuator Command Signal Incorrect (Coil 1)	• Open or short between the ISA and ECM • Bad connection of connectors/bad wiring • Bad ISA
P1511	Idle Charge Actuator Command Signal Incorrect (Coil 2)	• Open or short between the ISA and ECM • Bad connection of connectors/bad wiring • Bad ISA
P1529	Customer Snapshot (MIL Request/ Freeze Frame) Request Via Can	• TCM error (check the TCM DTC)
P1602	Serial Communication Problem With TCU (Timeout)	• Open or short of CAN wire • Bad TCM

DTC No.	Diagnostic items	Trouble Area (Check Point)
P1616	Main Relay Malfunction	• Bad main relay • Open battery fuse • Bad connection of connectors/bad wiring
P1623	Diagnostic Lamp Powerstage Malfunction	• Open or short between the MIL lamp and ECM • Bad MIL lamp • Bad connection of connectors/bad wiring
P1624	Cooling Fan Relay - Circuit Malfunction ("LOW" Circuit)	• Open or short between the cooling fan and ECM • Bad main relay • Bad connection of connectors/bad wiring
P1625	Cooling Fan Relay - Circuit Malfunction ("HIGH" Circuit)	• Open or short between the cooling fan and ECM • Bad main relay • Bad connection of connectors/bad wiring



MFI COMPONENT INSPECTION EFHA0250

LOCATION OF MFI COMPONENTS

[2.0 I4]
















[2.7 V6]



- 1 Engine coolant temperature (ECT) sensor. (FL-36)
- 2 Manifold absolute (MAP) sensor. (FL-40)
- 3 Mass air flow sensor (Hot film sensor) (FL-43)
- 4 Intake air temperature (IAT) sensor (FL-40, 46)
- 5 Throttle position sensor (TPS) (FL-49)
- 6 Idle speed actuator (ISA) (FL-52)
- 7 Heated oxygen sensor (HO2S) (FL-55, 58)
- 8 Camshaft position sensor (CMP) (FL-61)
- 9 Crankshaft position sensor (CKP) (FL-65)
- 10 Injector (FL-69, 71)
- 11 Evap. canister purge control solenoid valve (PCSV) (FL-74)
- 12 Knock sensor (FL-77)
- 13 Power steering oil pressure switch (FL-80)

EFHA025B


ECT Sensor  EFA9025C	Power Steering Oil Pressure Switch  Power steering oil pressure switch EFA9025D
Vehicle Speed Sensor  Vehicle speed sensor EFA9025E	Ignition Timing Adjustment Terminal  HEW31002
EVAP Solenoid Valve  EFA9025G	MAP, TPS, ISA, TR  MAP TPS ISA TR EFA9025H
CMP Sensor  EFA9025I	CKP  EFA9025J

Data Link Connector  EFA9025K	Heated Oxygen Sensor (HO2S)  EFA9025L
Transaxle Range (TR) Switch  Battery Transaxle range (TR) switch EFA9025M	Injectors  Injector EFA9025N
Knock  EFA9025O	

ENGINE COOLANT TEMPERATURE (ECT) SENSOR


EFHA7030

The engine coolant temperature sensor installed in the engine coolant passage of the cylinder head detects the engine coolant temperature and emits signals to the ECM. This part employs a thermistor which is sensitive to changes in temperature. The electric resistance of the thermistor decreases in response to a temperature rise. The ECM determines engine coolant temperature by the sensor output voltage and provides optimum fuel enrichment when the engine is cold.



EFA9026A

CIRCUIT DIAGRAM



EFHA703A

SENSOR CHECKING


USING HI-SCAN

Check item	Data display	Check conditions	Intake air temperature	Test specification
Engine coolant temperature sensor	Sensor temperature	Ignition switch : ON or engine running	When -20°C (-4°F)	-20°C
			When 0°C (32°F)	0°C
			When 20°C (68°F)	20°C
			When 40°C (104°F)	40°C
			When 80°C (176°F)	80°C

USING MULTI-METER

1. Remove the engine coolant temperature sensor from the intake manifold.
2. With temperature sensing portion of engine coolant temperature sensor immersed in hot engine coolant, check resistance.

Temperature [°C (°F)]	Resistance (kΩ)
0 (32)	5.9
20 (68)	2.5
40 (104)	1.1
80 (176)	0.3



EFA9028A

3. If the resistance deviates from the standard value greatly, replace the sensor.

HARNESS INSPECTION

1

Harness side connector (H)

Check for continuity of the ground circuit.

- o Connector: Disconnected

OK → **2**

NG → Repair the harness.

EFHA703B

2

Harness side connector (H)

Measure the power supply voltage.


- o Connector: Disconnected
- o Ignition switch: ON
- o Voltage (V): 4.5-4.9V

OK → **END !**

NG → Repair the harness.

EFHA703C

TROUBLESHOOTING PROCEDURES



DTC : Diagnosis Trouble Code

ECM : Engine Control Module

ECT : Engine coolant Temperature

USING VOLTMETER

Check item	Coolant temperature	Test specification
Engine coolant temperature sensor output voltage	When 0°C	4.05V
	When 20°C	3.44V
	When 40°C	2.72V
	When 80°C	1.25V

TROUBLESHOOTING HINTS

If the fast idle speed is not enough or the engine gives off dark smoke during the warming-up of the engine, the engine coolant temperature sensor might be the cause.

INSTALLATION

1. Apply sealant LOCTITE 962T or the equivalent to threaded portion.
2. Install the engine coolant temperature sensor and tighten it to specified torque.

Tightening torque

Engine coolant temperature sensor :
20-40 Nm (200-400 kg.cm, 14-29 lb.ft)

3. Securely connect the harness connector.

MANIFOLD ABSOLUTE PRESSURE(MAP) & INTAKE AIR TEMPERATURE(IAT) SENSOR


EFHA7050

The manifold absolute pressure(MAP) sensor converts intake manifold pressure into a voltage signal. The engine control module(ECM) uses this signal to determine the condition of the engine load.

The intake air temperature(IAT) sensor, built in the MAP sensor, is a resistor-based sensor for detecting the intake air temperature.

According to the intake air temperature information from the sensor, the ECM provides necessary fuel injection amount control.


CIRCUIT DIAGRAM <2.0 I4>




EFHA705A

Check item	Data display	Check conditions	Engine state	Test specification
MAP sensor	Inlet manifold pressure	- Engine coolant temperature : 18°C (65.4°F) - Lamps, electric cooling fan, accessory units: All OFF - Transaxle: Neutral (P range for vehicle with A/T) - Steering wheel: Neutral	Idle	0.8-2.4V
			When the accel pedal is depressed suddenly at idle	Rise from 0.8-2.4V


HARNESS INSPECTION PROCEDURE

1  Harness side connector (A)	Measure the power supply voltage. - o Connector: Disconnected. - o Ignition switch : ON. - o Voltage (V) : 4.8-5.2 V.	OK → 2 NG → Repair the harness.
--	--	--

EFAA705B


2  Harness side connector (A)	Check for an open-circuit, or a short-circuit of ground between the engine control module and the mass air flow sensor. - o MAP sensor circuit : Disconnected - o Engine control module : Disconnected	OK → 3 NG → Repair the harness.
--	---	--

EFAA705C

3  Harness side connector (A)	Check for continuity of the ground circuit. o Connector : Disconnected.	OK → END ! NG → Repair the harness.
---	--	--

EFAA705D

TROUBLESHOOTING PROCEDURES [MAP SENSOR]



DTC : Diagnosis Trouble Code
ECM : Engine Control Module

EFAA705E

TROUBLESHOOTING HINTS

The MIL (Malfunction Indicator Lamp) is ON or the DTC (Diagnostic Trouble Code) is displayed on the HI-SCAN under the following conditions:

1. When the manifold pressure is 4.5V or more for 4 second.
2. When the manifold pressure is 0.2V or lower for 4 second.

SENSOR INSPECTION [MAP SENSOR]


1. Connect the voltmeter between 1 and 4 of the MAP sensor connector

Terminal 4 : MAP sensor ground

Terminal 1 : MAP sensor output

2. Measure the voltage of terminals.

Engine state	Test specification
Ignition SW. ON.	4 - 5V
At idle	0.8 - 2.4V




EFAA705F

3. If the voltage deviates from the standard value, replace the MAP sensor assembly.


MASS AIR FLOW (MAF) SENSOR

EFHA7090

This hot film type air flow sensor is composed of a hot film sensor, housing and metering duct (hybrid, sensor element). Mass air flow rate is measured by detection of heat transfer from a hot film probe because the change of the mass air flow rate causes change in the amount of heat being transferred from the hot film probe surface to the air flow. The air flow sensor generates a pulse so it repeatedly opens and closes between the 5V voltage supplied from the engine control module. This results in the change of the temperature of the hot film probe and in the change of resistance.




EFA9040A

CIRCUIT DIAGRAM <2.7 V6>

EFHA709A

TROUBLESHOOTING PROCEDURES



DTC : Diagnosis Trouble Code
ECM : Engine Control Module

EFAA709E

TROUBLESHOOTING HINTS


1. If the engine stalls occasionally, start the engine and shake the MAF sensor harness. If the engine stalls, check for poor contact at the MAF sensor connector.
2. If the MAF sensor output voltage is other than 0 when the ignition switch is turned on (do not start the engine). Check for the faulty MAF sensor or ECM.
3. If the engine can be idle even if the MAF sensor output voltage is out of specification, check for the following conditions;
 - Disturbed air flow in the MAF sensor, disconnected air duct, and clogged air cleaner filter.
 - Poor combustion in the cylinder, faulty ignition plug, ignition coil, injector, and incorrect comparison.
4. Even if no AFS malfunction occurs, check the mounting direction of the AFS.

Check item	Check condition	Test specification
Mass air flow sensor output voltage	Idle rpm	0.5V
	2000 rpm	1.0V


NOTE

1. When the vehicle is new [within initial operation of about 500 km (300 miles)], the mass air flow sensor air quantity will be about 10% higher.
2. Use an accurate digital voltmeter.
3. Before checking, warm up the engine until the engine coolant temperature reaches 80 to 90°C (176 to 198°F).


HARNESS INSPECTION PROCEDURE

1  Harness side connector (A)	Measure the power supply voltage. ○ Connector : Disconnected. ○ Ignition switch : ON. ○ Voltage (V) : Battery voltage. OK → 2 NG → Repair the harness
---	---

EFAA709B

2  Harness side connector (A)	Check for an open-circuit, or a short-circuit to ground between the engine control module and the mass air flow sensor. ○ Engine control module connector : Disconnected. ○ Mass air sensor connector : Disconnected. OK → 3 NG → Repair the harness
---	--

EFAA709C

3  Harness side connector (A)	Check for continuity of the ground circuit. ○ Connector : Disconnected. OK → END ! NG → Repair the harness
---	--

EFAA709D

INTAKE AIR TEMPERATURE (IAT) SENSOR

EFHA7110


The intake air temperature sensor (IAT Sensor), located in the intake air hose, is a resistor-based sensor for

detecting the intake air temperature. According to the intake air temperature information from the sensor, the ECM provides the necessary fuel injection.



CIRCUIT DIAGRAM

< 2.7 V6 >


IAT side connector



Harness side connector (A)



TROUBLESHOOTING PROCEDURES



DTC : Diagnosis Trouble Code
ECM : Engine Control Module

EFAA711D

TROUBLESHOOTING HINTS


The MIL is ON or the DTC is displayed on the HI-SCAN under the following condition:

1. When the intake air temperature is detected as below -40°C or higher than 120°C
2. Input from intake air temperature sensor is below 0.1V or above 4.8V when engine is in a full warm-up condition.


USING HI-SCAN

Check item	Data display	Check conditions	Intake air temperature	Test specification
Intake air temperature sensor	Air temperature	Ignition switch : ON or engine running	When -20°C (-4°F)	-20°C
			When 0°C (32°F)	0°C
			When 20°C (68°F)	20°C
			When 40°C (104°F)	40°C
			When 80°C (176°F)	80°C

HARNESS INSPECTION PROCEDURE <2.7 V6>

1  Harness side connector (A)	Measure the power supply voltage of the IAT Sensor. - o Connector : Disconnected. - o Ignition switch : ON. - o Voltage : 4.8-5.2 V. OK → NG →	2 Repair the harness.
--	---	---

EFAA711B

1  Harness side connector (A)	Check for an open-circuit, or a short-circuit to ground between the engine control module and the IAT sensor - o ECM connector : Disconnected - o IAT sensor connector : Disconnected OK → NG →	END ! Repair the harness.
--	---	--

EFAA711C

SENSOR INSPECTION

1. Using a multimeter, measure the sensor resistance.
2. Measure the resistance between the IAT sensor terminal 1 and 2.


IG.SW. ON	Temperature °C (°F)	Resistance (Ω)
	0 (32)	3.3 - 3.7V
	20 (68)	2.4 - 2.8V
	40 (104)	1.6 - 2.0V
	80 (176)	0.5 - 0.9V

3. If the resistance deviates from the standard value, replace the intake air temperature sensor assembly.

THROTTLE POSITION (TP) SENSOR

EFHA7130


The TPS is a variable resistor type that rotates with the throttle shaft of the throttle body to sense the throttle valve angle. As the throttle shaft rotates, the output voltage of the TP Sensor changes. The ECM detects the throttle valve opening based on voltage change.





EFA9049A

CIRCUIT DIAGRAM

< 2.7 V6 >



< 2.0 I4 >



EFHA713A

SENSOR CHECKING**USING HI-SCAN**


Check item	Data display	Check conditions	Throttle valve	Test specification
Throttle position sensor	Sensor voltage	Ignition switch : ON	At idle position	300-900 mV (2.0 I4) 250-800 mV (2.7 V6)
			Open slowly	Increases with valve opening
			Open widely	4,250-4,700 mV

USING VOLTMETER

1. Disconnect the throttle position sensor connector.
2. Measure resistance between terminal 1 (sensor ground) and terminal 2 (sensor power) for 2.0 I4, between terminal 2 (sensor ground) and terminal 1 (sensor power) for 2.7 V6.

Standard value : 3.5 - 6.5 k Ω

3. Connect a pointer type ohmmeter between terminal 1 (sensor ground) and terminal 3 (sensor output) for 2.0 I4 and between terminal 2 (sensor ground) and terminal 3 (sensor output) for 2.7 V6.




EFHA713E

4. Operate the throttle valve slowly from the idle position to the full open position and check that the resistance changes smoothly in proportion with the throttle valve opening angle.
5. If the resistance is out of specification, or fails to change smoothly, replace the throttle position sensor.


Tightening torque

TP Sensor : 1.5-2.5 Nm (15-25 kg.cm, 1.1-1.8 lb.ft)


HARNESS INSPECTION

1  2.0 I4 2.7 V6 Harness side connector (H)	Measure the power supply voltage of the throttle position sensor. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): 4.25-4.7 OK → 2 NG → Repair the harness.
---	---

EFHA713B

2  2.0 I4 2.7 V6 Harness side connector (B)	Check for continuity of the ground circuit. o Connector : Disconnected OK → 3 NG → Repair the harness.
---	--

EFHA713C

3  ECM harness side connect 2.0 I4 (A) 2.7 V6 (B) Harness side connector	Check for an open-circuit, or a short-circuit or ground between the engine control module and the throttle position sensor. - o Throttle position sensor sensor : Disconnected - o Engine control module connector : Disconnected OK → END ! NG → Repair the harness. A3-C21-3 (8) A3-C22-4 (14) B3-C74-3 (19)
---	--

EFHA713D

TROUBLESHOOTING HINTS


The TPS signal is important in the control of the automatic transaxle. Shift shock and other trouble will occur if the sensor is defective.

IDLE SPEED CONTROL ACTUATOR EFHA7170


The idle speed control actuator is the double coil type and has two coils. The two coils are driven by separate driver stages in the ECM. Depending on the pulse duty

factor, the equilibrium of the magnetic forces of the two coils will result in different angles of the motor. In parallel to the throttle valve, a bypass hose line is arranged, where the idle speed actuator is inserted in side.

CIRCUIT DIAGRAM



TROUBLESHOOTING PROCEDURES



DTC : Diagnosis Trouble Code
ECM : Engine Control Module

EFAA717E

TROUBLESHOOTING HINTS

The MIL is ON or the DTC is displayed on the HI-SCAN under the following conditions;


- When the primary voltage side in ECM is in short or open circuit.

- The ignition closed loop control in the ECM is out of order.
- Open or short circuit is observed in idle air control system when ignition switch is turned on.


USING HI-SCAN

Check item	Check condition	HI-SCAN display	Type
Idle speed control actuator o Actuator	Start the engine	ISA	Activate

HARNESS INSPECTION PROCEDURE

1  Harness side connector (A)	Measure the power supply voltage of the actuator. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): Battery voltage OK → NG →	2 Repair the harness. Check the power supply
--	---	--

EFHA717B

2  ECM harness side connector Harness side connector (A)	Check for an open-circuit, or a short-circuit to ground between the ECM and the idle speed control actuator. - o ECM connector : Disconnected - o Idle speed actuator connector : Disconnected OK → NG →	END ! Repair the harness. <CLOSING> A1-C21-1(28) A1-C22-1(17) A1-C74-3(47) <OPEN> A1-C21-1(14) A1-C22-1(4) A1-C74-3(46)
--	--	--

EFHA717C

ACTUATOR INSPECTION


1. Disconnect the connector at the idle speed control actuator.
2. Measure the resistance between terminals.

Standard value

Terminal 3 and 2 : 10.5 - 14Ω

Terminal 1 and 3 : 10 - 12.5Ω [at 20°C (68°F)]

3. Connector the connector to the idle speed control actuator




EFAA717D

HEATED OXYGEN SENSOR (HO2S) EFHA7190

The heated oxygen sensor senses the oxygen concentration in exhaust gas, converts it into a voltage, which is sent to the ECM. The oxygen sensor outputs about 1V when the air fuel ratio is richer than the theoretical ratio,

and outputs about 0V when the ratio is leaner (higher oxygen concentration in exhaust gas.). The ECM controls the fuel injection ratio based on this signal so that the air fuel ratio is maintained at the theoretical ratio. The oxygen sensor has a heating element which ensures the sensor performance during all driving conditions.

CIRCUIT DIAGRAM <2.0 I4>



1. If the HO2S is defective, abnormally high emissions may occur.
2. If the HO2S check results are normal, but the sensor output voltage is out of specification, check for the following items (related to air fuel ratio control system):
 - Defective injector
 - Air leaks in the intake manifold
 - Defective volume air flow sensor, intake air temperature sensor, barometric pressure sensor and engine coolant temperature sensor.

Check item	Check conditions	Engine state	Test specification
Oxygen sensor	Engine: Warm-up (make the mixture lean by engine speed reduction, and rich by racing)	When sudden deceleration from 4,000 rpm	200mV or lower
		When engine is suddenly raced	600-1,000 mV
	Engine: Warm-up (using the heated oxygen sensor signal, check the air/fuel mixture ratio, and also check the condition of control by the ECU)	Idle	400 mV or lower - (oscilate)
		2,000 rpm	600-1,000 mV


INSPECTION

NOTE

- Before checking, warm up the engine until the engine coolant temperature reaches 80 to 95°C (176 to 205°F).
 - Use an accurate digital voltmeter.
1. Disconnect the oxygen sensor connector, and measure the resistance between terminal 3 and terminal 4.


Standard value

Temperature °C (°F)	Resistance (Ω)
400 (752)	30 or more



EFAA719E

4. Connect a digital-type voltmeter between terminal 1 and terminal 2.



EFAA719F

5. While repeatedly racing the engine, measure the oxygen sensor output voltage.

Engine	Oxygen sensor output voltage	Resistance (Ω)
Race	Min. 0.6V	30 or more

6. If there is a problem, there may be an oxygen sensor malfunction.

Tightening torque


Heated oxygen sensor :

40-50 Nm (400-500 kg.cm, 29-36 lb.ft)


2. Replace the oxygen sensor if there is a malfunction.
3. Apply battery voltage directly between terminal 3 and terminal 4.

NOTE


Be careful when applying the voltage. Damage will result if the terminals are incorrect or are short circuited.




HARNESS INSPECTION PROCEDURES

1 Harness side connector (H) 	Measure the power supply voltage of the heated oxygen sensor. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): Battery voltage OK → NG →	2 Repair the harness.
---	---	--

EFHA719B

2  Harness side connector (H)	Check for open-circuit, or a short-circuit to ground between the ECM and the oxygen sensor. - o Oxygen sensor connector : Disconnected - o ECM connector : Disconnected OK → NG →	3 Repair the harness.
---	--	--

EFHA719C

3 Harness side connector (H) 	Check for continuity of the ground circuit. o Connector : Disconnected OK → NG →	END ! Repair the harness.
---	---	--

EFHA719D


HEATED OXYGEN SENSOR (HO2S) [2.7 V6]

EFHA7210

The heated oxygen sensor senses the oxygen concentration in exhaust gas and converts it into a voltage, which is sent to the ECM. The oxygen sensor outputs about 0V when the air fuel ratio is richer than the theo-

retical ratio, and outputs about 5V when the ratio is more lean (higher oxygen concentration in exhaust gas.). The ECM controls the fuel injection ratio based on this signal so that the air fuel ratio is maintained at the theoretical ratio. The oxygen sensor has a heating element which ensures the sensor performance during all driving conditions.

CIRCUIT DIAGRAM



EFHA721A

TROUBLESHOOTING HINTS

1. If the HO2S is defective, abnormally high emissions may occur.
2. If the HO2S check results were normal, but the sensor output voltage is out of specification, check for the following items (related to air fuel ratio control system):

- Defective injector
- Air leaks in the intake manifold.
- Defective air flow sensor, intake air temperature sensor, and engine coolant temperature sensor.

USING GST

Check Item	Check conditions	Engine state	Test specification
Oxygen sensor	Engine: Warm-up (make the mixture lean by engine speed reduction, and rich by racing)	When sudden deceleration from 4,000 rpm	300-900 mV
		When engine is suddenly raced	4000-4800 mV
	Engine: Warm-up (using the heated oxygen sensor signal, check the air/fuel mixture ratio, and also check the condition of control by the ECU)	At Idle rpm	300-4800 mV
		2,000 rpm	300-4800 mV

INSPECTION (USING VOLTMETER)

NOTE

Before checking, warm up the engine until the engine coolant temperature reaches 80 to 95°C (176 to 205°F).

1. Apply battery voltage directly between terminal 3 and terminal 4.

NOTE

Be careful when applying the voltage. Damage will result if the terminals are incorrect or are short circuited.

2. Connect a digital-type voltmeter between terminal 1 and terminal 2.
3. While repeatedly racing the engine, measure the oxygen sensor output voltage.

Engine	Oxygen sensor output voltage	Remarks
Race	4000-4800mV	Makes the air/fuel mixture rich by increasing engine speed


4. If there is a problem, there may be an oxygen sensor malfunction.

Tightening torque


Heated oxygen sensor :

40-50 Nm (400-500 kg·cm, 29-36 lb·ft)


HARNESS INSPECTION PROCEDURES

1 	Measure the power supply voltage of the heated oxygen sensor. - o Connector : Disconnected - o Ignition switch : ON - o Voltage (V) : Battery voltage	OK → 2 NG → Repair the harness.
---	--	--

EFHA721B

2 	Check for open-circuit, or a short-circuit to ground between the engine control module and the heated oxygen sensor. - o Heated oxygen sensor connector: Disconnected - o ECM connector : Disconnected	OK → 3 NG → Repair the harness.
---	--	--

EFHA721C

3 	Check for continuity of the ground circuit. o Connector : Disconnected	OK → END ! NG → Repair the harness.
--	---	--

EFHA721D


CAMSHAFT POSITION SENSOR EFHA7230

The CMP sensor senses the camshaft position sensor on, the compression stroke of the No.1 and No.4 cylinders,

ders, converts it into a pulse signal, and inputs it to the ECM. The ECM then computes the fuel injection sequence, etc. based on the input signal.


CIRCUIT DIAGRAM

<2.0 I4>



HARNESS INSPECTION PROCEDURE [2.0 I4]

1



Measure the power supply voltage.

- o Connector: Disconnected
- o Ignition switch: ON
- o Voltage (V): Battery voltage


OK →

2

NG → Repair the harness.

EFHA723B

2



Check for continuity of the ground circuit.

- o Connector : Disconnected


OK →

3

NG → Repair the harness.

EFHA723C

3



Check the signal voltage.

- o Connector: Disconnected
- o Ignition switch : ON
- o Voltage : 4.8-5.2 V

OK → **END !**


NG → Repair the harness.

EFHA723D


TROUBLESHOOTING HINTS

If the CMP Sensor does not operate correctly, correct sequential injection is not made so that the engine may stall or run irregularly at idle or fail to accelerate normally.


HARNESS INSPECTION PROCEDURE [2.7 V6]

1 	Measure the power supply voltage. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): Battery voltage	OK → 2 NG → Repair the harness.
--	---	--

EFAA723F

2 	Check for continuity of the ground circuit. o Connector : Disconnected	OK → 3 NG → Repair the harness.
--	---	--

EFHA723G

3 	Check the signal voltage. - o Connector : Disconnected - o Ignition ON - o Voltage : 4.8-5.2V	OK → END ! NG → Repair the harness.
--	--	--

EFHA723H

TROUBLESHOOTING HINTS

If the camshaft position sensor does not operate correctly, correct sequential injection is not made so that the engine may stall or run irregularly at idle or fail to accelerate normally.


CRANKSHAFT POSITION SENSOR EFHA7250

The crankshaft position sensor senses the crank angle (piston position) of each cylinder and converts it into a




pulse signal. Based on the input signal, the ECM computes the engine speed and controls the fuel injection timing and ignition timing.

CIRCUIT DIAGRAM**[2.0 I4]**

Crankshaft position
sensor side connector




Harness side connector (H)






<2.7 V6>

CMP Sensor side
connector



Harness side connector (H)



EFHA725B

TROUBLESHOOTING HINTS

- ## TROUBLESHOOTING HINTS
1. If unexpected shocks are felt during driving or the engine stalls suddenly, shake the crankshaft position sensor harness. If this causes the engine to stall, check for poor sensor connector contact.
 2. If the tachometer reads 0 rpm when the engine is cranked, check for faulty crank angle sensor, broken timing belt or ignition system problems.
 3. If the engine can be run at idle even if the crank angle sensor reading is out of specification, check the following:
 - Faulty engine coolant temperature sensor
 - Faulty idle speed control motor
 - Poorly adjusted reference idle speed


USING GST

Check Item	Check conditions	Check content	Normal state
Crankshaft position sensor	- Engine cranking - Tachometer connected (check on and off ignition coil by tachometer)	Compare cranking speed and multi-tester reading	Indicated speed agrees

Check Item	Check conditions	Coolant temperature	Test specification
Crankshaft position sensor	- Engine: Running at idle - Idle position switch: ON	When -20°C (-4°F)	1,500-1,700 rpm
		When 0°C (-32°F)	1,350-1,550 rpm
		When 20°C (-68°F)	1,200-1,400 rpm
		When 40°C (-104°F)	1,000-1,200 rpm
		When 80°C (-176°F)	Idle rpm

HARNESS INSPECTION PROCEDURE <2.0 I4>

1



Measure the power supply voltage.


- o Connector: Disconnected
- o Ignition switch: ON
- o Voltage (V): Battery voltage

OK → **2**

NG → Repair the harness.

EFAA725C

2



Check for continuity of the ground circuit.


- o Connector : Disconnected

OK → **3**

NG → Repair the harness.

EFAA725D

3



Check for continuity of the ground circuit.


- o Connector : Disconnected
- o Ignition switch : ON
- o Voltage : 4.8-5.2 V

OK → **END !**


NG → Repair the harness.

EFHA725E


HARNESS INSPECTION PROCEDURE <2.7 V6>

1  Harness side connector (H)	Measure the power supply voltage. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): Battery voltage	OK → 2 NG → Repair the harness.
--	---	--

EFAA725F

2  Harness side connector (H)	Check for continuity of the ground circuit. - o Connector : Disconnected - o Continuity	OK → 3 NG → Repair the harness.
--	--	--

EFHA725G


3  Harness side connector (H)	Check for continuity of the ground circuit. - o Connector : Disconnected - o Ignition switch : ON - o Voltage : 4.8-5.2 V	OK → END ! NG → Repair the harness.
---	--	--

EFHA725H


FUEL INJECTOR [2.0 I4] EFHA7270

injectors is determined by the time which the solenoid valve is energized.


The injectors inject fuel according to a signal coming from the ECM. The amount of fuel injected by the



HARNESS INSPECTION

1  Harness side connector (H)	Measure the power supply voltage. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): Battery voltage	2 OK → NG →
		Repair the harness.

EFAA727B

2  Harness side connector (A) ECM harness side connector (C21-1) ECM harness side connector (C22-1)	Check for an open-circuit, or a short-circuit to ground between the engine control module and the injector. - o ECM connector : Disconnected - o Injector connector : Disconnected	END ! OK → NG →
		Repair the harness.

EFHA727C


TROUBLESHOOTING HINTS

1. If the engine is hard to start when hot, check for fuel pressure and injector leaks.
2. If the injector does not operate when the engine is cranked, then check the followings:
 - Defective power supply circuit to the ECM, faulty ground circuit
 - Defective control relay
 - Defective crankshaft position (CKP) sensor, camshaft position (CMP) sensor
3. If there is any cylinder whose idle state remains unchanged when the fuel injection of injectors is cut one after another during idling, check for the following items about such a cylinder.
 - Injector and harness
 - Ignition plug and high tension cable
 - Compression pressure
4. If the injection system is ok but the injector drive time is out of specification, check for the following items.
 - Poor combustion in the cylinder (faulty ignition plug, ignition coil, compression pressure, etc.)
 - Loose EGR valve seating

FUEL INJECTOR [2.7 V6] EFHA7290

injectors is determined by the time during which the solenoid valve is energized.

The injectors inject fuel according to a signal coming from the ECM. The amount of fuel injected by the

CIRCUIT DIAGRAM

EFHA729A

INJECTOR CHECKING**USING HI-SCAN**

Check Item	Data display	Check conditions	Check content	Test specification
Injector	Drive time	Engine: Cranking	0°C (32°F)	Approx. 17 ms
			20°C (68°F)	Approx. 35 ms
			80°C (176°F)	Approx. 8.5 ms

Check Item	Data display	Check conditions	Engine state	Test specification
Injector	Drive time	- Engine coolant temperature: 80 to 95°C (176 to 205°F) - Lamps, electric cooling fan, accessory modules: All OFF - Transaxle: Neutral (P range for vehicle with A/T) - Steering wheel: Neutral	Idle rpm	2.2-2.9 ms
			2,000 rpm	1.8-2.6 ms
			Rapid racing	To increase

NOTE

1. The injector drive time is when the supply voltage is 11V and the cranking speed is less than 250 rpm.
2. When engine coolant temperature is lower than 0°C (32°F), the ECM fires all four cylinders simultaneously.
3. When the vehicle is new (within initial operation of about 500 km [300 miles]), the injector drive time may be about 10% longer.


Check Item	Item No.	Drive content	Check condition	Normal state
Injector • Actuator test	01	No. 1 injector shut off	Engine: Idling after warm-up (Shut off the injectors in sequence during and after engine warm-up; check the idle condition)	Idle should become unstable as injector shuts off.
	02	No. 2 injector shut off		
	03	No. 3 injector shut off		
	04	No. 4 injector shut off		
	05	No. 5 injector shut off		
	06	No. 6 injector shut off		

USING STETHOSCOPE AND VOLTMETER**Operation Sound Check**

1. Using a stethoscope, check the injectors for clicking sound at idle. Check that the sound is produced at shorter intervals as the engine speed increases.


NOTE

Ensure that the sound from an adjacent injector is not being transmitted along with the delivery pipe to an inoperative injector.



EFA9087A

2. If a stethoscope is not available, check the injector operation with your finger. If no vibration is felt, check the wiring connector, injector or injection signal from the ECM.




EFA9087B

Resistance Measurement Between Terminals

3. Disconnect the connector at the injector.
4. Measure the resistance between terminals.


Standard value : 13–16Ω[at20°C(68°F)]

5. Connect the connector to the injector.




EFA9087C

HARNESS INSPECTION

1  Harness side connector (H)	Measure the power supply voltage. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): Battery voltage OK → NG →	2 Repair the harness.
--	---	---

EFHA729B


2  Harness side connector (A)	Check for an open-circuit, or a short-circuit to ground between the engine control module and the injector. - o ECM connector : Disconnected - o Injector connector : Disconnected OK → NG →	END ! Repair the harness.
--	---	--

EFHA729C

EVAPORATIVE EMISSION CANISTER PURGE SOLENOID VALVE


EFHA7310

The evaporative emission canister purge solenoid valve is a duty control type, which controls purge air from the evaporative emission canister.




EFA9089A

CIRCUIT DIAGRAM



EFHA731A

TROUBLESHOOTING PROCEDURES




DTC : Diagnosis Trouble Code
ECM : Engine Control Module

EFAA731B


USING HI-SCAN

Check Item	Check conditions	HI-SCAN display	Type
Evaporative emission canister purge solenoid valve • Actuator test	IG. S/W ON (Do not start)	PCSV	Activate

HARNESS INSPECTION

1 	Measure the power supply voltage. - o Connector: Disconnected - o Ignition switch: ON - o Voltage (V): Battery voltage OK → NG →	2 Repair the harness.
--	---	---


EFHA731C

2 	Check for an open-circuit, or a short-circuit to ground between the evaporative emission canister purge solenoid valve and the engine control module. - o Engine control module connector : Disconnected - o Evaporative emission canister purge solenoid valve connector : Disconnected OK → NG →	END ! Repair the harness. H2-C21-1:34 H2-C22-1:9 H1-C74-3:42
--	---	--


EFHA731D

KNOCK SENSOR EFHA7330

The knock sensor is attached to the cylinder block and senses engine knocking conditions. A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is delivered as output. If engine knocking occurs, ignition timing is retarded to suppress it.




EFA9094A

CIRCUIT DIAGRAM

EFHA733A

TROUBLESHOOTING PROCEDURES



DTC : Diagnosis Trouble Code
ECM : Engine Control Module

EFAA733B

TROUBLESHOOTING HINTS

1. The MIL is ON or the DTC is displayed on the HI-SCAN under the following condition:
 - When the knock sensor signal is not detected, even though the engine is in the over load condition.
 - When knock sensor signal is abnormally low.

HARNESS INSPECTION PROCEDURE <2.7 V6>

1 ECM harness side connector Harness side connector (A) C74-3	Check for an open-circuit, or a short-circuit to ground between the ECM and the knock sensor - o ECM connector : Disconnected - o Knock sensor connector : Disconnected OK → 2 NG → Repair the harness. A1 - C74-3 : 30 A1 - C74-3 : 32
--	--

EFHA733C

2 ECM harness side connector Harness side connector (A) C74-3	Check for continuity of the ground circuit - o ECM Connector : Disconnected - o Knock sensor connector : Disconnected OK → 3 NG → Repair the harness.
--	--

EFHA733D

3 Harness side connector (A)	Check for continuity of the ground circuit o Continuity OK → END ! NG → Repair the harness.
---	---

EFHA733F

SENSOR INSPECTION

1. Disconnect the knock sensor connector.
2. Measure resistance between the terminal 2 and 3.


Standard value : about 5MΩ [at 20°C (68°F)]

3. If the resistance is continual, replace the knock sensor.

Knock sensor :
16-28Nm (160-250 kg·cm, 11.8-18.4 lb·ft)

4. Measure the capacitance between the terminal 2 and 3.


Standard value : 800-1600 pF



EFHA733E


POWER STEERING PRESSURE SWITCH EFHA7350

The power steering oil pressure switch senses the power steering load into low/high voltage and inputs it to ECM, which then controls the idle speed control motor based on this signal.



EFHA9103A

CIRCUIT DIAGRAM




EFHA735A

USING HI-SCAN

Check item	Data display	Check conditions	Steering wheel	Normal indication
Power steering oil pressure switch	Switch state	Engine : Idling	Steering wheel neutral position (wheels straightahead direction)	OFF
			Steering wheel half turn	ON

HARNESS INSPECTION

1	 Harness side connector (H)	Measure the power supply voltage. - o Connector: Disconnect - o Ignition switch: ON - o Voltage (V): Battery voltage	OK → END ! NG → Repair the harness.
---	---	---	--


THROTTLE POSITION SENSOR(TPS) ADJUSTMENT

EFHA1060

1. Connect a HI-SCAN to the data link connector.


NOTE

Before adjusting the TPS, complete the basic idle speed adjustment.



EFA9100A

2. If a HI-SCAN is not used, connect a digital type voltmeter between ground and TPS input terminal.



EFA9106A

3. Turn the ignition switch to the ON position(do not start engine) and check that TPS output voltage is as specified. If a HI-SCAN is used, read the TPS voltage.

Standard value :

300-900mV (2.0 I4)

250-800mV (2.7 V6)

4. If it is out of specification, loosen TPS mounting screw and adjust by turning TPS.


NOTE

1. Turning the TPS clockwise increases the output voltage.
2. Tighten the screws securely after adjustment.
5. Turn the ignition switch to the OFF position.

FUEL SENDER REPLACEMENT


EFHA1070

1. Remove the fuel tank cap to lower the fuel tank's internal pressure.
2. Raise the vehicle and disconnect the fuel pump connector, remove the fuel feed and return line from the fuel pump assembly.



EFHA006B

3. Remove the fuel pump installation screws, then remove the fuel pump assembly from the fuel tank.
4. Remove the fuel sender from the fuel pump assembly.
5. Inspect and replace, if necessary.



EFHA006A

FUEL PUMP OPERATION CHECK


EFHA1080

1. Turn the ignition switch to the OFF position.
2. Apply battery voltage to the fuel pump drive connector to check that the pump operates.


NOTE

The fuel pump is an in-tank type and its operating sound is hard to hear without removing the fuel tank cap.

3. Pinch the hose to check that fuel pressure is felt.



EFA9108A



EFA9115A


EVAP CANISTER PURGE PORT VACUUM CHECK

EFHA1090


CHECKING CONDITION

Engine coolant temperature : 80-95°C (176-205°F)

1. Disconnect the vacuum hose from the throttle body EVAP Canister purge hose fitting and connect a vacuum pump.



EFA9109A




EFA9113A

2. Start the engine and check to see that, after increasing the engine speed, vacuum raises fairly constant.

NOTE

If there is no vacuum created, it is possible that the throttle body port may be restricted and may require cleaning.




EFA9109B

FUEL PRESSURE TEST

EFHA1100

1. Reduce the internal pressure of the fuel pipes and hoses by the following procedures:
 - Open the trunk door and disconnect the fuel pump harness connector.
 - Start the engine and after it stalls, turn the ignition switch to the OFF position.
 - Disconnect the battery negative (-) terminal.
 - Connect the fuel pump harness connector.



EFHA006B


2. Remove the bolt connecting the fuel line to the fuel delivery pipe.

CAUTION


Cover the hose connection with a shop towel to prevent splashing of fuel caused by fuel residual pressure in the fuel line.

3. Using the fuel pressure gauge adapter, install the fuel-pressure gauge to the fuel pressure gauge adaptor. Tighten the bolt to the specified torque.

Fuel pressure gauge to fuel delivery pipe
25-35 Nm (250-350 kg·cm, 18-26 lb·ft)



EFA9110A




EFA9116B


7. Disconnect the vacuum hose from the pressure regulator, and plug the hose end. Measure the fuel pressure at idle.

Standard value :

320-340 kPa (3.26-3.47 kg/cm², 46-49 psi)



EFA9110B




EFA9116C

8. Measure the fuel pressure when the vacuum hose is connected to the pressure regulator.

Standard value :


Approx.255 kPa (2.57 kg/cm², 37 psi)

9. If the results of the measurements made in steps (7) and (8) are not within the standard value, use the table below to determine the probable cause, and make the necessary repairs.



EFA9110A

4. Connect the battery's negative (-) terminal.
5. Apply battery voltage to the terminal for the pump drive and activate the fuel pump: then, with fuel pressure applied, check that there is no fuel leakage from the pressure gauge or connection part.
6. Start and run the engine at curb idle speed.



EFA9116B

Condition	Probable cause	Remedy
Fuel pressure is too low	• Clogged fuel filter • Fuel leakage to the return side, caused by poor seating of the fuel-pressure regulator	• Replace fuel filter • Replace fuel pressure regulator
	• Low discharge pressure of the fuel pump	• Check the in-tank fuel hose for kink or replace the fuel pump
Fuel pressure is too high	• Sticking fuel-pressure regulator • Clogged or bent fuel return hose or pipe	• Replace fuel pressure regulator • Repair or replace hose or pipe
There is no difference in fuel pressure when the vacuum hose is connected and when it is not.	• Clogging, or damaged vacuum hose or the nipple • Sticking or poor seating of the fuel pressure regulator	• Repair or replace the vacuum hose or the nipple • Repair or replace hose or pipe

10. Stop the engine and check for a change in the fuel pressure gauge reading, which should hold for approximately 5 minutes. If the gauge indication

drops, observe the rate at which it drops. Determine and remove the causes according to the following table.

Condition	Probable cause	Remedy
Fuel pressure drops slowly after engine is stopped	• Injector leakage	• Replace injector
Fuel pressure drops immediately after engine is stopped	• The check valve within the fuel pump is open	• Replace fuel pump

11. Reduce the pressure in the fuel line.

12. Disconnect the hose and the gauge.

CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by fuel residual pressure in the fuel line.

13. Replace the O-ring of the end of the hose.

14. Connect the fuel hose to the delivery pipe and tighten with the specified.


15. Check for fuel leakage.

FUEL FILTER REPLACEMENT EFHA1110

1. Reduce the internal pressure of the fuel lines and hoses and perform the following operations.
 - Disconnect the fuel pump harness connector in the trunk room.
 - Start the engine and, after it stops, turn the ignition switch to OFF.
 - Disconnect the battery negative (-) terminal.
 - Connect the fuel pump harness connector.
2. Remove the two fitting nuts while holding the fuel filter nuts securely.
3. Remove the fuel filter mounting bolts, and then remove the fuel filter from the fuel filter clamp.

Tightening torque

Fuel filter fitting nut :
25-35 Nm (250-350 kg·cm, 18-25 lb·ft)



EFHA006B

THROTTLE BODY CLEANING EFA91120


NOTE

Disconnect the intake air hose from the throttle body, and check the throttle valve surface for carbon deposits. Spray cleaning solvent on the valve to remove carbon deposits.

1. Warm up the engine, then stop it.
2. Remove the intake air hose from the throttle body.
3. Plug the bypass passage inlet of the throttle body.


NOTE

Make sure the solvent does not enter the by-pass passage.



EFA9112A

4. Spray cleaning solvent into the valve through the throttle body intake port and let it soak for about 5 minutes.
5. Start the engine, race it several times and allow the engine to idle for 1 minute.
6. Repeat Steps 4 and 5.
7. Unplug the bypass passage inlet.
8. Attach the intake air hose.
9. Disconnect the battery ground cable for more than 10 seconds.
10. Adjust the SAS (Speed Adjusting Screw).




EFA9112B

FUEL DELIVERY SYSTEM

ACCELERATOR PEDAL EFA91190


COMPONENTS



TORQUE : Nm (Kg-cm, lb-ft)

COMPONENTS

EFA91200




EFA9120A


REMOVAL

EFA91220

1. Remove the bushing and inner cable of the accelerator arm.
2. Pull the left side of the accelerator pedal toward you, and then remove the accelerator pedal from the accelerator arm.



EFA9122A



EFA9122B

INSPECTION

EFA91230


3. Loosen the bolts of the accelerator arm bracket and remove.

1. Check the inner and outer cable for damage.
2. Check the cable for smooth movement.
3. Check the accelerator arm for deformation.
4. Check the return spring for deterioration.

5. Check the connection of the bushing to end metal fitting.
6. Check the accelerator for proper operation.

INSTALLATION EFA91240

1. When installing the return spring and accelerator arm, apply multi-purpose grease around each moving point of the accelerator arm.




EFA9124A

2. Apply sealant to the bolt mounting hole and tighten the accelerator arm bracket.


Tightening torque

Accelerator arm bracket bolts :
8–12 Nm(80–120 kg·cm, 6–7 lb·ft)



EFA9124B

3. Securely install the resin bushing of the accelerator cable on the end of the accelerator arm.



EFA9124C


FUEL INJECTOR EFA91260

INSPECTION

1. Measure the resistance of the injectors between the terminals using an ohmmeter.

Resistance : 13–16Ω[at 20°C (68°F)]

2. If the resistance is not within specification, replace the injector.




EFA9126A

FUEL LINE EFHA1270

COMPONENTS


<2.0 I4>



TORQUE : Nm (kg·cm, lb·ft)

COMPONENTS EFHA1280

<2.7 V6>



TORQUE : Nm (kg·cm, lb·ft)

REMOVAL EFA91290

1. Release residual pressure from the fuel line to prevent fuel from spilling.


CAUTION

Cover the hose connection with rags to prevent splashing of fuel that could be caused by residual pressure in the fuel line.

2. Remove the delivery pipe with the fuel injector and pressure regulator.

INSTALLATION EFA91300

1. Install a new grommet and O-ring to the injector.
2. Apply a coating of solvent, spindle oil or gasoline to the injector O-ring.




EFA9130A

3. While turning the injector left and right, install it on to the delivery pipe.
4. Be sure the injector turns smoothly.

NOTE


If injector does not turn smoothly, the O-ring may be jammed. Remove the injector and re-insert it into the delivery pipe and re-check.



EFA9130B

FUEL LINE AND VAPOR LINE EFHA1310

COMPONENTS




EFHA131A

REMOVAL EFHA1320

1. Raise the vehicle and remove the two fitting nuts while holding the fuel filter nut securely.

CAUTION

1. Reduce the fuel pressure before disconnecting the fuel line and hose, or fuel will spill out.
2. Cover the pipe connection with a shop towel to prevent splashing of fuel that could be caused by residual pressure in the fuel line.



EFHA006B


2. Remove the fuel filter mounting bolts, then remove the fuel filter from the bracket.
3. Remove the fuel return hose and line.
4. Remove the fuel vapor hose and line

INSPECTION EFA91330

1. Check the hoses and pipes for cracking, bending, deformation or restrictions.
2. Check the EVAP Canister for restrictions.
3. Check the fuel filter for restrictions and damage.

INSTALLATION EFHA1340

1. Install the fuel vapor hose and return hoses.
 - If the fuel line has a stepped section, connect the fuel hose to the line securely, as shown in the illustration.
 - If the fuel line does not have a stepped section, connect the fuel hose to the line securely.



EFA9134A


2. Install the fuel filter and tighten the fuel filter bracket.
3. Tighten the two fitting nuts while holding the fuel filter nuts.

Tightening torque

Fuel filter fitting nuts :

30–40 Nm(300–400 kg·cm, 22.1–29.5 lb·ft)


4. Install the clips and make sure that they do not interfere with other components.




EFHA006B

FUEL TANK EFHA1350

COMPONENTS



EFHA131A



EFHA131B


EFHA135A

REMOVAL EFHA1360

1. To reduce the internal pressure of the fuel main pipes and hose, first start the engine and then disconnect the electrical fuel pump connector located near the fuel filter.


CAUTION

Be sure to reduce the fuel pressure before disconnecting the fuel main pipe and hose otherwise fuel will spill out.




EFAH006B

2. Disconnect the battery cable from the negative terminal of the battery.




EFA9136A

3. Remove the fuel tank cap.
4. Disconnect the return hose and vapor hose.




EFHA136C

5. Disconnect the fuel sender connector.
6. Disconnect the high pressure hose from the fuel tank.




EFHA136C

7. Loosen the two self-locking nuts that hold the tank in position and remove the two tank bands.



EFA9136D

8. Detach the fuel filler hose and leveling hose.
9. Remove the fuel vapor hose and the fuel tank.




EFA9136E

INSPECTION EFA91370

1. Check the hoses and the pipes for cracks or damage.
2. Check the fuel tank cap for proper operation.
3. Check the fuel tank for deformation, corrosion or cracking.
4. Check the fuel tank inside for dirt or contamination.
5. Check the in-tank fuel filter for damage or restriction.
6. Test the two-way valve for proper operation.

7. Using a vacuum hand pump, check the operation of the two-way valve.

Valve pump	Guide lines for acceptance or rejection
When connected to inlet side	Negative pressure generated and vacuum maintained
When connected to outlet side	No negative pressure generated




EFA9137A

INSTALLATION


EFHA1380

1. Connect the leveling hose to the tank at approximately 40 mm (1.6 in.) of the filler neck.
2. When connecting the filler hose, connect the end with the shorter straight pipe to the tank side.




EFA9138A

3. Confirm that the pad is fully bonded to the fuel tank. Install the fuel tank by tightening the self-locking nuts to the tank bands until the rear end of the tank band contacts the body.



EFA9138B

4. Connect the vapor hose and return hose. Attach the fuel hose to the line as shown in the illustration.



EFA9138C


5. To connect the high pressure hose to the fuel pump, temporarily tighten the flare nut by hand, and then tighten it to the specified torque. Be careful that the fuel hose does not twist.

Tightening torque

High pressure hose flare nut :
30–40 Nm(300–400 kg·cm, 22–29 lb·ft)


NOTE

When tightening the flare nut, be careful not to bend or twist the line to prevent damage to the fuel pump connection.



EFA9138D

6. Connect the electrical fuel pump and fuel sender connector.



EFHA006B

TROUBLESHOOTING FOR DTC

EFHA5010

DIAGNOSTIC ITEM

DTC	Diagnostic item
P0105	Manifold Absolute Pressure Sensor Circuit Malfunction


DESCRIPTION

The MAP sensor is essentially a strain gauge used to measure the pressure in the surge tank. Inside the sensor is a metal diaphragm with a small wire attached. The diaphragm flexes according to changes in pressure. When the diaphragm flexes, the wire attached to it stretches, changing the resistance of the wire. The Engine Control Module (ECM) applies five volts to the MAP sensor and measures the voltage drop across the sensor. The sensor output is in volts and as pressure decreases, the voltage drop across the sensor increases. Since the MAP sensor is used as an air flow sensor, the sensor signal is an important input. The ECM uses the information to determine fuel amount and ignition timing.

TROUBLESHOOTING GUIDE


DTC detection condition	Probable cause
Background - The MAP sensor outputs a voltage which corresponds to the pressure of surge tank. - The Engine Control Module checks whether this voltage is within a specified range. Check Area - Ignition switch : ON - Sixty seconds or more have passed since the starting sequence was completed. - Battery voltage is 8V or more. Judgment Criteria - Sensor output voltage has continued to be 4.5V or higher [corresponding to a surge tank pressure of 114 kPa(17psi) or higher] for 4 sec. - Sensor output voltage has continued to be 1.95V or lower [corresponding to a surge tank pressure of 50 kPa(7.4 psi) or lower] for 4 sec.	- MAP sensor failed - Open or shorted MAP sensor circuit, or loose connector - Engine control module failed

CIRCUIT DIAGRAM



HP0105A

TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE



Turn ignition off.
Disconnect MAP & IAT sensor.
Measure resistance between ground and MAP & IAT
sensor.
Resistance should be approximately 1 ohm or less, is it?

YES

Replace MAP & IAT sensor.
Clear code and verify MAP & IAT
sensor is within normal parameters.

NO

Repair open in wire between MAP & IAT sensor harness
connector terminal 4 and ECM terminal C21-2:17(A/T) or
ECM terminal C22-4:22(M/T). Clear code and verify MAP
sensor is within normal parameters.

HP0105C

EFHA5020


DTC	Diagnostic item
P0110	Intake Air temperature Circuit Malfunction

DESCRIPTION

The Intake Air Temperature (IAT) sensor is in the MAP sensor. The IAT sensor is a variable resistor whose resistance changes as the temperature of the air flowing through the air intake changes. The Engine Control Module (ECM) uses the IAT sensor input to adjust fuel injector pulse width. When the temperature sensed is cold, the ECM enriches fuel mixture by increasing injector pulse width; as the air warms, the injector pulse width time is shortened.


TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - The intake air temperature sensor converts the intake air temperature to a voltage and outputs it. - The engine control module checks whether the voltage is within a specified range. Check Area - Sixty seconds or more have passed since the starting sequence was completed. Judgment Criteria - Sensor output voltage has continued to be 4.6V or higher [corresponding to an intake air temperature of -45°C (-49°F) or lower] for 4 sec. - Sensor output voltage has continued to be 0.2V or lower [corresponding to an intake air temperature of 125°C (257°F) or higher] for 4 sec.	- MAP sensor failed - Open or shorted mass air flow sensor circuit, or loose connector - Engine control module failed

CIRCUIT DIAGRAM

HP0105A

TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE

- Turn ignition off.
- Disconnect MAP & IAT sensor.
- Measure resistance between ground and MAP & IAT sensor harness connector terminal 4. Resistance should be approximately 1 ohm or less, is it?

YES

Replace MAP & IAT sensor.
Clear codes and verify IAT sensor
is within normal parameters.

NO

Repair open in wire between MAP
& IAT sensor harness connector
terminal 4 and ECM. Clear codes
and verify IAT sensor is within
normal parameters.

CONTINUED FROM
PREVIOUS PAGE

- MAP & IAT sensor disconnected.
- Turn ignition off.
- A/T: Disconnect ECM connector C21-2.
- M/T: Disconnect ECM connector C22-4.
- Measure resistance between ground and MAP & IAT sensor harness connector terminal 4. Resistance should indicate open circuit, does it?

NO

Repair short to ground in wire
between MAP & IAT sensor
harness connector terminal 4 and
ECM. Clear code and verify IAT
sensor is within normal
parameters.

YES

Verify ECM connectors are secure.
If OK, replace MAP & IAT sensor.
Clear code and verify IAT sensor
is within normal parameters.
If problem persists, replace ECM.

CONTINUED FROM
PREVIOUS PAGE

- MAP & IAT sensor disconnected.
- Turn ignition off.
- A/T: Disconnect ECM connector C21-2.
- M/T: Disconnect ECM connector C22-4.
- Ground MAP & IAT sensor harness connector terminal 4.
- A/T: Measure resistance between ground and ECM connector C21-2 terminal 24.
- M/T: Measure resistance between ground and ECM connector C22-4 terminal 2. Resistance should be approximately 1 ohm or less, is it?

YES

Repair open in wire between MAP
& IAT sensor harness connector
terminal 4 and ECM. Clear code
and verify IAT sensor is within
normal parameters.

NO

EFHA5030

DTC	Diagnostic item
P0115	Engine Coolant Temperature Circuit Malfunction


DESCRIPTION

The Engine Coolant Temperature (ECT) sensor is located in the coolant passage of the cylinder head. The ECT sensor is a variable resistor whose resistance changes as the temperature of the engine coolant flowing past the sensor changes. When the coolant temperature is low, the sensor resistance is high; when the coolant temperature is high, the sensor resistance is low. The Engine Control Module (ECM) checks ECT voltage fifty times per second and uses the information to adjust the fuel injector pulse width and ignition timing. When the temperature sensed is very cold, the ECM enriches the fuel mixture.

TROUBLESHOOTING GUIDE


DTC detection condition	Probable cause
Background - The engine coolant temperature sensor converts the engine coolant temperature to a voltage and outputs it. - The Engine Control Module checks whether the voltage is within a specified range. In addition, it checks that the engine coolant temperature (signal) does not drop while the engine is warming up. Check Area, Judgment Criteria - Sensor output voltage has continued to be 4.6V or higher [corresponding to a coolant temperature of -45°C (-49°F) or lower] for 4 sec. - Sensor output voltage has continued to be 0.1V or lower [corresponding to a coolant temperature of 140°C (284°F) or higher] for 4 sec. Check Area, Judgment Criteria - Sensor output voltage increased from a value lower than 1.6V to a value higher than 1.6V [Coolant temperature decreases from a higher than 40°C (104°F) temperature to a lower than 40°C (104°F) temperature.]. - Then the sensor output voltage has continued to be 1.6V or higher for 5 min. Check Area - The Engine Coolant Temperature is approx. 40°C (104°F) or less after starting sequence is completed. Judgment Criteria - Approx. 60 - 300 seconds have passed for the engine coolant temperature to rise to about 40°C (104°F) after starting sequence was completed.	- Engine Coolant Temperature sensor failed. - Open or shorted Engine Coolant Temperature sensor circuit, or loose connector. - Engine Control Module failed.

CIRCUIT DIAGRAM



HP0115A

TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE



- Turn ignition off.
 - ECT sensor disconnected.
 - A/T: Disconnect ECM connector C21-2.
 - M/T: Disconnect ECM connector C22-4.
 - A/T: Measure resistance between ground and ECM harness connector C21-2 terminal 4.
 - M/T: Measure resistance between ground and ECM harness connector C22-4 terminal 13.
- Resistance should indicate open circuit, does it?

YES

NO

A/T: Repair short to ground in wire between ECT sensor harness connector terminal 3 and ECM harness connector C21-2 terminal 4.
M/T: Repair short to ground in wire between ECT sensor harness connector terminal 3 and ECM harness connector C22-4 terminal 13.
Clear code and verify ECT sensor is within normal parameters.

- Turn ignition off.
 - ECT sensor disconnected.
 - A/T: Disconnect ECM connector C21-2.
 - M/T: Disconnect ECM connector C22-4.
- Measure resistance between ground and ECT sensor harness connector terminal 1.
Resistance should indicate open circuit, does it?

YES

NO

Verify ECM connector is secure.
Replace ECT sensor with known good component. If problem persists, replace ECM. Clear code and verify ECT sensor is within normal parameters.

A/T: Repair open in wire between ECT sensor harness connector terminal 1 and ECM harness connector C21-2 terminal 4.
M/T: Repair open in wire between ECT sensor harness connector terminal 1 and ECM harness connector C22-4 terminal 13.
Clear code and verify ECT sensor is within normal parameters.

EFHA5040


DTC	Diagnostic item
P0120	Throttle Position Circuit Malfunction

DESCRIPTION


The throttle position (TP) sensor mounts on the side of the throttle body and is connected to the throttle blade shaft. The TP sensor is a variable resistor (potentiometer) whose resistance changes according to the throttle blade shaft position. During acceleration, the TP sensor resistance decreases; during deceleration, the TP sensor resistance increases. The TP sensor also includes an idle position switch. The switch is closed in the idle position. The Engine Control Module (ECM) applies a reference voltage to the TP sensor and then measures the voltage that is present on the TP sensor signal circuit. The ECM uses the TP sensor signal to adjust the timing and injector pulse width. The TP sensor signal along with the MAP sensor signal is used by the ECM to calculate the engine load.

TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - The Throttle Position sensor outputs a voltage which is proportional to the throttle valve opening angle. - The Engine Control Module checks whether the voltage output by the throttle position sensor is within a specified range. In addition, it checks that the voltage output does not become too large while the engine is idling. Check Area, Judgment Criteria - With the close Throttle Position switch set to ON, the sensor output voltage has continued to be 2V or higher for 4 sec. - Sensor output voltage has continued to be 0.2V or lower for 4 sec. Check Area - Engine speed is between 500 and 3,000 r/min. - Engine load is lower than 30%. Judgment Criteria - Sensor output voltage has continued to be 4.6V or higher for 4 sec.	- Throttle Position sensor failed or maladjusted. - Open or shorted Throttle Position sensor circuit, or loose connector. - Closed Throttle Position switch ON malfunction. - Closed Throttle Position switch signal wire shorted. - Engine control module failed.

CIRCUIT DIAGRAM

TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE

B

- Turn ignition off.
 - Disconnect TP sensor.
 - Turn ignition on.
 - Using voltmeter, measure voltage between ground and TP sensor harness connector terminal 2.
- 5 volts should be present, is it?

YES

- Ignition on, engine off.
 - TP sensor disconnected.
 - Measure resistance between ground and TP sensor harness connector terminal 1.
- Resistance should be approximately 1 ohm or less, is it?

YES

- Ignition on, engine off.
 - TP sensor disconnected.
 - Connect fused jumper across TP sensor harness connector terminals 1 and 2.
 - Using scan tool, observe TP sensor's output voltage.
- Voltage should be above 4.8 volts, is it?

NO

- Ignition off.
 - TP sensor disconnected.
 - Fused jumper in place.
 - ECM connected.
 - A/T: Measure voltage (backprobe) between ground and ECM connector C21-2 terminal 6.
 - M/T: Measure voltage (backprobe) between ground and ECM connector C22-4 terminal 11.
- 5 volts should be present, is it?

D

CONTINUED ON
NEXT PAGE

NO


A/T: Repair open in wire between TP sensor harness connector terminal 2 and ECM harness connector C21-2 terminal 6.
M/T: Repair short to voltage in wire between TP sensor harness connector terminal 2 and ECM harness connector C22-4 terminal 11.
Clear code and verify TP sensor is within normal parameters

NO

A/T: Repair poor ground or open in wire between TP sensor harness connector terminal 1 and ECM harness connector C21-3 terminal 17.
M/T: Repair poor ground or open in wire between TP sensor harness connector terminal 4 and ECM harness C22-4 terminal 13.
Clear code and verify TP sensor is within normal parameters.

YES

Replace TP sensor.
Clear code and verify TP sensor is within normal parameters.



EFHA5060

DTC	Diagnostic item
P0130, P0133	Oxygen Sensor Circuit Malfunction (Bank 1, sensor 1)


DESCRIPTION

Refer to excessive time to enter closed loop fuel control (P0134).

TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - When the heated oxygen sensor begins to deteriorate, the oxygen sensor signal response becomes poor. - The Engine Control Module forcibly varies the air/fuel mixture to make it leaner and richer and checks the response speed of the heated oxygen sensor. In addition, the Engine Control Module also checks for an open circuit in the heated oxygen sensor output line. Check Area - Coolant temperature sensor: Normal. - Heated oxygen sensor signal voltage has continued to be 0.1V or lower for 3 min. or more after the starting sequence was completed. - Engine Coolant Temperature is higher than 80°C (176°F). - Engine speed is higher than 1,200 r/min. - Engine load is 25% or more. Judgment Criteria - Input voltage supplied to the engine control module interface circuit is 4.5V or more when 5V is applied to the heated oxygen sensor output line via a resistor. Check Area - Coolant temperature sensor: Normal. - Engine Coolant Temperature is 50°C (122°F) or more. - Engine speed is between 1,500 and 3,000 r/min or 1,100 and 3,000 r/min. - Engine load is 25 - 60%. - Intake air temperature is -10°C (14°F) or more. - Under the closed loop air-fuel control. - Monitoring Time: 8sec. Judgment Criteria - When the air-fuel ratio is forcibly changed (lean to rich and rich to lean), the heated oxygen sensor signal doesn't provide response within 1.28 sec. - Monitored only once per trip.	- Heated oxygen sensor deteriorated - Open circuit in heated oxygen sensor output line - Engine control module failed

CIRCUIT DIAGRAM



◁ D : To Joint connector (refer to ETM)

TEST PROCEDURE

- Turn ignition switch on.
 - Connect scan tool to data link connector.
 - Verify DTC P0130 or P0133 is set.
- Are other DTCs also set?

NO

YES

- Start engine and warm it to normal operating temperature.
 - Turn on air conditioning (if equipped).
 - Increase engine speed to 4000 RPM and, using scan tool, monitor oxygen sensor voltage.
- Voltage should vary between 0 and 900mV, does it?

Repair conditions that caused other DTCs to set. Refer to DTC test procedures.

No, voltage is constant and the reading is between 19 and 58mV.

No, voltage is constant and approximately 5 or 12 volts.

Repair short to voltage in wiring harness. Clear code and verify oxygen sensor is within normal parameters.

No, 0 volts present.

No, voltage varies but stays below 500mV (lean).

No, voltage varies but stays above 500mV (rich).

Yes, voltage varies between 100 and 900mV.

B

C

CONTINUED ON
NEXT PAGE

CONTINUED ON
NEXT PAGE

- While running the engine, measure voltage (backprobe) between front oxygen sensor connector terminals 1 and 2.
- Does voltage go above and below 500mV?

- Disconnect oxygen sensor connector. Does voltage now read between 19 and 58mV on scan tool?

A

CONTINUED ON
NEXT PAGE



NO


YES

A/T: Repair short to ground in wire between oxygen sensor harness connector terminal 1 and ECM harness connector C21-3 terminal 3.
M/T: Repair short to ground in wire between oxygen sensor harness connector terminal 1 and ECM harness connector C22-4 terminal 5. Clear code and verify oxygen sensor is within normal parameters.

Replace oxygen sensor. Clear code and verify oxygen sensor is within normal parameters.

TROUBLESHOOTING FOR DTC

CONTINUED FROM
PREVIOUS PAGECONTINUED FROM
PREVIOUS PAGECONTINUED ON
NEXT PAGE



EFHA5050

DTC	Diagnostic item
P0134	No Activity of Oxygen Sensor (Bank 1, Sensor 1)

DESCRIPTION


To obtain a high purification rate for the CO, HC and NO_x components of the exhaust gas, a three way catalytic converter is used, but for the most efficient use of the three-way catalytic inverter, the ratio of the air must be precisely controlled so that it is always close to the stoichiometric air-fuel ratio. The oxygen sensor has the characteristic whereby its output voltage changes suddenly in the vicinity of the stoichiometric air-fuel ratio. This characteristic is used to detect the oxygen concentration in the exhaust gas and provide feedback to the computer for control of the air-fuel ratio. When the air-fuel ratio becomes LEAN, the oxygen concentration in the exhaust increases and the oxygen sensor informs the ECM of the LEAN condition (small electromotive force: 0V). When the air-fuel ratio is RICHER than the stoichiometric air-fuel ratio the oxygen concentration in the exhaust gas is reduced and the oxygen sensor informs the ECM of the RICH condition (large electromotive force: 1V).

The ECM determined by the electromotive force from the oxygen sensor whether the air-fuel ratio is RICH or LEAN and controls the injection time accordingly. However, if malfunction of the oxygen sensor causes output of abnormal electromotive force, the ECM is unable to perform an accurate air-fuel ratio control. The heated oxygen sensors include a heater which heats the Zirconia element. The heater is controlled by the ECM. When the intake air volume is low (the temperature of the exhaust gas is low), current flows to the heater to heat the sensor for accurate oxygen concentration detection.

TROUBLESHOOTING GUIDE


DTC detection condition	Probable cause
Background - The MFI system reduces exhaust emissions by means of closed-loop fuel control. - The Engine Control Module checks the time taken until closed-loop fuel control commences. Check Area - Engine coolant temperature is higher than 80°C (176°F) - Intake air temperature is -10°C (14°F) or more. - Atmospheric pressure is 76 kPa (11.0 psi) or more. - Engine speed is between approx. 2,400 and 3,500 r/min. - Engine load is 26 - 60%. - In operation within air-fuel-ratio feedback zone. - Monitoring time: 128 sec. Judgment Criteria - Multiport fuel injection system doesn't enter the closed loop control within approx. 30 sec. - Monitored only once per trip.	- Heated oxygen sensor failed - Injector failed - Fuel pressure regulator failed - Fuel pump failed - Fuel filter clogged - Air intake in exhaust system - Exhaust gas leaks - Engine control module failed

CIRCUIT DIAGRAM



 : To Joint connector (refer to ETM)

TEST PROCEDURE



EFHA5070

DTC	Diagnostic item
P0135	Oxygen Sensor Heater Circuit Malfunction (Bank 1, Sensor 1)


DESCRIPTION

Refer to excessive time to enter closed loop fuel control (P0134).


TROUBLESHOOTING GUIDE


DTC detection condition	Probable cause
Background - The Engine Control Module checks whether the heater current is within a specified range when the heater is energized. Check Area - Battery voltage is between 12 and 16V. Judgment Criteria - Heater current of the front heated oxygen sensor heater (Bank 1 Sensor 1) has continued to be 0.2 A or less, or 3.5 A or higher for 6 sec. - Monitored only once per trip.	- Open or shorted oxygen sensor heater circuit - Open circuit in oxygen sensor heater - Engine control module failed

CIRCUIT DIAGRAM



TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE

EFHA5080

DTC	Diagnostic item
P0136	Oxygen Sensor Circuit Malfunction (Bank 1, Sensor 2)


DESCRIPTION

Refer to excessive time to enter closed loop fuel control (P0134).

TROUBLESHOOTING GUIDE


DTC detection condition	Probable cause
Background • The Engine Control Module checks for an open circuit in the heated oxygen sensor output line. Check Area • Coolant temperature sensor: Normal. • Heated oxygen sensor signal voltage has continued to be 0.1V or lower for 3 min. or more after the starting sequence was completed. • Engine coolant temperature is 80°C (176°F) or more. • Engine speed is higher than 1,200 r/min. • Engine load is 25% or more. • Monitoring Time: 7 - 10 sec. Judgment Criteria • Input voltage supplied to the engine control module interface circuit is 4.5V or more when 5V is applied to the heated oxygen sensor output line via a resistor. • Making the air-fuel ratio 15% richer doesn't result in raising the heated oxygen sensor output voltage beyond 0.1V.	• Heated oxygen sensor failed • Open circuit in heated oxygen sensor output line • Engine control module failed



CIRCUIT DIAGRAM



◁ D : To Joint connector (refer to ETM)

TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGECONTINUED FROM
PREVIOUS PAGECONTINUED ON
NEXT PAGE

CONTINUED FROM
PREVIOUS PAGE

D

Voltage varies between 0 and 900mV.

YES

- Ignition off.
- Disconnect ignition coil connector.
- Measure voltage drop across negative battery cable by connecting voltmeter between negative battery post and cable attachment point on engine while cranking the engine. Voltage drop measured should be less than 0.5 volts, is it?

YES

- Disconnect negative battery terminal.
- Measure resistance between generator case and engine ground point. Resistance measured should be approximately 1 ohm or less, is it?

YES

- If Malfunction Indicator Lamp (MIL) is turning on intermittently and DTC P0133 is set, problem is most likely a poor ground circuit. Clean negative battery terminal and engine ground. Also clean mating surfaces of generator housing and engine block.
- If Malfunction Indicator Lamp (MIL) was on and DTC P0136 is set, replace oxygen sensor.
- Clear code and verify oxygen sensor is within normal parameters.

CONTINUED FROM
PREVIOUS PAGE

E

NO

Follow diagnostic procedures outlined in shop manual. Clear code and verify oxygen sensor is within normal parameters.

NO

Replace negative battery cable. Clear code and verify oxygen sensor is within normal parameters.

NO

Clean mating surfaces of generator housing and engine block. Clear code and verify oxygen sensor is within normal parameters.

EFHA5090

DTC	Diagnostic item
P0141	Oxygen Sensor Heater Circuit Malfunction (Bank 1, Sensor 2)


DESCRIPTION

Refer to excessive time to enter closed loop fuel control (P0134).

TROUBLESHOOTING GUIDE


DTC detection condition	Probable cause
Background - The Engine Control Module checks whether the heater current is within a specified range when the heater is energized. Check Area - Battery voltage is between 12 and 16V. Judgment Criteria - Heater current of the front heated oxygen sensor heater (Bank 1 Sensor 2) has continued to be 0.2 A or less, or 3.5 A or more for 6 sec. - Monitored only once per trip.	- Open or shorted oxygen sensor heater circuit - Open circuit in oxygen sensor heater - Engine control module failed

CIRCUIT DIAGRAM



 : To Joint connector (refer to ETM)

TEST PROCEDURE



EFHA5100

DTC	Diagnostic item
P0201, P0202 P0203, P0204	Injector Circuit Malfunction (Cylinder-1, Cylinder-2, Cylinder-3, Cylinder-4)

DESCRIPTION

The fuel injectors are solenoid operated valves that are normally closed. When a fuel injector solenoid is energized (pulsed) the injector needle valve moves, allowing pressurized fuel to pass through the injector and mix with the air entering the engine. Each fuel injector (there is one for each engine cylinder) is mounted in the intake manifold and is positioned to spray fuel into a cylinder head intake port.


The Engine Control Module (ECM) controls injector timing and pulse width (how long the fuel injectors are turned on). The ECM pulses the fuel injectors based on information provided by its network of engine sensors. The ECM uses the crankshaft position sensor to determine when to pulse the injectors. Engine coolant temperature, intake air temperature, air flow and throttle position data are all used by the ECM to calculate injector pulse width.

The ECM also uses its network of sensors to determine whether all injectors should be pulsed at the same time (simultaneous injection) or each injector should be pulsed individually (sequential injection). Sequential injection is almost always used during normal engine operation and simultaneous injection may be used when the engine is being cranked.


TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background • A surge voltage is generated when the injectors are driven and the current flowing to the injector coil, is shut off. • The engine control module checks this surge voltage. Check Area • Engine speed is between 50 and 1,000 r/min • Throttle position sensor output voltage is 1.16V or less. • Monitoring Time: 4 sec. Judgment Criteria • Injector coil surge voltage (system voltage +2V) has not been detected for 4 sec.	• Injector failed • Open or shorted injector circuit, or loose connector • Engine control module failed

CIRCUIT DIAGRAM




TEST PROCEDURE



CONTINUED ON
NEXT PAGE

CONTINUED FROM
PREVIOUS PAGE



EFHA5110

DTC	Diagnostic item
P0300	Random Misfire Detected

DESCRIPTION


With the ignition switch ON or START, voltage is applied to the ignition coil. The ignition coil consists of two coils. High tension leads go to each cylinder from the ignition coil. The ignition coil fires two spark plugs every power stroke (the cylinder under compression and the cylinder on the exhaust stroke). Coil number one fires cylinders 1 and 4. Coil number two fires cylinders 2 and 3.

The ignition power transistor, controlled by the Engine Control Module (ECM), provides a switching circuit to ground for energizing the primary ignition coils. When a primary ignition coil is energized and deenergized, the secondary coil produces a high voltage spike across the attached spark plugs. At the same time, the tach interface (part of the ignition power transistor) provides the ECM and Transaxle Control Module (TCM) with an RPM signal.


TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - If a misfiring occurs while the engine is running, the engine speed suddenly changes. - The Engine Control Module checks for changes in the engine speed. Check Area - Five seconds or more have passed after the engine was started. - Engine speed is between 500 and 6,000 r/min. - Engine Coolant Temperature is higher than -10°C (14°F). - Intake air temperature is higher than -10°C (14°F). - Running free from sudden accelerations/decelerations such as shift change. Judgment Criteria (change in the angular acceleration of the crankshaft is used for misfire detection.) - Misfire has occurred more frequently than allowed during the last 200 revolutions [when the catalyst temperature is higher than 950°C ($1,742^{\circ}\text{F}$)]. - Misfire has occurred more frequently than the allowed number of times (2%) during 1,000 motor revolutions.	- Ignition system related part(s) failed - Poor crankshaft position sensor signal - Incorrect air/fuel ratio - Low compression pressure - Engine coolant temperature sensor failed - Timing belt missing teeth - Injector failed - Engine control module failed


CIRCUIT DIAGRAM




TEST PROCEDURE



A
CONTINUED ON
NEXT PAGE

CONTINUED FROM
PREVIOUS PAGE

CONTINUED FROM
PREVIOUS PAGE

EFHA5120

DTC	Diagnostic item
P0301, P0302, P0303, P0304,	Misfire detected (Cylinder-1, Cylinder-2, Cylinder-3, Cylinder-4)


DESCRIPTION

Refer to Random Misfire Detected (P0300).

TROUBLESHOOTING GUIDE


DTC detection condition	Probable cause
Background - If a misfiring occurs while the engine is running, the engine speed suddenly changes. - The Engine Control Module checks for changes in the engine speed. Check Area - Five seconds or more have passed after the engine was started. - Engine speed is between 500 and 6,000 r/min. - Engine Coolant Temperature is higher than -10°C (14°F). - Intake air temperature is higher than -10°C (14°F). - Running free from sudden accelerations/decelerations such as shift change. Judgment Criteria (change in the angular acceleration of the crankshaft is used for misfire detection.) - Misfire has occurred more frequently than allowed for during the last 200 revolutions [when the catalyst temperature is higher than 950°C (1,742°F)]. - Misfire has occurred more frequently than the allowed number of times (2%) during 1,000 motor revolutions.	- Ignition system related part(s) failed - Poor crankshaft position sensor signal - Incorrect air/fuel ratio - Low compression pressure - Engine coolant temperature sensor failed - Timing belt missing teeth - Injector failed - EGR valve failed - Engine control module failed

CIRCUIT DIAGRAM



HP0300A

TEST PROCEDURE



EFHA5130


DTC	Diagnostic item
P0335	Crankshaft Position Sensor Circuit Malfunction

DESCRIPTION

The Crankshaft Position (CKP) sensor consists of a magnet and coil located next to the flywheel. The voltage signal from the CKP sensor allows the Engine Control Module (ECM) to determine the engine of the RPM and Crankshaft Position.

TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - When the engine is running, the Crankshaft Position sensor outputs a pulse signal. - The Engine Control Module checks whether the pulse signal is input while the engine is cranking. Check Area - Engine is being cranked. Judgment Criteria - Sensor output voltage has not changed (no pulse signal is input) for 4 sec. Check Area, Judgment - Normal signal pattern has not been input for cylinder identification from the crankshaft position sensor signal and camshaft position sensor signal for 4 sec.	- Crankshaft position sensor failed - Open or shorted crankshaft position sensor circuit - Engine control module failed

CIRCUIT DIAGRAM

TEST PROCEDURE

- Turn ignition switch on.
- Connect scan tool to data link connector.
- Verify DTC P0335 is set.

- Ignition on.
 - Disconnect Crankshaft Position (CKP) sensor.
 - Measure voltage between ground and CKP sensor harness connector terminal 3.
- Battery voltage should be measured, is it?

YES

- Ignition off.
 - CKP sensor disconnected.
 - A/T: Disconnect ECM connector C21-2.
 - M/T: Disconnect ECM connector C22-4.
 - A/T: Ground CKP sensor harness connector terminal 2. Measure resistance between ground and ECM harness connector C21-2 terminal 5.
 - M/T: Ground CKP sensor harness connector terminal 2. Measure resistance between ground and ECM harness connector C22-4 terminal 19.
- Resistance measured should be approximately 1 ohm or less, is it?

YES

- Ignition off.
 - CKP sensor disconnected.
 - A/T: Disconnect ECM connector C21-2. Measure resistance between ground and CKP sensor harness connector terminal 2.
 - M/T: Disconnect ECM connector C22-4. Measure resistance between ground and CKP sensor harness connector terminal 2.
- Resistance should indicate an open circuit, does it?

YES



CONTINUED ON
NEXT PAGE

NO

Repair open in wire between CKP sensor harness connector terminal 3 and engine compartment junction block terminal D10.
Clear code and verify CKP sensor is within normal parameters.

NO

A/T: Repair open in wire between CKP sensor harness connector terminal 2 and ECM harness connector C21-2 terminal 5.
M/T: Repair open in wire between CKP sensor harness connector terminal 2 and ECM harness connector C22-4 terminal 19.
Clear code and verify CKP sensor is within normal parameters.

NO

A/T: Repair short to ground or another circuit in wire between CKP sensor harness connector terminal 2 and ECM harness connector C21-2 terminal 5.
M/T: Repair short to ground or another circuit in wire between CKP sensor harness connector terminal 2 and ECM harness connector C22-4 terminal 19.
Clear code and verify CKP sensor is within normal parameters.

CONTINUED FROM
PREVIOUS PAGE

- Ignition off.
- CKP sensor disconnected.
- Measure resistance between ground and CKP sensor harness connector terminal 1.

Resistance measured should be approximately 1 ohm or less, is it?

YES

- Inspect CKP sensor for damage or debris.

Is CKP sensor OK?

YES

- Ignition on.
- CKP sensor disconnected.
- ECM connector connected.
- Measure voltage between ground and CKP Sensor harness connector terminal 2.

Voltage should be approximately 5 volts, is it?

NO

Verify ECM connector is secure. If OK, replace CKP sensor with known good component. Clear code and verify CKP sensor is within normal parameters. If problem persists, replace ECM.

NO

Repair open or poor ground connection in ground wire. Clear code and verify CKP sensor is within normal parameters.

NO

Repair or replace CKP sensor. Clear code and verify CKP sensor is within normal parameters.

YES

Repair or replace CKP sensor. Clear code and verify CKP sensor is within normal parameters.

EFHA5140


DTC	Diagnostic item
P0340	Camshaft Position Sensor Circuit Malfunction

DESCRIPTION

The Camshaft Position (CMP) sensor senses the Top Dead Center (TDC) point of the #1 cylinder in the compression stroke. The CMP sensor signal allows the ECM to determine the fuel injector sequence starting point.


TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - When the engine is running, the Camshaft Position sensor outputs a pulse signal. - The Engine Control Module checks whether the pulse signal is input. Check Area, Judgement Criteria - Sensor output voltage has not changed (no pulse signal is input) for 4 sec. Check Area, Judgement Criteria - Normal signal pattern has not been input for cylinder identification from the camshaft position sensor signal for 4 sec.	- Camshaft Position sensor malfunction - Open or shorted camshaft position sensor circuit or loose connector - Engine control module failed

CIRCUIT DIAGRAM

HP0335A

TEST PROCEDURE



EFHA5170

DTC	Diagnostic item
P0421	Warm Up Catalyst Efficiency Below Threshold (Bank 1)

DESCRIPTION


The ECM compares the waveform of the oxygen sensor located in front of the catalyst with the waveform of the oxygen sensor located after the catalyst to determine whether or not catalyst performance has deteriorated. Air-fuel ratio feedback compensation keeps the waveform of the oxygen sensor in front of the catalyst repeatedly changing back and forth from rich to lean.

If the catalyst is functioning normally, the waveform of the oxygen sensor after the catalyst switches back and forth between rich and lean much more slowly than the waveform of the oxygen sensor in front of the catalyst. But when both waveforms change at a similar rate, it indicates that catalyst performance has deteriorated.

TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - The signal from the heated oxygen sensor which follows the catalytic converter differs from that which precedes the catalytic converter. This is because the catalytic converter purifies exhaust gas. When the catalytic converter has deteriorated, the signal from the heated oxygen sensor which follows the catalytic converter becomes similar to that which precedes the catalytic converter. - The Engine Control Module checks the outputs of the heated oxygen sensor signals. Check Area - Engine speed is 3,000 r/min or higher. - Closed throttle position switch: OFF - Under the closed loop air-fuel ratio control - Monitoring Time: 140 sec. Judgment Criteria - The front or rear heated oxygen sensor signal is abnormal.	- Catalytic converter deteriorated - Heated oxygen sensor failed - Engine control module failed

TEST PROCEDURE



EFHA5190


DTC	Diagnostic item
P0443	Evaporative Emission Control System Purge Control Valve Circuit Malfunction

DESCRIPTION


The evaporative system reduces hydrocarbon emission by trapping fuel tank vapors until they can be burned as part of the incoming fuel charge. Evaporating fuel is stored in a charcoal canister until it can be flushed into the intake manifold.

TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - The engine control module checks current flows in the evaporative emission purge solenoid drive circuit when the solenoid is ON and OFF. Check Area - Battery voltage is 10V or higher. Judgment Criteria - Solenoid coil surge voltage (system voltage +2V) is not detected when the EVAP emission vent solenoid is turned on/off.	- Evaporative emission purge solenoid failed - Open or shorted evaporative emission purge solenoid circuit, or loose connector - Engine control module failed


CIRCUIT DIAGRAM

TEST PROCEDURE



CONTINUED ON
NEXT PAGE

CONTINUED FROM
PREVIOUS PAGE



EFHA5220


DTC	Diagnostic item
P0500	Vehicle Speed Sensor Malfunction

DESCRIPTION

The vehicle speed sensor outputs a pulse signal while the vehicle is driven.
The engine control module checks whether the pulse signal is output.


TROUBLESHOOTING GUIDE

DTC detection condition	Probable cause
Background - The vehicle speed sensor outputs a pulse signal while the vehicle is driven. - The engine control module checks whether the pulse signal is output. Check Area - Closed throttle position switch: OFF - Engine speed is 3,000 r/min or more. - Engine load is 70% or more. Judgment Criteria - Sensor output voltage has not changed (no pulse signal is input) for 4 sec.	- Vehicle speed sensor failed - Open or shorted vehicle-speed sensor circuit, or loose connector - Engine control module failed

CIRCUIT DIAGRAM

HP0500A

TEST PROCEDURE



CONTINUED ON
NEXT PAGE

CONTINUED FROM
PREVIOUS PAGE

