


B: INSTALLATION


• Overall view



BS-06020

Panel Replacement


• Views 1



- | | | |
|--------------------------------|-------------------------------|--------------------------------|
| (1) 7 points | (4) 2 points | (7) 2 points [15 mm (0.59 in)] |
| (2) 1 point | (5) 1 point [35 mm (1.38 in)] | (8) 6 points |
| (3) 2 points [20 mm (0.79 in)] | (6) 3 points | |

Panel Replacement

• Views 2



(1) 2 points (only LH)
3 points (only RH)

(2) 1 point

(3) 1 point [20 mm (0.79 in)] (only LH)

(4) 1 point (service)


(5) 2 points (service)

(6) 3 points

(7) 2 points

Panel Replacement

• Views 3



(1) 4 points (service)

(2) 2 points (service)


(3) 1 point (service)

(4) 3 points

(5) 2 points

Panel Replacement

• Views 4




- | | | |
|------------------------|--------------------------------|-------------------------------|
| (1) 3 points (service) | (4) 2 points (service) | (7) 1 point |
| (2) 1 point (service) | (5) 4 points (service) | (8) 1 point [80 mm (3.15 in)] |
| (3) 6 points (service) | (6) 2 points [25 mm (0.98 in)] | |

Note: Designations in the RH diagram are the same as in the LH diagram, except for the indicated points.

Panel Replacement

• Views 5



BS-06024

(1) 2 points (service)


(3) 1 point (service)

(4) 3 points (service)

(2) 4 points

Panel Replacement

• Views 6



(1) 2 points

(2) 3 points