

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

ALPHABETICAL INDEX

Numerics

4WD mode switch [TF-54](#), [TF-57](#)
 4WD shift indicator lamp [TF-55](#)
 4WD solenoid valve [TF-49](#), [TF-52](#)
 4WD warning lamp [TF-40](#), [TF-55](#), [TF-56](#), [TF-57](#), [TF-58](#)

A

A/C air flow [ATC-31](#), [MTC-5](#)
 A/C component layout [ATC-23](#)
 A/C compressor clutch removal and installation
[ATC-135](#)
 A/C compressor precaution [ATC-9](#)
 A/C compressor special service tool [ATC-14](#)
 A/C diagnostic work flow (auto A/C) [ATC-33](#)
 A/C HFC134a (R134a) system precaution [ATC-4](#)
 A/C HFC134a (R134a) system service procedure
[ATC-129](#)
 A/C HFC134a (R134a) system service tools ... [ATC-15](#)
 A/C HFC134a system service equipment precaution ...
[ATC-10](#)
 A/C lubricant (R134a) [ATC-24](#)
 A/C operational check [ATC-54](#), [MTC-7](#)
 A/C performance test diagnoses [ATC-88](#)
 A/C rera [ATC-84](#)
 A/C self-diagnoses (auto A/C) [ATC-46](#)
 A/C system description (auto A/C) [ATC-27](#)
 A/C trouble diagnoses (auto A/C) [ATC-33](#), [MTC-3](#)
 A/C, A - Wiring diagram [ATC-38](#)
 A/CUT - Wiring diagram [EC-1572](#)
 A/T - Wiring diagram - AT - FTS [AT-118](#)
 A/T - Wiring diagram - AT - MAIN [AT-350](#)
 A/T - Wiring diagram - AT - PNP/SW [AT-112](#)
 A/T - Wiring diagram - AT - VSS A/T . [AT-124](#), [AT-355](#)
 A/T fluid checking [AT-13](#), [MA-36](#)
 A/T fluid replacement [AT-13](#), [MA-36](#)
 A/T fluid temperature sensor [AT-121](#)
 A/T IND - Wiring diagram [DI-57](#)
 A/T indicator [DI-57](#)
 A/T shift lock system [AT-406](#)
 A/T shift lock system - Wiring diagram [AT-407](#)
 A/T trouble diagnoses [AT-56](#), [AT-258](#)
 A/T Wiring diagram - AT - ENG SS ... [AT-128](#), [AT-393](#)
 A/T Wiring diagram AT - 1ST [AT-134](#)
 A/T Wiring diagram AT - 2ND [AT-140](#)
 A/T Wiring diagram AT - 3RD [AT-146](#)
 A/T Wiring diagram AT - 4TH [AT-152](#)
 A/T Wiring diagram AT - BA/FTS [AT-195](#), [AT-388](#)
 A/T Wiring diagram AT - CAN [AT-191](#), [AT-404](#)
 A/T Wiring diagram AT - LPSV [AT-165](#), [AT-398](#)
 A/T Wiring diagram AT - OVRCSV [AT-187](#), [AT-378](#)
 A/T Wiring diagram AT - SSV/A [AT-172](#), [AT-369](#)
 A/T Wiring diagram AT - SSV/B [AT-177](#), [AT-374](#)
 A/T Wiring diagram AT - TCV [AT-160](#), [AT-383](#)
 A/T Wiring diagram AT - TPS [AT-182](#), [AT-364](#)
 A/T Wiring diagram AT - VSSMTR .. [AT-201](#), [AT-360](#)
 ABS - Wiring diagram [BRC-12](#)
 Absolute pressure sensor [EC-1494](#)

Accelerator control system [ACC-2](#)
 Accelerator pedal position (APP) sensor [EC-355](#),
[EC-361](#), [EC-373](#), [EC-631](#), [EC-637](#), [EC-651](#), [EC-893](#),
[EC-1222](#), [EC-1460](#)
 Accelerator pedal released position learning . [EC-1404](#)
 Accelerator pedal released position switch [EC-1531](#)
 Actuator relay [TF-52](#)
 Aiming adjustment [LT-4](#)
 Air bag [SRS-3](#)
 Air bag disposal [SRS-41](#)
 Air bleeding (hydraulic clutch) [CL-8](#)
 Air bleeding for brake system [BR-10](#)
 Air cleaner and air duct(QR20DE•QR25DE) [EM-14](#)
 Air cleaner and air duct(YD22DDTi) [EM-120](#)
 Air cleaner filter replacement(QR20DE•QR25DE)
[MA-22](#)
 Air cleaner filter replacement(YD22DDTi) [MA-32](#)
 Air cleaner filter(QR20DE•QR25DE) [EM-14](#)
 Air cleaner filter(YD22DDTi) [EM-120](#)
 Air conditioner cut control [EC-36](#), [EC-446](#), [EC-768](#),
[EC-1132](#), [EC-1401](#)
 Air flow meter - See Mass air flow sensor [EC-138](#),
[EC-516](#), [EC-870](#), [EC-999](#), [EC-1202](#)
 Air mix door control linkage adjustment [ATC-66](#),
[ATC-125](#), [MTC-10](#), [MTC-28](#)
 Air mix. door motor [ATC-64](#), [ATC-125](#)
 Air spoiler, rear [EI-21](#)
 Alternator [SC-12](#)
 Ambient sensor [ATC-100](#), [ATC-102](#), [ATC-112](#)
 Angular tightening application(QR20DE•QR25DE)
[EM-5](#)
 Angular tightening application(YD22DDTi) [EM-110](#)
 Antenna - See Power antenna [AV-16](#)
 APPS - Wiring diagram ... [EC-895](#), [EC-1225](#), [EC-1462](#)
 APPS1 - Wiring diagram [EC-357](#), [EC-633](#)
 APPS2 - Wiring diagram [EC-363](#), [EC-640](#)
 APPS3 - Wiring diagram [EC-375](#), [EC-653](#)
 APRSW - Wiring diagram [EC-1533](#)
 Audio [AV-3](#)
 Auto air conditioner - Wiring diagram [ATC-38](#)
 Automatic amplifier [ATC-44](#), [ATC-57](#)
 Automatic transmission fluid replacement [MA-35](#),
[MA-37](#)
 Axle [MA-41](#)

B

Back door [BL-71](#)
 Back door trim [EI-25](#)
 Back door window [GW-8](#)
 Back window [GW-8](#)
 BACK/L - Wiring diagram [LT-28](#)
 Back-up lamp [LT-28](#), [LT-42](#)
 Back-up lamp switch (M/T) [MT-12](#)
 Basic inspection ... [EC-73](#), [EC-465](#), [EC-805](#), [EC-1152](#),
[EC-1412](#)
 Battery [SC-3](#)
 Baulk ring (M/T) [MT-18](#), [MT-23](#)
 Blower motor [ATC-70](#), [ATC-77](#), [ATC-118](#), [MTC-14](#),

ALPHABETICAL INDEX

[MTC-17, MTC-21](#)
 Blower resistor [MTC-22](#)
 Blower unit [ATC-116, MTC-21](#)
 Boring/horning cylinder block(QR20DE•QR25DE)
[EM-93](#)
 Brake booster [BR-17](#)
 Brake fluid change [BR-9](#)
 Brake fluid level [MA-39](#)
 Brake fluid level and line check [BR-9](#)
 Brake hydraulic line [BR-11](#)
 Brake inspection [MA-39](#)
 Brake lines and cables inspection [MA-39](#)
 Brake master cylinder [BR-13](#)
 Brake pedal [BR-6](#)
 Brake switch [EC-349, EC-625, EC-1068, EC-1301,](#)
[EC-1558](#)
 BRK/SW - Wiring diagram [EC-351, EC-627, EC-1070,](#)
[EC-1303, EC-1559](#)
 Bulb specifications [LT-67](#)
 Bumper, front [EI-6](#)
 Bumper, rear [EI-9](#)

C

Camshaft inspection(QR20DE•QR25DE) [EM-51](#)
 Camshaft inspection(YD22DDTi) [EM-159](#)
 Camshaft position sensor (CMPS) [EC-1484](#)
 Camshaft position sensor (PHASE) . [EC-233, EC-557,](#)
[EC-962, EC-1246](#)
 Camshaft(QR20DE•QR25DE) [EM-46](#)
 Camshaft(YD22DDTi) [EM-158](#)
 CAN - Wiring diagram [EC-123, EC-514, EC-855,](#)
[EC-1200, EC-1449, LAN-6, LAN-13](#)
 CAN (Controller Area Network) [LAN-3, LAN-5, LAN-12](#)
 CAN Communication [TF-53](#)
 CAN communication [EC-122, EC-513, EC-854,](#)
[EC-1199, EC-1448, AT-109, AT-190, AT-309, AT-403,](#)
[BRC-54, BRC-62, BRC-92, BRC-110, LAN-3, LAN-5,](#)
[LAN-12](#)
 Canister-See EVAP canister [EC-427, EC-748,](#)
[EC-1114, EC-1388](#)
 CHARGE - Wiring diagram [SC-13](#)
 Charging system [SC-12](#)
 Chassis and body maintenance [MA-35](#)
 CHIME - Wiring diagram [DI-59](#)
 CIGAR - Wiring diagram [WW-25](#)
 Cigarette lighter [WW-25](#)
 Circuit breaker [PG-12](#)
 CKPS - Wiring diagram [EC-1481](#)
 Clearance lamp [LT-4, LT-40](#)
 Clock [DI-70](#)
 CLOCK - Wiring diagram [DI-70](#)
 Closed loop control [EC-34, EC-444, EC-766, EC-1130](#)
 Clutch cover [CL-15](#)
 Clutch disc [CL-15](#)
 Clutch master cylinder [CL-9](#)
 Clutch operating cylinder [CL-11](#)
 Clutch pedal [CL-5](#)
 Clutch release bearing [CL-13](#)

Clutch release mechanism [CL-13](#)
 Clutch withdrawal lever [CL-13](#)
 CMPS - Wiring diagram [EC-1486](#)
 Coil spring (rear) [RSU-8](#)
 Collision diagnosis [SRS-47](#)
 Combination meter [DI-4, DI-24](#)
 Combination switch [LT-24, LT-44](#)
 Common rail fuel pressure sensor [EC-1468](#)
 Component Location (auto A/C) [ATC-34, MTC-4](#)
 Compression pressure(QR20DE•QR25DE) [EM-59](#)
 Compression pressure(YD22DDTi) [EM-182](#)
 Compressor clutch removal and installation .. [ATC-135](#)
 Compressor special service tool [ATC-14](#)
 Condenser [ATC-143](#)
 Connecting rod bearing clearance(QR20DE•QR25DE)
[EM-91](#)
 Connecting rod bearing clearance(YD22DDTi) [EM-216](#)
 Connecting rod bushing clearance(QR20DE•QR25DE)
[EM-91](#)
 Connecting rod bushing clearance(YD22DDTi) [EM-210](#)
 Connecting rod(QR20DE•QR25DE) [EM-91](#)
 Connecting rod(YD22DDTi) [EM-207, EM-212](#)
 Console box - See Instrument panel [IP-3, IP-10](#)
 CONSULT for engine [EC-94, EC-486, EC-826,](#)
[EC-1173, EC-1431](#)
 CONSULT for VDC [BRC-80](#)
 Control lever (M/T) [MT-13](#)
 Control unit [ATC-111, MTC-20](#)
 Control units (terminal arrangement) [PG-71](#)
 Controller Area Network (CAN) [LAN-3, LAN-5, LAN-12](#)
 Converter housing installation [AT-419, AT-514](#)
 COOL/F - Wiring diagram [EC-327, EC-607, EC-1054,](#)
[EC-1291, EC-1510](#)
 Coolant replacement(QR20DE•QR25DE) [MA-19](#)
 Coolant replacement(YD22DDTi) [MA-27](#)
 Cooling circuit (engine)(QR20DE•QR25DE) [CO-7](#)
 Cooling circuit (engine)(YD22DDTi) [CO-27](#)
 Cooling fan control system(QR20DE•QR25DE) [CO-12](#)
 Cooling fan motor [EC-336, EC-616, EC-1063, EC-1300](#)
 Cooling fan relay [EC-336, EC-616, EC-1063, EC-1300](#)
 Cooling fan(QR20DE•QR25DE) [CO-12](#)
 Cooling fan(YD22DDTi) [CO-33](#)
 Coupling sleeve (M/T) [MT-18, MT-23](#)
 Cowl top [EI-12](#)
 Cowl top cover [EI-12](#)
 Crankcase ventilation system [EC-1402](#)
 Crankcase ventilation system - See Positive crankcase
 ventilation [EC-428, EC-749, EC-1115, EC-1389](#)
 Crankshaft position sensor (POS) [EC-227, EC-551,](#)
[EC-956, EC-1240](#)
 Crankshaft position sensor (TDC) [EC-1479](#)
 Crankshaft(QR20DE•QR25DE) [EM-74](#)
 CRFPS - Wiring diagram [EC-1469](#)
 Cylinder block boring(QR20DE•QR25DE) [EM-94](#)
 Cylinder block boring(YD22DDTi) [EM-214](#)
 Cylinder block(QR20DE•QR25DE) [EM-73](#)
 Cylinder block(YD22DDTi) [EM-197](#)
 Cylinder head bolt tightening(QR20DE•QR25DE)
[EM-61](#)

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L

IDX

ALPHABETICAL INDEX

Cylinder head bolt tightening(YD22DDTi) [EM-184](#)
 Cylinder head gasket selection(YD22DDTi) .. [EM-185](#)
 Cylinder head(QR20DE•QR25DE) [EM-59](#)
 Cylinder head(YD22DDTi) [EM-182](#)

D

Data link connector [EC-424](#), [EC-745](#), [EC-1111](#),
[EC-1385](#)
 Data link connector for Consult [EC-96](#), [EC-488](#),
[EC-827](#), [EC-1174](#), [EC-1431](#)
 Daytime light system [LT-9](#)
 Daytime running light - See Daytime light system [LT-9](#)
 DEF - Wiring diagram [GW-15](#)
 Desiccant Assembly [ATC-30](#), [ATC-146](#)
 Diagnosis sensor unit [SRS-40](#)
 Diagnostic trouble code (DTC) [EC-1406](#)
 Diagnostic trouble code (DTC) for OBD system [EC-20](#),
[EC-47](#), [EC-432](#), [EC-454](#), [EC-753](#), [EC-779](#), [EC-1119](#),
[EC-1141](#), [EC-1393](#)
 Diagnostic trouble code (DTC) inspection priority chart
[EC-70](#), [EC-463](#), [EC-802](#), [EC-1150](#)
 Differential gear (FF M/T) [MT-21](#), [MT-26](#)
 DLC - Wiring diagram [EC-424](#), [EC-745](#), [EC-1111](#),
[EC-1385](#)
 Door glass [GW-44](#), [GW-46](#)
 Door glass Fitting Adjustment [GW-44](#), [GW-46](#)
 Door lock [BL-65](#), [BL-68](#)
 Door mirror [GW-49](#)
 Door trim [EI-23](#)
 Door, front [BL-8](#)
 Door, rear [BL-8](#)
 Drive belt inspection(QR20DE•QR25DE) [MA-19](#)
 Drive belt inspection(YD22DDTi) [MA-26](#)
 Drive belt(QR20DE•QR25DE) [EM-12](#)
 Drive belt(YD22DDTi) [EM-118](#)
 Drive shaft (front) [FAX-11](#)
 Drive shaft (rear) [RAX-9](#)
 Driver air bag [SRS-29](#)
 Dropping resistor (A/T) [AT-169](#), [AT-402](#)
 DTC work support [EC-103](#), [EC-834](#)
 DTRL - Wiring diagram [LT-9](#)
 Dual pressure switch [ATC-18](#), [ATC-85](#), [ATC-143](#)
 Duct and grilles [ATC-127](#), [MTC-29](#)

E

ECM input/output signal [EC-87](#), [EC-479](#), [EC-819](#),
[EC-1166](#)
 ECM power supply [EC-116](#), [EC-267](#), [EC-507](#), [EC-580](#),
[EC-848](#), [EC-995](#), [EC-1193](#), [EC-1269](#), [EC-1442](#)
 ECM relay [EC-1538](#)
 ECM/PW - Wiring diagram . [EC-268](#), [EC-581](#), [EC-996](#),
[EC-1270](#)
 ECMRLY - Wiring diagram [EC-1539](#)
 ECTS - Wiring diagram [EC-151](#), [EC-525](#), [EC-883](#),
[EC-1211](#), [EC-1457](#)
 EDU - Wiring diagram [EC-1503](#)
 EGR function [EC-1551](#)

EGR volume control valve [EC-1551](#)
 EGRC/V - Wiring diagram [EC-1553](#)
 Electric sunroof [RF-3](#)
 Electric throttle control actuator [EC-276](#), [EC-278](#),
[EC-584](#), [EC-586](#), [EC-1010](#), [EC-1012](#), [EC-1273](#),
[EC-1275](#)
 Electrical unit [PG-71](#)
 Electrical units location [PG-63](#)
 Electronic drive unit (EDU) [EC-1501](#)
 Electronic fuel injection pump(YD22DDTi) [EM-147](#)
 Electronic ignition (EI) system [EC-35](#), [EC-445](#), [EC-768](#),
[EC-1132](#)
 Engine control circuit diagram [EC-85](#), [EC-477](#), [EC-817](#),
[EC-1164](#), [EC-1423](#)
 Engine control component parts location [EC-81](#),
[EC-473](#), [EC-813](#), [EC-1160](#)
 Engine control module (ECM) [EC-260](#), [EC-573](#),
[EC-988](#), [EC-1262](#), [EC-1536](#)
 Engine control system diagram and chart [EC-31](#),
[EC-441](#), [EC-763](#), [EC-1127](#), [EC-1398](#)
 Engine coolant temperature sensor (ECTS) .. [EC-149](#),
[EC-523](#), [EC-881](#), [EC-1209](#), [EC-1456](#)
 Engine coolant(QR20DE•QR25DE) [CO-9](#)
 Engine coolant(YD22DDTi) [CO-29](#)
 Engine fail-safe system [EC-71](#), [EC-464](#), [EC-803](#),
[EC-1151](#)
 Engine oil filter replacement(QR20DE•QR25DE)
[MA-23](#)
 Engine oil filter replacement(YD22DDTi) [MA-33](#)
 Engine oil precautions [GI-7](#)
 Engine oil replacement(QR20DE•QR25DE) [MA-23](#)
 Engine oil replacement(YD22DDTi) [MA-32](#)
 Engine oil(QR20DE•QR25DE) [LU-7](#)
 Engine oil(YD22DDTi) [LU-18](#)
 Engine removal(QR20DE•QR25DE) [EM-69](#)
 Engine removal(YD22DDTi) [EM-193](#)
 ETC1 - Wiring diagram [EC-280](#), [EC-588](#)
 ETC2 - Wiring diagram [EC-287](#), [EC-595](#)
 ETC3 - Wiring diagram [EC-292](#), [EC-600](#)
 EVAP canister purge volume control solenoid valve
[EC-244](#), [EC-425](#), [EC-692](#), [EC-746](#), [EC-972](#), [EC-1112](#),
[EC-1340](#), [EC-1388](#)
 EVAP vapor lines inspection(QR20DE•QR25DE)
[MA-25](#)
 Evaporative emission (EVAP) system [EC-425](#), [EC-746](#),
[EC-1112](#), [EC-1386](#)
 Evaporator [ATC-145](#)
 Exhaust manifold(QR20DE•QR25DE) [EM-24](#)
 Exhaust manifold(YD22DDTi) [EM-127](#)
 Exhaust system [EX-2](#)
 Exhaust system inspection [EX-2](#), [MA-35](#)
 Expansion valve [ATC-146](#)
 Exterior [EI-13](#), [EI-14](#), [EI-16](#), [EI-17](#), [EI-18](#), [EI-19](#), [EI-21](#),
[EI-22](#)

F

F/FOG - Wiring diagram [LT-33](#), [LT-34](#)
 F/PUMP - Wiring diagram [EC-407](#), [EC-728](#), [EC-1094](#),

ALPHABETICAL INDEX

[EC-1368](#)
 Fan control amp. [ATC-74](#), [ATC-120](#)
 Fan switch [ATC-30](#), [MTC-17](#)
 FIAR - Wiring diagram [EC-1526](#)
 Final drive (FF M/T) [MT-21](#), [MT-26](#)
 Final drive disassembly [RFD-11](#)
 Final drive removal and installation [RFD-11](#)
 Finisher, interior - See Trim [EI-23](#), [EI-25](#)
 Finisher, rear panel [EI-22](#)
 Floor trim [EI-28](#)
 Flow charts [GI-23](#)
 Fluid temperature sensor (A/T) [AT-121](#)
 Fluorescent leak detector [ATC-147](#)
 Flywheel (clutch) [CL-15](#)
 Flywheel runout(QR20DE•QR25DE) [EM-97](#)
 Flywheel runout(YD22DDTi) [EM-218](#)
 Fog lamp, front [LT-33](#)
 Fork rod (M/T) [MT-20](#), [MT-25](#)
 Freeze frame data [EC-48](#), [EC-455](#), [EC-780](#), [EC-1142](#)
 FRO2 - Wiring diagram [EC-672](#), [EC-1321](#)
 FRO2/H - Wiring diagram [EC-658](#), [EC-1308](#)
 Front bumper [EI-6](#)
 Front disc brake [BR-21](#)
 Front door [BL-8](#)
 Front Door Trim [EI-23](#)
 Front fog lamp [LT-33](#)
 Front passenger air bag [SRS-35](#)
 Front seat [SE-7](#)
 Front seat belt [SB-3](#)
 Front seat belt pre-tensioner [SB-2](#), [SRS-3](#), [SRS-39](#)
 Front side air bag [SRS-36](#)
 Front suspension [FSU-5](#)
 Front washer [WW-4](#)
 Front wiper [WW-4](#)
 FTS - Wiring diagram [EC-1497](#)
 Fuel check valve [EC-425](#), [EC-746](#), [EC-1112](#)
 Fuel cut control (at no load high engine speed) [EC-37](#),
[EC-447](#), [EC-769](#), [EC-1133](#), [EC-1401](#)
 Fuel filler lid [BL-75](#)
 Fuel filter [EC-1404](#)
 Fuel filter replacement(QR20DE•QR25DE) [FL-4](#)
 Fuel filter replacement(YD22DDTi) [FL-15](#), [MA-31](#)
 Fuel gauge [DI-4](#), [DI-24](#)
 Fuel injection control system [EC-1399](#)
 Fuel injection system [EC-200](#), [EC-206](#), [EC-934](#),
[EC-940](#)
 Fuel injector [EC-1472](#)
 Fuel injector adjustment resistor [EC-1525](#)
 Fuel injector and fuel tube(QR20DE•QR25DE) . [EM-32](#)
 Fuel injector and fuel tube(YD22DDTi) [EM-144](#)
 Fuel leak [EC-1529](#)
 Fuel line inspection(QR20DE•QR25DE) . [FL-3](#), [MA-22](#)
 Fuel line inspection(YD22DDTi) [FL-14](#), [MA-30](#)
 Fuel pressure check [EC-42](#), [EC-452](#), [EC-775](#), [EC-1139](#)
 Fuel pressure release [EC-42](#), [EC-452](#), [EC-775](#),
[EC-1139](#)
 Fuel pressure relief valve [EC-1405](#)
 Fuel pump [EC-405](#), [EC-726](#), [EC-1092](#), [EC-1366](#)
 Fuel pump and gauge(QR20DE•QR25DE) [FL-4](#)

Fuel system(QR20DE•QR25DE) [FL-3](#)
 Fuel system(YD22DDTi) [FL-14](#)
 Fuel tank(QR20DE•QR25DE) [FL-9](#)
 Fuel tank(YD22DDTi) [FL-21](#)
 Fuel temperature sensor [EC-1496](#)
 Fuse [PG-12](#)
 Fuse and fusible link box [PG-75](#)
 Fusible link [PG-12](#)

G

Gear components (M/T) [MT-18](#), [MT-23](#)
 Generator [SC-12](#)
 Generator - See Alternator [SC-12](#)
 Generic scan tool (GST) [EC-104](#), [EC-836](#)
 Glass [GW-44](#), [GW-46](#)
 GLOW - Wiring diagram [EC-1545](#)
 Glow plug [EC-1544](#)
 Glow plug(YD22DDTi) [EM-138](#)
 Glow relay [EC-1544](#)
 Grille - See Exterior [EI-11](#)
 Ground distribution [PG-13](#)
 G-sensor [TF-50](#)

H

H/AIM - Wiring diagram [LT-15](#)
 H/LAMP - Wiring diagram [LT-4](#), [LT-5](#)
 H/MIRROR - Wiring diagram [GW-15](#)
 Harness connector [PG-68](#)
 Harness layout [PG-29](#)
 Headlamp [LT-4](#)
 Headlamp aiming control [LT-15](#)
 Headlamp leveler - See Headlamp aiming control
[LT-15](#)
 Headlamp washer [WW-19](#)
 Headlining - See Roof trim [EI-29](#)
 Heated oxygen sensor 1 ... [EC-163](#), [EC-169](#), [EC-178](#),
[EC-295](#), [EC-301](#), [EC-534](#), [EC-671](#), [EC-899](#), [EC-905](#),
[EC-914](#), [EC-1023](#), [EC-1029](#), [EC-1229](#), [EC-1320](#)
 Heated oxygen sensor 1 heater [EC-128](#), [EC-657](#),
[EC-860](#), [EC-1307](#)
 Heated oxygen sensor 2 ... [EC-185](#), [EC-192](#), [EC-307](#),
[EC-315](#), [EC-677](#), [EC-921](#), [EC-927](#), [EC-1035](#), [EC-1042](#),
[EC-1326](#)
 Heated oxygen sensor 2 heater [EC-133](#), [EC-662](#),
[EC-865](#), [EC-1312](#)
 Heated seat [SE-3](#), [SE-5](#)
 HEATER - Wiring diagram [MTC-6](#)
 Heater and cooling unit (Heater core) [ATC-122](#)
 Heater mirror [GW-15](#)
 Heater system - Wiring diagram [MTC-6](#)
 Heater unit (heater core) .. [ATC-126](#), [MTC-24](#), [MTC-26](#)
 HFC134a (R134a) system precaution [ATC-4](#)
 HFC134a (R134a) system service procedure [ATC-129](#)
 HFC134a (R134a) system service tools [ATC-15](#)
 HFC134a system service equipment precaution
[ATC-10](#)
 HO2S1 - Wiring diagram [EC-130](#), [EC-165](#), [EC-172](#),

ALPHABETICAL INDEX

[EC-181](#), [EC-536](#), [EC-862](#), [EC-901](#), [EC-908](#), [EC-917](#),
[EC-1231](#)
HO2S2 - Wiring diagram [EC-187](#), [EC-195](#), [EC-310](#),
[EC-318](#), [EC-923](#), [EC-930](#), [EC-1038](#), [EC-1045](#)
HO2S2H - Wiring diagram [EC-135](#), [EC-867](#)
Hood [BL-4](#)
Horn [WW-23](#)
HORN - Wiring diagram [WW-23](#)
How to erase DTC [EC-1406](#)
How to erase DTC for OBD system [EC-56](#), [EC-455](#),
[EC-788](#), [EC-1142](#)

I

IATS - Wiring diagram [EC-146](#), [EC-878](#)
IATSEN - Wiring diagram [EC-668](#), [EC-1317](#)
Identification [ATC-12](#)
Idle air volume learning [EC-39](#), [EC-450](#), [EC-772](#),
[EC-1137](#)
Idle speed [EC-73](#), [EC-465](#), [EC-805](#), [EC-1152](#), [EC-1412](#)
IGN/SG - Wiring diagram [EC-380](#), [EC-1075](#)
Ignition coil [EC-379](#), [EC-683](#), [EC-1074](#), [EC-1331](#)
Ignition coil(QR20DE•QR25DE) [EM-29](#)
Ignition control system [EC-379](#), [EC-683](#), [EC-1074](#),
[EC-1331](#)
Ignition timing [EC-73](#), [EC-465](#), [EC-805](#), [EC-1152](#)
IGNSYS - Wiring diagram [EC-684](#), [EC-1332](#)
ILL - Wiring diagram [LT-45](#)
Illumination [LT-45](#)
In vehicle sensor [ATC-102](#), [ATC-104](#), [ATC-113](#)
INJECT - Wiring diagram . [EC-389](#), [EC-710](#), [EC-1084](#),
[EC-1358](#), [EC-1475](#)
Injection nozzle(YD22DDTi) [EM-144](#)
Injector [EC-388](#), [EC-709](#), [EC-1083](#), [EC-1357](#)
Input shaft (FF M/T) [MT-18](#), [MT-23](#)
Instrument panel [IP-3](#)
INT/L - Wiring diagram [LT-65](#)
Intake air temperature sensor [EC-144](#), [EC-160](#),
[EC-667](#), [EC-876](#), [EC-1316](#)
Intake door control linkage adjustment [ATC-69](#)
Intake door motor [ATC-68](#), [ATC-119](#), [MTC-11](#), [MTC-23](#)
Intake manifold(QR20DE•QR25DE) [EM-16](#)
Intake manifold(YD22DDTi) [EM-123](#)
Intake sensor [ATC-108](#), [ATC-115](#)
Intake valve timing control . [EC-125](#), [EC-699](#), [EC-857](#),
[EC-1347](#)
Intake valve timing control solenoid valve [EC-271](#),
[EC-699](#), [EC-1005](#), [EC-1347](#)
Interior [EI-23](#), [EI-25](#), [EI-26](#), [EI-28](#), [EI-29](#)
Interior lamp [LT-55](#)
Interior lamp on-off control [LT-55](#), [LT-56](#)
ISO 15031-5 Mode 1 - 9 [EC-44](#), [EC-777](#)
IVC - Wiring diagram [EC-273](#), [EC-1007](#)
IVC/V - Wiring diagram [EC-701](#), [EC-1349](#)

J

Joint connector (J/C) [PG-70](#), [PG-74](#)

K

Keyless entry system - See Multi-remote control system
[BL-55](#)
Knock sensor (KS) [EC-222](#), [EC-546](#), [EC-951](#), [EC-1235](#)
KS - Wiring diagram [EC-224](#), [EC-548](#), [EC-953](#),
[EC-1237](#)

L

LAN system circuit [ATC-59](#)
License lamp [LT-30](#)
Line pressure solenoid valve [AT-156](#)
Line pressure test (A/T) [AT-67](#), [AT-268](#)
Liquid gasket application(QR20DE•QR25DE) ... [EM-6](#),
[EM-111](#), [LU-3](#), [LU-15](#), [CO-3](#), [CO-23](#)
LOAD - Wiring diagram [EC-416](#), [EC-737](#), [EC-1103](#),
[EC-1377](#)
Location of electrical units [PG-63](#)
Lock, door [BL-65](#), [BL-68](#)
Lubricant (R134a) A/C [ATC-5](#), [ATC-24](#)
Lubrication circuit (engine)(QR20DE•QR25DE) .. [LU-5](#)
Lubrication circuit (engine)(YD22DDTi) [LU-17](#)
Lubrication oil A/C [ATC-150](#)
Lubrication-locks, hinges and hood latches [MA-41](#)

M

M/T major overhaul [MT-26](#), [MT-35](#)
M/T oil replacement [MT-10](#)
M/T removal and installation [MT-15](#)
MAFS - Wiring diagram [EC-140](#), [EC-519](#), [EC-872](#),
[EC-1001](#), [EC-1205](#), [EC-1453](#)
Magnet clutch [ATC-78](#), [ATC-135](#)
MAIN - Wiring diagram [EC-116](#), [EC-507](#), [EC-848](#),
[EC-1193](#), [EC-1443](#)
Mainshaft (M/T) [MT-18](#), [MT-23](#)
Maintenance (engine)(QR20DE•QR25DE) [MA-19](#)
Maintenance (engine)(YD22DDTi) [MA-26](#)
Malfunction indicator (MI) .. [EC-263](#), [EC-576](#), [EC-991](#),
[EC-1265](#), [EC-1407](#)
Malfunction indicator lamp (MIL) [EC-58](#), [EC-457](#),
[EC-790](#), [EC-1144](#)
Mass air flow sensor (MAFS) [EC-138](#), [EC-516](#),
[EC-870](#), [EC-999](#), [EC-1202](#), [EC-1451](#)
Master cylinder (brake) [BR-13](#)
Master cylinder (clutch) [CL-9](#)
METER - Wiring diagram [DI-8](#), [DI-28](#)
MIL - Wiring diagram [EC-264](#), [EC-577](#), [EC-992](#),
[EC-1266](#)
MIL/DL - Wiring diagram [EC-1573](#)
MIRROR - Wiring diagram [GW-50](#)
Mirror defogger [GW-15](#)
Mirror, door [GW-49](#)
Mirror, out side [GW-49](#)
Misfire [EC-217](#), [EC-946](#)
Mode door control linkage adjustment [ATC-64](#),
[ATC-124](#), [MTC-9](#), [MTC-27](#)
Mode door motor [ATC-62](#), [ATC-124](#)

ALPHABETICAL INDEX

Molding - See Exterior [EI-14](#), [EI-16](#), [EI-17](#)
Mud guard - See Exterior [EI-16](#)
MULTI - Wiring diagram [BL-57](#)
Multiport fuel injection (MFI) system ... [EC-33](#), [EC-443](#),
[EC-765](#), [EC-1129](#)
Multiport fuel injection precautions [GI-6](#)
Multi-remote control system [BL-55](#)

N

NATS - Wiring diagram [BL-83](#)
NATS (Nissan anti-theft system) [BL-80](#)
NATS (Nissan anti-theft system) precautions [GI-3](#)
NVH troubleshooting (BR) [BR-5](#), [PB-2](#)
NVH troubleshooting (CL) [CL-4](#)
NVH troubleshooting (EM)(QR20DE•QR25DE) [EM-10](#)
NVH troubleshooting (EM)(YD22DDTi) [EM-116](#)
NVH troubleshooting (M/T) [MT-7](#)
NVH troubleshooting (PR) [FAX-6](#)
NVH troubleshooting (RA) [RAX-5](#)
NVH troubleshooting (RAX) [RAX-5](#)
NVH troubleshooting (RSU) [RSU-4](#)
NVH troubleshooting (Transfer) [TF-7](#)

O

Oil cooler (engine)(QR20DE•QR25DE) [LU-13](#)
Oil cooler (engine)(YD22DDTi) [LU-25](#)
Oil filter(QR20DE•QR25DE) [LU-9](#)
Oil filter(YD22DDTi) [LU-20](#)
Oil pan (engine)(QR20DE•QR25DE) [EM-26](#)
Oil pan (engine)(YD22DDTi) [EM-133](#)
Oil pressure (engine)(QR20DE•QR25DE) [LU-7](#)
Oil pressure (engine)(YD22DDTi) [LU-18](#)
Oil pump (engine)(QR20DE•QR25DE) [LU-10](#)
Oil pump (engine)(YD22DDTi) [LU-23](#)
Oil pump regulator valve (engine)(QR20DE•QR25DE)
[LU-11](#)
Oil pump regulator valve (engine)(YD22DDTi) .. [LU-24](#)
Oil seal replacement (engine)(QR20DE•QR25DE)
[EM-37](#), [EM-59](#), [EM-73](#)
On board diagnostic system . [EC-44](#), [EC-454](#), [EC-777](#),
[EC-1141](#)
Operating cylinder (clutch) [CL-11](#)
Out side mirror [GW-49](#)
Overdrive control switch [AT-246](#), [AT-349](#)
Overheat [EC-1508](#)
Oversize piston(QR20DE•QR25DE) [EM-93](#)
Oversize piston(YD22DDTi) [EM-214](#)

P

Park/Neutral position switch [EC-345](#), [EC-705](#),
[EC-1064](#), [EC-1353](#), [EC-1562](#)
Park/neutral position switch (A/T) [AT-110](#)
Park/neutral position switch (M/T) [MT-12](#)
PCV (positive crankcase ventilation) [EC-428](#), [EC-749](#),
[EC-1115](#), [EC-1389](#)
PGC/V - Wiring diagram [EC-246](#), [EC-974](#)

PHASE - Wiring diagram ... [EC-235](#), [EC-559](#), [EC-964](#),
[EC-1248](#)
Pilot bushing replacement - See Pilot
converter(QR20DE•QR25DE) [EM-73](#)
Piston assembly(QR20DE•QR25DE) [EM-93](#)
Piston pin inspection(QR20DE•QR25DE) [EM-89](#)
Piston pin inspection(YD22DDTi) [EM-206](#)
Piston ring inspection(QR20DE•QR25DE) [EM-90](#)
Piston ring inspection(YD22DDTi) [EM-211](#)
Piston to bore clearance(QR20DE•QR25DE) ... [EM-93](#)
Piston to bore clearance(YD22DDTi) [EM-214](#)
PNP/SW - Wiring diagram [EC-347](#), [EC-1066](#), [EC-1563](#)
PNPSW1 - Wiring diagram [EC-706](#), [EC-1354](#)
POS - Wiring diagram [EC-229](#), [EC-553](#), [EC-958](#),
[EC-1242](#)
POWER - Wiring diagram [PG-3](#)
Power antenna [AV-16](#)
Power door lock [BL-11](#)
Power socket [WW-27](#)
Power steering fluid level [PS-5](#), [MA-40](#)
Power steering gear [PS-12](#)
Power steering oil pressure switch [EC-1568](#)
Power steering oil pump [PS-24](#)
Power steering pressure (PSP) sensor [EC-255](#),
[EC-568](#), [EC-983](#), [EC-1257](#)
Power supply routing [PG-2](#)
Power window [GW-23](#)
Precations for Leak detection dye [ATC-12](#)
Precautions (General) [GI-4](#)
Pressure plate - See Clutch cover [CL-15](#)
PRGVLV - Wirng diagram [EC-694](#), [EC-1342](#)
Propeller shaft [PR-2](#)
Propeller shaft on vehicle service [PR-2](#)
PS/SEN - Wiring diagram .. [EC-257](#), [EC-570](#), [EC-985](#),
[EC-1259](#)
PST/SW - Wiring diagram [EC-1569](#)

Q

Quick-glow system [EC-1544](#)

R

R/FOG - Wiring diagram [LT-37](#)
Radiator fan - See Cooling fan(QR20DE•QR25DE)
[CO-12](#)
Radiator fan - See Cooling fan(YD22DDTi) [CO-33](#)
Radiator(QR20DE•QR25DE) [CO-11](#), [CO-14](#)
Radiator(YD22DDTi) [CO-32](#), [CO-35](#)
Radio - See Audio [AV-3](#)
Rear air spoiler [EI-21](#)
Rear bumper [EI-9](#)
Rear cover packing replacement diff. [RFD-10](#)
Rear disc brake [BR-26](#)
Rear door [BL-8](#)
Rear fog lamp [LT-37](#)
Rear panel finisher [EI-22](#)
Rear seat [SE-11](#)
Rear seat belt [SB-4](#)

ALPHABETICAL INDEX

Rear side window [GW-6](#)
Rear suspension [RSU-5](#)
Rear washer [WW-13](#)
Rear window defogger [GW-10](#)
Rear wiper [WW-13](#)
Refrigerant connection precaution [ATC-5](#)
Refrigerant discharging evacuating charging [ATC-129](#)
Refrigerant general precaution [ATC-5](#)
Refrigerant lines [ATC-129](#)
Refrigerant pressure sensor [EC-412](#), [EC-733](#),
[EC-1099](#), [EC-1373](#), [ATC-18](#), [ATC-85](#), [ATC-143](#)
Refrigeration cycle [ATC-18](#)
Release bearing (clutch) [CL-13](#)
Removal and installation (A/T) [AT-418](#)
Reverse idler shaft (M/T) [MT-18](#), [MT-23](#)
Reverse lamp switch (M/T) - See Back-up lamp switch
(M/T) [MT-12](#)
Reverse main gear (M/T) [MT-18](#), [MT-23](#)
Rocker cover(QR20DE•QR25DE) [EM-35](#)
Rocker cover(YD22DDTi) [EM-156](#)
Room lamp [LT-55](#)
Room lamp - See Interior lamp [LT-55](#)
ROOM/L - Wiring diagram [LT-55](#)
RP/SEN - Wiring diagram [EC-413](#), [EC-734](#), [EC-1100](#),
[EC-1374](#)
RRO2 - Wiring diagram [EC-678](#), [EC-1327](#)
RRO2/H - Wiring diagram [EC-663](#), [EC-1313](#)

S

S/LOCK - Wiring diagram [BL-13](#), [BL-32](#)
S/SIG - Wiring diagram [EC-402](#), [EC-723](#), [EC-1089](#),
[EC-1363](#), [EC-1566](#)
SCTC/V - Wiring diagram [EC-1522](#)
Seat belt inspection [MA-42](#)
Seat belt pre-tensioner disposal [SRS-41](#)
Seat belt, front [SB-3](#)
Seat belt, rear [SB-4](#)
Seat, front [SE-7](#)
Seat, rear [SE-11](#)
Self-diagnosis (Transfer) [TF-45](#)
SEN/PW - Wiring diagram [EC-342](#), [EC-622](#)
Sheft warning system [BL-76](#)
SHIFT - Wiring diagram [AT-407](#)
Shift control components (M/T) [MT-20](#), [MT-25](#)
Shift fork (M/T) [MT-20](#), [MT-25](#)
Shift lever [MT-13](#)
Shift lock system [AT-406](#)
Shift schedule [AT-521](#)
Shift solenoid valve A (A/T) .. [AT-131](#), [AT-136](#), [AT-148](#)
Shift solenoid valve B (A/T) [AT-131](#), [AT-136](#)
Side air bag (satellite) sensor [SRS-38](#)
Side trim [EI-26](#)
Side window - See Rear side window [GW-6](#)
Spark plug replacement(QR20DE•QR25DE) .. [MA-24](#)
Spark plug(QR20DE•QR25DE) [EM-30](#)
Specification value [EC-111](#), [EC-502](#), [EC-843](#), [EC-1188](#)
Speedometer [DI-4](#), [DI-24](#)
Spiral cable [SRS-33](#)

Spot lamp [LT-65](#)
SROOF - Wiring diagram [RF-4](#)
SRS - See Supplemental Restraint System [SRS-5](#)
SRS - Wiring diagram/LHD [SRS-10](#)
SRS - Wiring diagram/RHD [SRS-12](#)
SRS Trouble diagnoses [SRS-7](#)
Stall test (A/T) [AT-64](#), [AT-265](#)
Standardized relay [PG-72](#)
START - Wiring diagram [SC-21](#), [SC-22](#)
Start signal [EC-401](#), [EC-722](#), [EC-1088](#), [EC-1362](#),
[EC-1566](#)
Starter [SC-20](#)
Starting system [SC-20](#)
Steering gear and linkage inspection [MA-40](#)
Steering knuckle [FAX-7](#)
Steering linkage [PS-12](#)
Steering wheel and column [PS-6](#), [PS-9](#)
Stop lamp [LT-26](#), [LT-42](#)
Stop lamp switch [EC-349](#), [EC-625](#), [EC-1068](#), [EC-1301](#)
STOP/L - Wiring diagram [LT-26](#), [LT-42](#)
Strut (rear) [RSU-8](#)
Suction control valve [EC-1519](#)
Sunload sensor [ATC-105](#), [ATC-107](#), [ATC-114](#)
Sunroof [RF-3](#)
Super lock [BL-29](#)
Supplemental Restraint System [SRS-5](#)
Supplemental restraint system - Wiring diagram/LHD ..
[SRS-10](#)
Supplemental restraint system - Wiring diagram/RHD .
[SRS-12](#)
Suspension [MA-41](#)
Symbols and abbreviations [GI-9](#), [GI-21](#)
Symptom matrix chart [EC-77](#), [EC-469](#), [EC-809](#),
[EC-1156](#), [EC-1416](#)
Synchronizer (M/T) [MT-18](#), [MT-23](#)
System readiness test (SRT) code [EC-48](#), [EC-781](#)

T

T/MTR - Wiring diagram [EC-1014](#), [EC-1277](#)
Tachometer [DI-4](#), [DI-24](#)
Tail lamp [LT-30](#), [LT-40](#)
TAIL/L - Wiring diagram [LT-30](#)
Tailgate lamp [LT-30](#)
TCM circuit diagram [AT-15](#)
TCM inspection table [AT-106](#), [AT-306](#)
THEFT - Wiring diagram [BL-76](#)
Thermal protector [ATC-85](#)
Thermostat(QR20DE•QR25DE) [CO-20](#)
Thermostat(YD22DDTi) [CO-42](#)
Three way catalyst function [EC-239](#), [EC-968](#)
Three way catalyst precautions [GI-5](#)
Three way catalyst(QR20DE•QR25DE) [EM-24](#)
Throttle control motor [EC-290](#), [EC-598](#)
Throttle control motor relay [EC-285](#), [EC-593](#), [EC-1018](#),
[EC-1281](#)
Throttle position sensor (TPS) [EC-154](#), [EC-212](#),
[EC-337](#), [EC-339](#), [EC-367](#), [EC-528](#), [EC-540](#), [EC-617](#),
[EC-619](#), [EC-644](#), [EC-886](#), [EC-1214](#)

ALPHABETICAL INDEX

Throwout bearing - See Clutch release bearing [CL-13](#)
 Time control system [BCS-3](#)
 Timing chain(QR20DE•QR25DE) [EM-37](#)
 Timing chain(YD22DDTi) [EM-167](#), [EM-172](#)
 TM/RLY - Wiring diagram [EC-1020](#), [EC-1283](#)
 Torque converter installation [AT-419](#), [AT-514](#)
 TPS - Wiring diagram [EC-889](#), [EC-1218](#)
 TPS1 - Wiring diagram [EC-214](#), [EC-543](#)
 TPS2 - Wiring diagram [EC-156](#), [EC-530](#)
 TPS3 - Wiring diagram [EC-369](#), [EC-647](#)
 Transfer control unit inspection table [TF-42](#), [TF-49](#)
 Transmission case (M/T) [MT-17](#), [MT-22](#)
 Trouble diagnoses [GI-9](#)
 Turbocharger charge air cooler(YD22DDTi) ... [EM-122](#)
 Turbocharger precautions [GI-6](#)
 Turbocharger(YD22DDTi) [EM-127](#)
 TURN - Wiring diagram [LT-17](#), [LT-19](#)
 Turn signal lamp [LT-17](#), [LT-42](#)
 Two trip detection logic [EC-44](#), [EC-454](#), [EC-777](#),
[EC-1141](#)

V

Vacuum hose (brake system) [BR-19](#)
 Vacuum hose drawing (Engine control) [EC-32](#),
[EC-442](#), [EC-764](#), [EC-1128](#)
 Vacuum pump(YD22DDTi) [EM-139](#)
 Valve clearance(QR20DE•QR25DE) [EM-53](#)
 Valve clearance(YD22DDTi) [EM-163](#)
 Valve guide(QR20DE•QR25DE) [EM-65](#)
 Valve guide(YD22DDTi) [EM-189](#)
 Valve lifter(QR20DE•QR25DE) [EM-46](#)
 Valve lifter(YD22DDTi) [EM-161](#)
 Valve seat(QR20DE•QR25DE) [EM-66](#)
 Valve seat(YD22DDTi) [EM-190](#)
 Valve spring(QR20DE•QR25DE) [EM-67](#)
 Valve spring(YD22DDTi) [EM-192](#)
 Variable induction air control system (VIAS) .. [EC-393](#),
[EC-714](#)
 VDC -Wiring diagram [BRC-69](#)
 Vehicle speed sensor (VSS) [EC-250](#), [EC-563](#), [EC-978](#),
[EC-1252](#), [EC-1489](#)
 Ventilation air filter [ATC-121](#)
 VIAS - Wiring diagram [EC-395](#), [EC-716](#)
 VSS - Wiring diagram [EC-252](#), [EC-565](#), [EC-980](#),
[EC-1254](#), [EC-1490](#)

W

WARN - Wiring diagram [DI-44](#), [DI-50](#)
 Warning chime [DI-58](#)
 Warning lamps [DI-43](#)
 Washer, front [WW-4](#)
 Washer, rear [WW-13](#)
 Water control valve(QR20DE•QR25DE) [CO-20](#)
 Water pump(QR20DE•QR25DE) [CO-18](#)
 Water pump(YD22DDTi) [CO-39](#)
 Water temperature gauge [DI-4](#), [DI-24](#)
 Weatherstrip - See Exterior [BL-10](#)

Wheel alignment (front) [FSU-6](#)
 Wheel alignment (rear) [RSU-6](#)
 Wheel balance [WT-4](#), [MA-38](#)
 Wheel bearing (front axle) [FAX-7](#)
 Wheel bearing (rear) [RAX-6](#)
 Wheel hub (front) [FAX-7](#)
 Wheel hub (rear) [RAX-6](#)
 Wheel sensor (VDC) [BRC-121](#)
 Wheel sensors (ABS) [BRC-49](#)
 WINDOW - Wiring diagram [GW-27](#)
 Window, back [GW-8](#)
 Window, back door [GW-8](#)
 Window, door [GW-44](#), [GW-46](#)
 Window, rear side [GW-6](#)
 Window, side - See Rear side window [GW-6](#)
 WIP/R - Wiring diagram [WW-13](#)
 WIPER - Wiring diagram [WW-6](#)
 Wiper and washer [WW-4](#)
 Wiper, front [WW-4](#)
 Wiper, rear [WW-13](#)
 Wiring Diagram (Cell code) list [PG-60](#)
 Wiring diagrams [GI-13](#)
 Withdrawal lever (clutch) [CL-13](#)
 Wrist pin - See Piston pin inspection(QR20DE•QR25DE)
 [EM-89](#)

A
B
C
D
E
F
G
H
I
J
K
L

IDX