054G7–05

PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
A door is opened within 20 seconds of unlocking all doors, but automatic lock function still operates.	1. Door control transmitter 2. ECU power source circuit 3. Wireless turner circuit 4. Key unlock warning switch circuit 5. Door key lock and unlock switch circuit 6. Driver door ECU 7. Theft warning ECU assy (Theft deterrent ECU)	05–2939 05–2924 05–2934 05–3010 05–2545 05–2516 05–3059
Lock or unlock does not operate.	1. Door unlock detection switch circuit (Driver side door) (Passenger side door) (Rear LH door) (Rear RH door) 2. Door key lock and unlock switch circuit 3. ECU power source circuit 4. Any door ECU 5. Theft warning ECU assy (Theft warning ECU)	 05–2564 05–2566 05–2568 05–2570 05–2545 05–2551 05–2516 05–3059
A door is opened within 30 seconds of unlocking all doors, but automatic lock function still operates.	1. Door courtesy switch circuit (Driver side door) (Passenger side door) (Rear LH door) (Rear RH door) 2. Any door ECU 3. Theft warning ECU assy (Theft warning ECU)	 05–2596 05–2599 05–2602 05–2605 05–2516 05–3059
Wireless door lock function operates, but buzzer does not sound.	1. Wireless door lock buzzer circuit 2. Wireless buzzer volume and ON/OFF switch circuit 3. Door unlock detection switch circuit (Driver side door) (Passenger side door) (Rear LH door) (Rear RH door) 4. Any door ECU 5. Theft warning ECU assy (Theft warning ECU)	05–2928 05–2931 05–2564 05–2566 05–2568 05–2570 05–2516 05–3059
Wireless door lock function operates, but headlamp does not operate.	1. Headlamp relay circuit 2. Front controller 3. Theft warning ECU assy (Theft warning ECU)	05–1453 05–1340 05–3059
Wireless door lock function operates, but taillamp does not operate.	1. Taillamp relay circuit 2. Luggage room J/B ECU 3. Theft warning ECU assy (Theft warning ECU)	05–1478 05–1340 05–3059
Buzzer sounds, but wireless door lock function does not operate.	1. Door control transmitter 2. Theft warning ECU assy (Theft warning ECU)	05–2939 05–3059
Luggage compartment door does not open.	1. Luggage compartment door closer motor circuit 2. ECU power source circuit 3. Luggage room J/B ECU 4. Theft warning ECU assy (Theft warning ECU)	05–2806 05–2789 05–2768 05–3059