(Cont. next page) 1

Power Source


1
2
3
4
B-G
B-G
SB(*4)
B-W
SB
SB(*5)
B
(*1)
I26
Ignition SW
AM1
ACC
IG1
7A
6B
6D
IV1
3Q
3C
3E
3K
3I
2E
2Q
2I
2G
2C
2D
J24
Junction
Connector
Double Lock
Control Relay
<1-48>
7.5A ACC
ACC Relay
7.5A AM1
Body ECU
ACC
SIG
BDR1
25A DOOR
10A ECU-IG1
10A GAUGE1
IG1
NO. 2
Relay
15A DBL LOCK
7.5A IDLE UP
20A DEFOG
DEFOG Relay
ACC
CUT
Relay
7.5A
SECURITY
20A P/W (FR)
20A P/W (FL)
20A P/W (RR)
20A P/W (RL)
Engine Control and
Fuel Tank Changeover
System<8-3>
Option Connector
(Glass Breakage
Sensor)<1-24>
Theft Deterrent
Siren<1-24>
Theft Deterrent
ECU<1-25>
Power Window Control
SW Front RH<1-26>
Power Window
Master SW
<1-30>
Power Window Control
SW Rear RH<1-29>
Power Window Control
SW Rear LH<1-27>
Theft
Deterrent
ECU<1-25>
Option Connector
(Glass Breakage
Sensor)<1-24>
Rear Window
Defogger System
<19-2>
F37(A), F38(B), F39(C)
Fusible Link Block
120A
J/B
NO. 3
120A
J/B
NO. 1
120A
J/B
NO. 2
120A
MAIN
140A
ALT
(Diesel)
Battery
Battery
IF
Set Bolt of Cowl Side
J/B LH

* 1 : 2UZ-FE
* 2 : 2UZ-FE A/T
* 3 : 2UZ-FE M/T
* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock

Multiplex Communication System

* 1 : 2UZ-FE
* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
* 6 : w/ Moon Roof
* 7 : w/o Moon Roof w/ Overhead Console
* 8 : w/o Moon Roof w/o Overhead Console


5
6
7
8
B-G
B-G
SB(*4)
B-W
SB
SB
(*5)
B
(*1)
B12(A), B13(B), B14(C)
Body ECU
RDEF
LMRY
ILE
27 A
3 A
13
(*1) B
R-W
R
1 2G
8 2L
2
3
DOME Relay
1
5
9 2K
79 2Q
L-Y
SB
F26
Front Personal Light
V18
Vanity Light LH
V19
Vanity Light RH
W-B
8 Ba1
(*6) R
(*7) R
(*6) W
4 A (*6)
3 B (*7)
R34(A), (B)
Rear Personal Light
DOOR
OFF
ON
1 A (*6)
1 B (*7)
3 A (*6)
2 B (*7)
11 Ba1
9 Ba1
(*6) W-B
(*7) W-B
(*6) G-W
(*7) G-W
(*6, *7) R
(*8) R
5 Ba1 (*6)
7 BZ2 (*7)
3 BZ1
1 BZ1
(*6, *7) W
(*8) W
R33
Rear Interior Light
F25
Front Interior Light
4 Ba1 (*6)
2 BZ2 (*7)
4 BZ1
2 BZ1
(*6, *7) G-Y
(*8) G-Y
(*8) G-W
(*7) G-W
(*6) G-W
3 2L
15 2E
22 2E
22 2K
4 2I
27 2Q
G-W
R
SB
T14
Ignition Key Cylinder Light
2
6
SB
R
R
G-Y(*8)
G-Y(*6, *7)
SB
B-G
B-G
B-W
L-Y
W-B
SB
SB(*4)
SB
(*5)

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
* 6 : w/ Moon Roof
* 7 : w/o Moon Roof w/ Overhead Console
* 8 : w/o Moon Roof w/o Overhead Console

Multiplex Communication System


9
10
11
12
B12(A), B13(B), B14(C)
Body ECU
PCYL
RCYL
DCYL
LCYL
LP
25 A
22 B
26 A
21 B
6 B
G-B
G-R
G-W
G-Y
8 IQ3
20 ID5
12 2E
18 2L
12 IW3
2 BE4
12 IC3
2 BB4
D16
Door Courtesy Light Front RH
D18
Door Courtesy Light Rear RH
D15
Door Courtesy Light Front LH
D17
Door Courtesy Light Rear LH
1 BE4
1 BB4
R
SB
80 3Q
22 3K
7 3J
(*8)
(*6, *7)
1 1C
64 1A
62 1A
B-G
R-B
1 EV1
2 EV1
F 5
Front Fog Light LH
F 6
Front Fog Light RH
W-B
3 EV1
Short Pin
(A)
30A BAT
15A TAIL
TAIL Relay
24 1B
51 1A
49 1B
L-O
G
25 3B
10A DOME
10A ECU-B2
17 3Q
71 3Q
44 3Q
Taillight System
<16-1>
SB
R
R
G-Y(*8)
G-Y(*6, *7)
SB
B-G
B-G
B-W
L-Y
W-B
G
SB
B-G
B-W
L-Y
W-B
SB
SB(*4)
SB
(*5)
SB
SB(*4)
SB
SB
(*5)
W-B
Front Right Side of
Fender Apron
EA

(Cont. next page) 1

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
* 9 : w/ HID
*10 : w/o HID
*11 : Europe

Multiplex Communication System


13
14
15
16
B12(A), B13(B), B14(C)
Body ECU
DRL
HDCL
7 A
5 A
R-Y
R
Rear Fog Light SW <36-2>
FR FOG Relay
15A FR FOG
HEAD Relay
HEAD HI Relay
10A HEAD LH-LWR
10A HEAD RH-LWR
20A HEAD RH-UPR
20A HEAD LH-UPR
9 2G
7 2B
61 1A
2 1C
59 1B
26 1A
9 1A
22 1B
8 1A
1 1B
12 1A
10 1B
G
B-G
G-Y
(Except *11)
G-W
(*11)
D34 Diode (Front Fog No. 2)
16 2A
53 2Q
24 1A
30 1A
23 1A
W-B
(*9)
(*10)
R-L
R-B
R-W
R-G
H 9 Headlight LH (Low)
H10 Headlight RH (Low)
H 8 Headlight RH (High)
H 6 Headlight Control ECU RH
H 7 Headlight LH (High)
H 5 Headlight Control ECU LH
Light Control ECU
High (HID)
6 IG1
Combination Meter <50-14><51-15>
SB
B-W
L-Y
SB(*4)
(*5)

(Cont. next page) 1

Multiplex Communication System

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*12 : w/ Daytime Running Light
*13 : w/o Daytime Running Light
*14 : Automatic A/C


17
18
19
20
B12(A), B13(B), B14(C)
Body ECU
HRLY
HR
HEAD
TAIL
A
HF
HU
CLTS
CLTB
CLTE
17
46 2Q
5 2B
11 2E
20 C
1 C
8 C
3 C
7 C
2 C
4 C
6 C
21 C
SB
R-W
J27 Junction Connector
B
J 6 Junction Connector
E
D
IF2
IH2
II6
IU1
Ij1
II5
R-B
G-B
G-O
R-Y
Y
R
BR
Rear Fog Light SW <36-3>
Headlight Cleaner SW<35-4>
D 7 Diode (Front Fog No. 1)
(*12)
Rear Fog Light SW <36-2>
Combination Meter <50-15><51-15>
J29 Junction Connector
C19 Combination SW
13 14 12 8
11 10 16 7
G-Y
G-O(*12)
W-B
(*13)
A66 Automatic Light Control Sensor
J15 Junction Connector
J 7 Junction Connector
H
(*14)
B-W
L-Y
SB(*4)
SB(*5)
(*5)
35 3E
8 3D
10 3D
9 3I
II
Set Bolt of Cowl Side J/B RH

C19 Combination SW

		BFG	LFG	HL	H	T	EL	A	HF	HU
Light Control SW	OFF									
	Tail					○	○			
	Head				○	○	○			
	Auto						○	○		
Dimmer SW	Low			○			○			
	High						○			○
	Flash						○		○	○
Fog Light SW	OFF									
	ON	○	○							

(Cont. next page) 1

Multiplex Communication System

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*14 : Automatic A/C
*15 : Except *14
*16 : w/ Navigation System
*17 : w/o Navigation System
*18 : w/o Power Window


21
22
23
24
B12(A), B13(B), B14(C)
Body ECU
BECU
11
T 9
Theft Deterrent ECU
+B2
E
HORN
IND
REV
DSWH
IOUT
S+B
CTLS
GBS
3
29
5
25
23
34
26
24
27
11
L-W
W-B
G-O
G-R
B
L-B
L-R
P-B
BR
Y-G
12 IL3
22 IL3
6 IL3
5 IL3
20 IL3
8 IL3
11 IL3
10 IL3
2 IL3
3 IL3
SB
Horn Relay <32-4>
DLC3 <7-8>
SECURITY Fuse <1-4>
26 2Q
22 2Q
19 2E
2 2I
3 4C
7 4E
82 3Q
4 3B
75 3Q
28 3K
12 3D
76 3Q
27 3E
6 EA2
12 IU1
13 IU1
14 IU1
21 ID5
22 ID5
(*14)
(*15)
(*5)
G-R
21 A (*16)
14 B (*17)
M 4(A), (B)
Multi-Display
LP(*16)
SECURITY(*17)
GND1(*16)
GND(*17)
3 A (*16)
8 B (*17)
33 A
SEC
GND
12 C
A57(A), A59(C)
A/C Control
Assembly
Transponder Key
Computer<7-4>
E 3
Engine Hood Courtesy SW
Z 3
Option Connector
(Radar Sensor)
T26
Theft Deterrent Siren
Z 1
Option Connector
(Glass Breakage
Sensor)
Z 8
Option Connector
(Microphone)
(Shielded)
W
LG
1
2
3
4
5
6
8
J13
Junction
Connector
J 6
Junction
Connector
A
SECURITY
Fuse<1-4>
ECU-IG1
Fuse<1-2>
B-W
W-B
(*14)
SB
B-W
L-Y
W-B
L-W
SB(*18)
L-W(*5)
SB(*4)
(*5)
(*18)
11 2L
20 2Q
2 2D
7 2E
43 2Q
8 2I
18 2E
10 2E
IF
Set Bolt of
Cowl Side J/B LH
EA
Front Right Side of
Fender Apron
BK
Front Side Under the
Front Seat RH

(Cont. next page) 1

Multiplex Communication System

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*18 : w/o Power Window


25
26
27
28
B12(A), B13(B), B14(C)
Body ECU
MPX3
26 C
KSW
14 C
MPX4
11 A
MPX5
14 B
T 9
Theft Deterrent ECU
SH-
+B1
IG
MPX1
KSW
1
2
10
31
12
W
LG
B-W
B
R-B
7 IL3
14 IL3
15 IL3
1 IL3
9 IL3
15 IU1
SB
SECURITY Fuse <1-4>
ECU-IG1 Fuse <1-2>
J24
Junction Connector
E
E SB
(*5)
84 3Q
6 3B
W
1
T 2
Theft Deterrent Horn
74 3Q
18 3E
23 3E
3 3P
25 3E
46 3Q
1 3P
R-B
W-B
Transponder Key Computer<7-4>
Combination Meter <50-10><51-11>
U 1
Unlock Warning SW
2
1
Y-B
11 IW3
P12
Power Window Control SW Front RH
8
11
MPX1
PCT
BDR
GND
SEL1
DN
UP
LMT
PLS
SGND
12
7
9
1
6
3
4
5
L
G
Y
L-Y
L-W
BR-B
P/W (FR) Fuse <1-4>
M
P18
Power Window Motor Front RH
19 ID5
11 BB4
10 BB4
P13
Power Window Control SW Rear LH
MPX1
PCT1
SEL2
1 BB3
10 BB3
12 BB4
4 ID5
P/W (RL) Fuse <1-4>
P19
Power Window Motor Rear LH
L-W
B-W
L-Y
SB(*18)
W-B
L-W(*5)
SB(*5)
SB(*4)
(*5)
BJ
Under the Front Seat LH

(Cont. next page) 1

Multiplex Communication System


29
30
31
32
B12(A), B13(B), B14(C)
Body ECU
MPX6
MPX1
UL1
L1
P14
Power Window Control SW Rear RH
MPX1
PCT1
BDR
GND
DN
UP
LMT
PLS
SGND
P15
Power Window Master SW
WLSW
MPX1
CPUB
SIG
BDR
DN
UP
LMT
PLS
SGND
KL
KUL
GND
KEYE
LSWD
IQ3
BE4
BE3
3K
3J
3Q
2Q
2K
2J
IC3
2I
2E
IF2
M
P20
Power Window Motor Rear RH
P17
Power Window Motor
Front LH
P/W (RR) Fuse
<1-4>
P/W (FL) Fuse
<1-4>
D23
Door Key Lock and
Unlock SW LH
Lock
Unlock
D 9
Door Lock Control SW
Unlock
Lock
J25
Junction
Connector
BW2
BK2
(*16)
(*17)
Bg1
Bf1
(*21)
(*20)
BK
Front Side Under
the Front Seat RH
Y-B
W
B
SB
G-O
G-W
L
G
Y
L-Y
L-W
BR-B
B-W
W-B
G-B
L-B(*5 *19)
L-B(*22 *19)
SB(*18)
L-W(*5)
SB(*5)
SB(*4)
W-B(*20)

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*16 : w/ Navigation System
*17 : w/o Navigation System
*18 : w/o Power Window
*19 : w/ Power Window
*20 : Liftgate Type
*21 : Swing Type
*22 : w/o Double Door Lock

(Cont. next page) 1

Multiplex Communication System


33
34
35
36
B12(A), B13(B), B14(C)
Body ECU
UL2
L2
RDA
PRG
DCTY
PCTY
RLCY
RRCY
BCTY
D24
Door Key Lock and Unlock SW RH
B 8(A), (B)
Back Door Key Lock and Unlock SW
D23
Door Key Lock and Unlock SW LH
Unlock
Lock
D38
Door Control Receiver
RDA
PRG
+B
E
Transponder Key Computer<7-3>
D19
Door Courtesy SW Front LH
D20
Door Courtesy SW Front RH
D21
Door Courtesy SW Rear LH
D22
Door Courtesy SW Rear RH
B 7
Back Door Courtesy SW
J31
Junction Connector
Bf1 (*20)
Bg1 (*21)
BK1 (*16)
BK2 (*17)
ID5
BW3
IQ3
2E
2K
3E
3K
3Q
3J
3I
2Q
2J
G-B
L-W
SB
L
V
L-Y
W-B
R-Y
R-B
R-L
R-G
L-Y
W-B
L-B(*22 *19)
L-B(*5 *19)
L-W(*5)
SB(*5)
SB
SB(*4)
SB
SB(*5)
W-B(*20)
W-B(*21)
W-B

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*16 : w/ Navigation System
*17 : w/o Navigation System
*18 : w/o Power Window
*19 : w/ Power Window
*20 : Liftgate Type
*21 : Swing Type
*22 : w/o Double Door Lock

(Cont. next page) 1

Multiplex Communication System


37
38
39
40
B12(A), B13(B), B14(C)
Body ECU
M2
M1
MM
LSWP
2 A
20 A
8 A
30 A
* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*19 : w/ Power Window
*20 : Liftgate Type
*21 : Swing Type
*22 : w/o Double Door Lock
5 3I
3 3I
5 3K
34 3K
39 3E
42 3E
19 IC3
18 IC3
17 IC3
1 BA1
2 BA1
4 BA1
3 BA1
D29
Driving Position
Memory SW
SET
D40
Door Lock Motor Front RH
Door Unlock Detection SW Front RH
Double Lock Motor Front RH
Double Lock Position SW Front RH
D26
Door Lock Motor Front RH
Door Unlock Detection
SW Front RH
D42(A)
Door Lock Motor Rear RH
Door Unlock Detection SW Rear RH
Double Lock Motor Rear RH
Double Lock Position SW Rear RH
D28(B)
Door Lock Motor Rear RH
Door Unlock Detection SW Rear RH
M
2 Bc1
3 Bc1
4 Bc1
8 Bc1
8 BE3
9 BE3
14 BE4
7 BE4
4 BE4
5 BE4
6 BE4
13 BE4
4 IW3
Y
L
R
W-B
L-O
L-B
V
Y-B
G-Y
GR-L
Y-G
Y-R
(*5)
(*22)
BK
Front Side Under the
Front Seat RH
L-B(*22 *19)
L-B(*5 *19)
L-W(*5)
SB(*5)
SB
SB(*4)
W-B(*20)
W-B(*21)
R(*5)
G-Y(*5)
Y-R(*5)
Y-B(*5)

(Cont. next page) 1

Multiplex Communication System

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*16 : w/ Navigation System
*17 : w/o Navigation System
*18 : w/o Power Window
*19 : w/ Power Window
*20 : Liftgate Type
*21 : Swing Type
*22 : w/o Double Door Lock

41	42	43	44


B12(A), B13(B), B14(C)
Body ECU
LSR
ACT-
ACT+
5
24
23
3 2G
11 2G
25 2K
42 2K
38 2K
3 2I
10 2I
L-B
V
GR-L
L-B(*5)
V(*5)
9 BF4
9 BB3
8 BB3
13 BB4
2 BO4
D41(A)
Door Lock Motor Rear LH
Door Unlock Detection SW Rear LH
Double Lock Motor Rear LH
Double Lock Position SW Rear LH
D27(B)
Door Lock Motor Rear LH
Door Unlock Detection SW Rear LH
M
(*5)
(*22)
12 BB4
7 BB4
6 BB4
5 BB4
6 BB4
W-B
Y-G
G-Y
R
J31
Junction
Connector
E
BJ
Under the Front
Seat LH
7 BW2
3 Bg2
1 BW2
2 Bg2
2 BW2
2 Bg2
(*20)
(*21)
3 BK1 (*16)
5 BK1 (*17)
6 BK2 (*16)
2 BK1 (*17)
5 BK2 (*16)
6 BK1 (*17)
B 9
Back Door Lock Motor and
Back Door Unlock Detection SW
W-B(*20)
W-B(*21)
3 BY1
2 BY1
8 BY1
4 BY1
D25
Door Lock Motor Front LH
Door Unlock Detection
SW Front LH
W-B(*5)
L-B(*22 *18)
(*22 *19)
R(*5)
G-Y(*5)
Y-R(*5)
Y-G(*5)
Y-B(*5)
L-B(*22 *19)
L-B(*5 *19)
L-W(*5)
SB(*5)
SB
SB(*4)
W-B(*20)
W-B(*21)

(Cont. next page) 1

* 4 : 2UZ-FE, 1HD-FTE
* 5 : w/ Double Door Lock
*18 : w/o Power Window
*19 : w/ Power Window
*22 : w/o Double Door Lock

Multiplex Communication System


45
46
47
48
B12(A), B13(B), B14(C)
Body ECU
LSWD
21 A
L-B (*18)
16 IC3
L-B
(*5 *18)
L-B (*22 *18)
D37
Double Lock Control Relay
ACTR
ACTS
DLPD
DLPR
DLPP
DLPL
CPUB
MPX1
+B
GND
4 R (*5)
3 G-Y (*5)
5 Y (*5)
11 Y-R (*5)
6 Y-B (*5)
12 Y-G (*5)
7 L-W (*5)
9 B (*5)
1 B (*5)
14 W-B (*5)
20 IU5
21 IU5
2 Ib3
4 Ib3
3 Ib3
26 IU5
SB (*5)
B
J30
Junction Connector
B
15 IC3
15 IQ2
3 IW3
19 IU5
22 IU5
12 IU5
28 2Q
84 2Q
36 3Q
62 3Q
34 3Q
72 2Q
1 2J
30 2K
27 3K
12 3J
29 3K
5 3J
8 2J
28 2K
2 4F
9 4A
C
A
G
J30
Junction Connector
DBL LOCK Fuse
<1-2>
L-B(*5)
V(*5)
V (*5)
L-B (*5)
3
2
D39
Door Lock Motor Front LH
Door Unlock Detection SW Front LH
Double Lock Motor Front LH
Double Lock Position SW Front LH
M
M
7
8
4
1
5
6
W-B (*5)
L-B (*5 *19)
W-B (*5)
Y (*5)
G-Y (*5)
R (*5)
W-B(*5)
L-B(*22 *18)
R(*5)
G-Y(*5)
Y-G(*5)
R(*5)
G-Y(*5)
Y-R(*5)
R(*5)
G-Y(*5)
Y-B(*5)
L-B(*5 *19)
L-W(*5)
SB(*5)
SB
SB(*4)
SB
SB(*5)
SB
SB(*4)
SB

Multiplex Communication System

* 1 : 2UZ-FE
* 4 : 2UZ-FE, 1HD-FTE
*11 : Europe
*14 : Automatic A/C
*16 : w/ Navigation System
*23 : 1HD-FTE
*24 : Except *23
*25 : Middle East


49
50
51
52
B12(A), B13(B), B14(C)
Body ECU
DCY2
ACC
SIG
BDR1
SPD
ACAN
BDSU
DBKL/
DBKLR
TC
OBD2
P
L
ELS1
11 C
22
10
12
14
5 C
17 A
13 A
18 C
17 C
17 B
14 A
15 A
R-Y
3 IU1
SB
(*4) SB
9 IU5
(*4) B
C18
Combination Meter
10
19
13
11
12
1
20
(*4) SB
SB
SB
SB
(*4) SB
8 IV1
SB
SB(*4)
SB
(*23) BR
(*24) BR
ED
Rear Bank of Left
Cylinder Head
EC
Rear Bank of Right
Cylinder Head (2UZ-FE)
Rear Bank of Left
Cylinder Head (1HZ, 1FZ-FE)
G 4
Gateway ECU
MPD1
MPD2
4
11
(*16) B
(*16) P-B
3 4F
6 4E
4 4E
12 4C
10 4A
3 4C
(*4) B
(*14) B
(*14) P-B
29 A (*1)
29 B (*23)
MPX2
MPX1
18 A (*1)
18 B (*23)
E10(A), E18(B)
Engine ECU
Engine and ECT ECU
19
39
MPX+
MPX-
A57
A/C Control Assembly
(*4) P-B
24 2E
66 2Q
(*4) SB
Multiplex Communication
System<1-1>
Combination Meter
System<50-6><51-6>
W-L
21 3E
26 3E
13 3D
10 3Q
(*11) W-L
SB
Multi-Display
<46-4><47-14>
Combination Meter
<50-13><51-9>
(*11, *25) W-L
8 4A
17 4A
6 4B
(*11, *25) W-L
(*11, *25) W-L
A/C Control Assembly
<53-14>
Radio and Player
<47-8><48-4>
G-Y
G
B
4 IU1
SB
V-W
G-W
2 IU1
SB
B
G-W
1 5B
10 5C
G-W
Suspension Control
ECU<23-3>
Buckle SW LH
<42-3>
Rheostat
<17-2>
DLC3
<7-7>
Neutral Start SW
<11-10><12-10><13-11>
Alternator
<2-3><3-4>
Engine ECU
Engine and ECT ECU<8-14>

Multiplex Communication System


53
54
55
B12(A), B13(B), B14(C)
Body ECU
MPX2
23 A
HAZ
8
PWS
21
TRLY
18
IDL
28 A
GND2
16
GND1
4
PKB
2 B
B
25 2Q
9 2L
24 2B
SB
L
R-W
4 2G
12 2D
7 2Q
14 2K
Turn Signal Flasher
<15-4>
Moon Roof Control ECU
<30-3>
Taillight System
<16-1>
Combination Meter
<50-20><51-19>
B
B
4 Ib2
B
2
MPX2
A65
Auto Wiper ECU
SB
4
MPX1
MPX2
9
S32
Seat ECU
R47
Remote Control
Mirror ECU
MPX2
MPX1
25
13
B
B
B
23 ID5
7 IC4
20 IC3
B
B
B
37 3Q
41 3E
41 3D
40 3D
B
B
3
8
MPX1
MPX2
T11
Tilt and Telescopic ECU
Set Bolt of
Cowl Side J/B LH
IG
IF
Set Bolt of
Cowl Side J/B LH