



A line drawing diagram showing the installation of a seat belt pre-tensioner connector. A person is shown from the side, wearing a seat belt. A black arrow points to the 'C-18 or C-31 Harness side connector (2-pin, black)' which is being inserted into the 'C-18 or C-31 Seat belt pre-tensioner connector (2-pin)'. A 'Locking button' is shown on the side of the pre-tensioner connector. A 'Flat-tipped screwdriver' is shown inserted into the bottom of the pre-tensioner connector. The diagram is set against a background of vertical lines representing the car's interior structure.

**C-18 or C-31
Harness side
connector
(2-pin, black)**

**C-18 or C-31
Seat belt
pre-tensioner
connector (2-pin)**

**Locking
button**

**Flat-tipped
screwdriver**

AC208430AC