

REMOVAL

1. HEAT MOULDING

Using a heat light, heat the moulding between 20 to 30°C (68 to 86 °F).

NOTICE:

Do not heat the moulding excessively.

2. REMOVE MOULDING

- (a) Insert piano wire between the vehicle body and moulding.
- (b) Tie objects that can serve a handle (for example, wooden blocks) to all wire ends.
- (c) Cut off the double-sided tape by pulling the piano wire as shown in the illustration.

NOTICE:

Do not damage the body.

- (d) Remove the moulding.

