



## INSTALLATION

### 1. INSTALL UPPER BALL JOINT

- (a) Using SST and a socket wrench, install a new ball joint.  
SST 09309-37010
- (b) Using a snap ring expander, install a new snap ring.
- (c) Install a new boot and fix it with a new wire.

#### HINT:

Use the grease supplied in the kit.

### 2. INSTALL STEERING KNUCKLE WITH AXLE HUB (See page [SA-26](#))