

INSTALLATION

1. INSTALL REAR SHOCK ABSORBER

- (a) Install the 2 retainers and cushion to the shock absorber.
- (b) Install the shock absorber, cushion and retainer with the nut.

Torque: 20 N·m (200 kgf·cm, 15 ft·lbf)

- (c) Install the lower side of the shock absorber with the bolt and nut.

Torque: 87 N·m (890 kgf·cm, 64 ft·lbf)

2. INSTALL REAR WHEEL

Torque: 110 N·m (1,150 kgf·cm, 83 ft·lbf)

3. REMOVE SAFETY STANDS