



INSTALLATION

1. INSTALL VSV FOR ACIS

- (a) Install the VSV to the intake manifold with the bolt.

Torque: 7.5 N·m (76 kgf·cm, 66 in.-lbf)

- (b) Connect the 2 vacuum hoses to the VSV.

2. INSTALL INTAKE MANIFOLD ASSEMBLY

(See page [EM-60](#))

3. INSTALL THROTTLE BODY COVER