

Engine & Cooling

Fuel

Ignition

Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system145, 146 1.3ie1994 to 1997

Type	AR 33501 SOHC 66kW	
Capacity (cm³) / number of cylinders	1351 / 4	
Compression ratio / pressure	bar	9.5 / 10.3
Oil pressure	bar	0.8 [4.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order	1-3-2-4	
No 1 cylinder position	FR	
Thermostat opening temperature	°C	86±2
Radiator cap pressure	bar	1.0±0.1

Fuel system145, 146 1.3ie1994 to 1997

Idle speed - manual [auto]	rpm	850±50
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	—
HC @ idle speed [3000 rpm] - see page VI	ppm	—
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection	_Weber-Marelli	
Type / ref	IAW-8F.6B	
Main jet / needle	—	
Injection pressure	bar	2.8 to 3.2
Pump pressure	bar	≤4.0
Octane rating	RON	95[U]

Ignition system145, 146 1.3ie1994 to 1997

Type	IAW	
Ignition coil		
Primary resistance	ohms	—
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor	—	
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation	—	
Ignition timing - basic [static	° Crankshaft @ rpm	N/A
V = Vacuum NV = No Vacuum		
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs	Lodge	
Type	25HL	
Electrode gap	mm	N/A

Electrical system145, 146 1.3ie1994 to 1997

Battery	V / CC / RC	12 / 45Ah
Alternator voltage / full load current / engine rpm	14 / 65 / _	
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear145, 146 1.3ie1994 to 1997

Brakes -		
Front (min. friction material thickness)	mm	1.5
Rear (min. friction material thickness)	mm	1.5

Tyres		
Saloon	Size	175/65x14: 185/60x14
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.2 / 2.0
- Estate / Van	bar	—

Front suspension / wheel alignment

Toe-in (+) / Toe-out (–)	mm [°]	+3.5±1.0
Camber	+10'±20'	
Castor	+3°20'±30'	
King pin inclination	—	

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (–)	mm [°]	+4.0±2.0
Camber	-1°±15'	

Torque wrench settings145, 146 1.3ie1994 to 1997

Cylinder head - stage 1	Nm	30
- stage 2	Nm	60
Cylinder head - stage 3	Nm	91 to 101
- stage 4	Nm	—
Big-end bearings	Nm	53 to 58 oiled
Main bearings	Nm	67 to 74. Side: 41 to 50 oiled
Clutch cover	Nm	19 to 23
Flywheel [driveplate]	Nm	97 to 107 oiled
Front hubs	Nm	266 to 294
Rear hubs	Nm	266 to 294
Wheel nuts / bolts	Nm	83 to 103
Spark plugs	Nm	25 to 34

Capacities145, 146 1.3ie1994 to 1997

Engine oil & filter	litres	4.0
Gearbox - 4-speed [5-speed]	litres	2.4
Automatic transmission - refill	litres	—
Final drive	litres	WT
Cooling system	litres	6.7
Fuel tank	litres	51

Notes and Illustrations

—
