

Engine & Cooling

Fuel

Ignition


Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system75, 1.8IE1989 to 1992

Type		061.68 DOHC (88kW)
Capacity (cm³) / number of cylinders		1779 / 4
Compression ratio / pressure	bar	9.5 / _
Oil pressure	bar	[3.4 to 4.9]
Oil temperature	°C	90
Valve clearance - inlet	mm	0.40 to 0.45
Valve clearance - exhaust	mm	0.45 to 0.50
Firing order		1-3-4-2
No 1 cylinder position		TCE
Thermostat opening temperature	°C	81 to 85
Radiator cap pressure	bar	0.69

Fuel system75, 1.8IE1989 to 1992

Idle speed - manual [auto]	rpm	900±50
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤300
CO2 @ idle speed [3000 rpm] - see page VI	%	_
O2 @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		Bosch
Type / ref		L-Jetronic
Main jet / needle		_
Injection pressure	bar	_
Pump pressure	bar	2.7 to 3.1
Octane rating	RON	98[E 95 RON]

Ignition system75, 1.8IE1989 to 1992

Type		Electronic
Ignition coil		Bosch 0 221 122 344
Primary resistance	ohms	0.5±10%
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		Bosch
Points gap (air gap)	mm	_
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation		Clockwise
Ignition timing - basic [static	° Crankshaft @ rpm	10±1 BTDC @ 900±50
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Vacuum range check	mbar	_
Maximum vacuum advance	° Crankshaft	_
Spark plugs		Lodge/Champion
Type		2HL / RN7YCC
Electrode gap	mm	Champion: 0.80

Electrical system75, 1.8IE1989 to 1992

Battery	V / CC / RC	12 / 255 / 55Ah
Alternator voltage / full load current / engine rpm		14.0 / _ / 3000
Starter motor current / voltage - cranking	A / V	220 to 250 / 9.0 to 9.8
- locked	A / V	290 to 480 / 5.0 to 7.4

Running gear75, 1.8IE1989 to 1992

Brakes -		
Front (min. friction material thickness)	mm	7.0 with backing
Rear (min. friction material thickness)	mm	7.0 with backing

Tyres		
Saloon	Size	185/70x13: 185/65x14
Estate / Van	Size	_
Pressure - front / rear - Saloon	bar	1.8 / 2.0
- Estate / Van	bar	_

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	-1.0±1.0
Camber		-30'±30'
Castor		+3°30'±30'
King pin inclination		_

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	[0±10']
Camber		0±30'


Torque wrench settings75, 1.8IE1989 to 1992

Cylinder head - stage 1	Nm	71 to 73
- stage 2	Nm	Warm up, 75 to 76
Cylinder head - stage 3	Nm	1000km: - 360°
- stage 4	Nm	76 to 78
Big-end bearings	Nm	49 to 52 oiled
Main bearings	Nm	46 to 49 oiled
Clutch cover	Nm	13 to 16
Flywheel [driveplate]	Nm	113, LkC
Front hubs	Nm	WSM
Rear hubs	Nm	265 to 324
Wheel nuts / bolts	Nm	98
Spark plugs	Nm	25 to 34 oiled


Capacities75, 1.8IE1989 to 1992

Engine oil & filter	litres	5.6
Gearbox - 4-speed [5-speed]	litres	2.3
Automatic transmission - refill	litres	_
Final drive	litres	WT
Cooling system	litres	8.0
Fuel tank	litres	49

Notes and Illustrations



1779 cm³



1779 cm³