

Engine & Cooling

Fuel

Ignition

Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling systemA8, 3.71995 to 1997

Type	AEW DOHC 32V 169kW	
Capacity (cm³) / number of cylinders	3697 / 8	
Compression ratio / pressure	bar	10.8 / ≥7.5
Oil pressure	bar	1.0 to 2.5 [3.0 to 5.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order	1-5-4-8-6-3-7-2	
No 1 cylinder position	PER	
Thermostat opening temperature	°C	87 to 102
Radiator cap pressure	bar	1.2 to 1.5

Fuel systemA8, 3.71995 to 1997

Idle speed - manual [auto]	rpm	720 to 800 N/A
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection	_ Bosch	
Type / ref	Motronic	
Main jet / needle	—	
Injection pressure	bar	3.0 to 3.6
Pump pressure	bar	4.2
Octane rating	RON	95[U]

Ignition systemA8, 3.71995 to 1997

Type	Direct electronic	
Ignition coil	—	
Primary resistance	ohms	—
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor	—	
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation	—	
Ignition timing - basic [static	° Crankshaft @ rpm	Computer control N/A
V = Vacuum NV = No Vacuum		
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs	NGK	
Type	BUR6-EFSZ	
Electrode gap	mm	—

Electrical systemA8, 3.71995 to 1997

Battery	V / CC / RC	—
Alternator voltage / full load current / engine rpm	—	
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gearA8, 3.71995 to 1997

Brakes -		
Front (min. friction material thickness)	mm	3.0
Rear (min. friction material thickness)	mm	7.0 with backing

Tyres		
Saloon	Size	225/60x16: 225/55x17
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.2 / 2.2
- Estate / Van	bar	—

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	[+15'±5'] PW
Camber	-30'±30' PW	
Castor	—	
King pin inclination	—	

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	[+6'±5'] PW
Camber	-40'±30' PW	

Torque wrench settingsA8, 3.71995 to 1997

Cylinder head - stage 1	Nm	40 N
- stage 2	Nm	60
Cylinder head - stage 3	Nm	+90°
- stage 4	Nm	+90°
Big-end bearings	Nm	—
Main bearings	Nm	—
Clutch cover	Nm	—
Flywheel [driveplate]	Nm	85 LkC N
Front hubs	Nm	200 + 90°
Rear hubs	Nm	200 + 90°
Wheel nuts / bolts	Nm	120
Spark plugs	Nm	30

CapacitiesA8, 3.71995 to 1997

Engine oil & filter	litres	7.5
Gearbox - 4-speed [5-speed]	litres	—
Automatic transmission - refill	litres	3.0
Final drive	litres	Front: 0.7. Rear: 1.5
Cooling system	litres	9.0
Fuel tank	litres	90

Notes and Illustrations

—

