

Engine & Cooling

Fuel

Ignition


Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling systemFiesta 1.3, Van & Courier1991 to 1994

Type		JBC HCS 44kW. 15.05
Capacity (cm ³) / number of cylinders		1297 / 4
Compression ratio / pressure	bar	9.5 / 13 to 16
Oil pressure	bar	0.6 [1.5]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.20
Valve clearance - exhaust	mm	0.30 to 0.35
Firing order		1-2-4-3
No 1 cylinder position		TCE
Thermostat opening temperature	°C	85 to 89
Radiator cap pressure	bar	1.2 to 1.4

Fuel systemFiesta 1.3, Van & Courier1991 to 1994

Idle speed - manual [auto]	rpm	750±50 (fan on)
Fast idle speed - manual [auto]	rpm	2500
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Weber
Type / ref		2V (TLD)
Main jet / needle		90, 122
Injection pressure	bar	—
Pump pressure	bar	0.24 to 0.38
Octane rating	RON	98[E 95 RON]

Ignition systemFiesta 1.3, Van & Courier1991 to 1994

Type		DIS
Ignition coil		High output DIS
Primary resistance	ohms	0.5±0.05
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static	° Crankshaft @ rpm	—
V = Vacuum NV = No Vacuum		—
Total ignition advance	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Motorcraft/Champion
Type		AGRF22C1 / RS9YC
Electrode gap	mm	1.00

Electrical systemFiesta 1.3, Van & Courier1991 to 1994

Battery	V / CC / RC	12 / 270 / 50, 360 /60, 500/70
Alternator voltage / full load current / engine rpm		13.7 to 14.6 / 50, 70 / 3000
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gearFiesta 1.3, Van & Courier1991 to 1994

Brakes -		
Front (min. friction material thickness)	mm	1.5
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	145x13: 155/70x13: 165/65x13
Estate / Van	Size	145x13: 165/70x13
Pressure - front / rear - Saloon	bar	1.8 / 1.8 ¹
- Estate / Van	bar	1.8 / 1.8 ²

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	-2.0±1.0
Camber		-8'±1°20'. Van: -3'±1°20' ³
Castor		+53'±1°15'. Van: +51'±1°15' ⁴
King pin inclination		—

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	+2.3±2.0 ⁵
Camber		-1°+30'-1° ⁶

Torque wrench settingsFiesta 1.3, Van & Courier1991 to 1994

Cylinder head - stage 1	Nm	30
- stage 2	Nm	+ 90°
Cylinder head - stage 3	Nm	+ 90°
- stage 4	Nm	—
Big-end bearings	Nm	4 + 90°
Main bearings	Nm	88 to 102
Clutch cover	Nm	24 to 35
Flywheel [driveplate]	Nm	64 to 70
Front hubs	Nm	205 to 235
Rear hubs	Nm	250 to 290
Wheel nuts / bolts	Nm	100
Spark plugs	Nm	14 to 20


CapacitiesFiesta 1.3, Van & Courier1991 to 1994

Engine oil & filter	litres	3.25
Gearbox - 4-speed [5-speed]	litres	3.1
Automatic transmission - refill	litres	3.5
Final drive	litres	WT
Cooling system	litres	7.1
Fuel tank	litres	42


Notes and Illustrations

¹**155/70x13: 2.0 / 1.8**
²**Courier: 2.3 / 2.5**
³**92 ►: -9'±1°20'. Van: -6'±1°20'**
⁴**92 ►: +51'±1°15'. Van: +53'±1°15'**
⁵**Courier: +1.35±0.5**
⁶**Courier: -24.5'±10'**

1: Idle speed 2: CO / Mixture



1297 cm³



Weber TLD