

Engine & Cooling

Fuel

Ignition


Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling systemXJ-S 3.61988 to 1991

Type		AJ-6
Capacity (cm³) / number of cylinders		3590 / 6
Compression ratio / pressure	bar	9.6 / 11.0
Oil pressure	bar	2.1
Oil temperature	°C	80
Valve clearance - inlet	mm	0.30 to 0.34
Valve clearance - exhaust	mm	0.30 to 0.34
Firing order		1-5-3-6-2-4
No 1 cylinder position		TCE
Thermostat opening temperature	°C	88
Radiator cap pressure	bar	1.0

Fuel systemXJ-S 3.61988 to 1991

Idle speed - manual [auto]	rpm	700±50 (550 to 600 base idle)
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	1.0 to 1.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Lucas
Type / ref		EFI
Main jet / needle		—
Injection pressure	bar	3.0 above manifold pres.
Pump pressure	bar	3.0
Octane rating	RON	98[L] ¹

Ignition systemXJ-S 3.61988 to 1991

Type		Computerized
Ignition coil		Bosch TC1
Primary resistance	ohms	0.45 to 0.55
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		Lucas
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		Clockwise
Ignition timing - basic [static	° Crankshaft @ rpm	21 BTDC @ 2000. 89 ►: N/A
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Champion
Type		RC9YCC
Electrode gap	mm	0.90

Electrical systemXJ-S 3.61988 to 1991

Battery	V / CC / RC	12 / 66Ah
Alternator voltage / full load current / engine rpm		13.8 to 14.0 / _ / 3000
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	940 / 6.5

Running gearXJ-S 3.61988 to 1991

Brakes -		
Front (min. friction material thickness)	mm	—
Rear (min. friction material thickness)	mm	—

Tyres		
Saloon	Size	235/60x15
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	1.8 / 1.9
- Estate / Van	bar	—

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	0 to +3.2 ²
Camber		0±15'
Castor		+3°30'±15'
King pin inclination		+1°30'

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	0±0.8 ²
Camber		+15'±15'

Torque wrench settingsXJ-S 3.61988 to 1991

Cylinder head - stage 1	Nm	38 to 40
- stage 2	Nm	+ 90°
Cylinder head - stage 3	Nm	—
- stage 4	Nm	—
Big-end bearings	Nm	52 to 55
Main bearings	Nm	136 to 142
Clutch cover	Nm	23 to 27
Flywheel [driveplate]	Nm	98
Front hubs	Nm	WSM
Rear hubs	Nm	136 to 163
Wheel nuts / bolts	Nm	61
Spark plugs	Nm	—

CapacitiesXJ-S 3.61988 to 1991


Engine oil & filter	litres	8.0
Gearbox - 4-speed [5-speed]	litres	1.4
Automatic transmission - refill	litres	8.0
Final drive	litres	1.6
Cooling system	litres	11.6
Fuel tank	litres	91

Notes and Illustrations


¹89 ►: 95 [E 95 RON]

²Laden

1: Idle speed2: CO / Mixture



3590 cm³



EFI, 3590 cm³