

Engine & Cooling

Fuel

Ignition

Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system

E200

1995 to 1997

Type	DOHC 16V 100kW	
Capacity (cm³) / number of cylinders	1998 / 4	
Compression ratio / pressure	bar	9.6 / ≥10.5
Oil pressure	bar	0.3 [3.0]
Oil temperature	°C	90
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order	1-3-4-2	
No 1 cylinder position	F	
Thermostat opening temperature	°C	
Radiator cap pressure	bar	

Fuel system

E200

1995 to 1997

Idle speed - manual [auto]	rpm	
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection	—	
Type / ref		
Main jet / needle	—	
Injection pressure	bar	—
Pump pressure	bar	—
Octane rating	RON	95[U]

Ignition system

E200

1995 to 1997

Type	Computerized	
Ignition coil		
Primary resistance	ohms	
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	Battery
Distributor	—	
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation	—	
Ignition timing - basic [static	° Crankshaft @ rpm	Computer control
V = Vacuum NV = No Vacuum		
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs	—	
Type		
Electrode gap	mm	

Electrical system

E200

1995 to 1997

Battery	V / CC / RC	12 / 62Ah
Alternator voltage / full load current / engine rpm	14.0 / 90 / 2490	
Starter motor current / voltage - cranking	A / V	
- locked	A / V	

Running gear

E200

1995 to 1997

Brakes -		
Front (min. friction material thickness)	mm	3.5
Rear (min. friction material thickness)	mm	2.5

Tyres		
Saloon	Size	195/65x15:205/65x15:215/55x15
Estate / Van	Size	205/65x15: 215/55x16
Pressure - front / rear - Saloon	bar	—
- Estate / Van	bar	—

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	—
Camber	—	
Castor	—	
King pin inclination	—	

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	—
Camber	—	

Torque wrench settings

E200

1995 to 1997

Cylinder head - stage 1	Nm	55
- stage 2	Nm	+ 90°
Cylinder head - stage 3	Nm	+ 90°
- stage 4	Nm	—
Big-end bearings	Nm	30 + 90 to 100°
Main bearings	Nm	55 + 90 to 100°
Clutch cover	Nm	
Flywheel [driveplate]	Nm	30 + 90 to 100°
Front hubs	Nm	WSM
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	20


Capacities

E200

1995 to 1997

Engine oil & filter	litres	
Gearbox - 4-speed [5-speed]	litres	
Automatic transmission - refill	litres	
Final drive	litres	
Cooling system	litres	
Fuel tank	litres	65. Estate: 62

Notes and Illustrations



1998 cm³