

VAUXHALL/OPEL

Corsa-B & Combo 1.2i

1993 to 1997

Engine & Cooling

Fuel

Ignition

Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system

Corsa-B & Combo 1.2i

1993 to 1997

Type		C12NZ SOHC. 33kW 91/441/EEC
Capacity (cm ³) / number of cylinders		1196 / 4
Compression ratio / pressure	bar	9.1 / _
Oil pressure	bar	1.5
Oil temperature	°C	≥80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	88 to 106
Radiator cap pressure	bar	1.2 to 1.4

Fuel system

Corsa-B & Combo 1.2i

1993 to 1997

Idle speed - manual [auto]	rpm	840 to 1000 N/A
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	1.5±0.5 WSM
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	_
O2 @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		GM
Type / ref		Multec-ZE CFI
Main jet / needle		_
Injection pressure	bar	0.76
Pump pressure	bar	_
Octane rating	RON	95[U]

Ignition system

Corsa-B & Combo 1.2i

1993 to 1997

Type		Multec-MSTS-h
Ignition coil		Delco
Primary resistance	ohms	0.43
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		_
Points gap (air gap)	mm	_
Dwell angle	° (%)	Electronic control
Condenser capacity	µF	_
Rotation		Anticlockwise
Ignition timing - basic [static	° Crankshaft @ rpm	10 BTDC @ 840 to 1000 N/A
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	_
Spark plugs		Bosch/Champion
Type		WR8DC / RN7YC
Electrode gap	mm	0.70 to 0.80

Electrical system

Corsa-B & Combo 1.2i

1993 to 1997

Battery	V / CC / RC	12 / 180 / 36Ah or / 210 / 44
Alternator voltage / full load current / engine rpm		14.7±0.5 / 55 / 3500
Starter motor current / voltage - cranking	A / V	70 / 11.5 (no load)
- locked	A / V	450 to 650 / 5.6

Running gear

Corsa-B & Combo 1.2i

1993 to 1997

Brakes -		
Front (min. friction material thickness)	mm	7.0 with backing
Rear (min. friction material thickness)	mm	0.5 above rivets

Tyres		
Saloon	Size	145x13: 165/70x13: 165/65x14
Estate / Van	Size	Combo: 165/70x13
Pressure - front / rear - Saloon	bar	1.9 / 1.7
- Estate / Van	bar	1.9 / 1.9

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+0.5±1.0 L
Camber		-35'±45' L
Castor		+1°50'±1° L
King pin inclination		_

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+1.0+3.0-1.5
Camber		-1°30'±30' L

Torque wrench settings

Corsa-B & Combo 1.2i

1993 to 1997

Cylinder head - stage 1	Nm	25 N
- stage 2	Nm	+ 60°
Cylinder head - stage 3	Nm	+ 60°
- stage 4	Nm	+ 60°
Big-end bearings	Nm	25 ¹
Main bearings	Nm	50 +45° +15° N
Clutch cover	Nm	15
Flywheel [driveplate]	Nm	35 +30° +15° N
Front hubs	Nm	WSM
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	25

Capacities

Corsa-B & Combo 1.2i


1993 to 1997

Engine oil & filter	litres	3.5
Gearbox - 4-speed [5-speed]	litres	1.6
Automatic transmission - refill	litres	_
Final drive	litres	WT
Cooling system	litres	5.9
Fuel tank	litres	46. Combo: 50

Notes and Illustrations

¹40mm bolt: 25 +30° N

²Van: 145/80x13: 165/70x13: 165/65x14: 2.1 / 1.9



1196 cm³