

# Troubleshooting

## Symptom-to-System Chart

PROBLEM CODE		PROBLEMATIC COMPONENT/ SYSTEM	AFFECTED				See page	OTHER COMPONENT	See page
MAIN CODE	SUB CODE		FRONT RIGHT	FRONT LEFT	REAR RIGHT	REAR LEFT			
1	—	Hydraulic Controlled Components	—	—	—	—	13-51	-ALB fuse -Motor relay -Pressure Switch -Accumulator -Modulator	13-80
2	—	Parking brake switch-related problem	—	—	—	—	13-54	Brake fluid level switch BRAKE light	
3	1	Pulser(s)	○				13-81		
	2			○					
	4				○	○			
4	1	Speed sensor	○				13-55		
	2			○					
	4				○				
	8					○			
5	—	Speed sensor (s)			○	○	13-56	-Modulator	
5	4				○				
5	8					○			
6	—	Fail safe relay	—	—	—	—	13-57 (Function Test)	Front or rear fail safe relay	
6	1		—	—	—	—		Front fail safe relay	
6	4		—	—	—	—		Rear fail safe relay	
7	1	Solenoid related problem (Open or short)	○				13-61	ALB 3 fuse	
	2			○				ALB 1 fuse	
	4				○	○		-Rear fail safe relay -Pressure Switch -Motor relay	

NOTE: In the event of simultaneous speed sensor or solenoid problems (codes 4 or 7), the control unit will only indicate the higher number sub-code.