


Heater Control Panel




Replacement

1. Remove the ashtray.
Remove the console.



2. Remove the switches, coin box, air vent, and ashtray lighting bracket.



(cont'd)