




(LEVER TYPE)





# Heater Door Position

(LH Type)

- Always blowing air in every mode.

← HOT

← COLD



(COOL VENT)

